
Tony Giampaolo MSME, PE

Compressor Handbook

PRINCIPLES AND PRACTICE



Compressor Handbook: Principles and Practice



Compressor Handbook: Principles and Practice

By Tony Giampaolo, MSME, PE





Library of Congress Cataloging-in-Publication Data

Giampaolo, Tony, 1939-

Compressor handbook: principles and practice/by Tony

Giampaolo.

p. cm.

Includes index.

ISBN-10: 0-88173-615-5 (alk. paper)

ISBN-10: 0-88173-616-3 (electronic)

ISBN-13: 978-1-4398-1571-7 (Taylor & Francis : alk. paper)

1. Compressors--Handbooks, manuals, etc. I. Title.

TJ990.G53 2010 621.5'1--dc22

Compressor handbook: principles and practice by Tony Giampaolo

2010008818

©2010 by The Fairmont Press. All rights reserved. No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopy, recording, or any information storage and retrieval system, without permission in writing from the publisher.

Published by The Fairmont Press, Inc. 700 Indian Trail

Lilburn, GA 30047

tel: 770-925-9388; fax: 770-381-9865 http://www.fairmontpress.com

Distributed by Taylor & Francis Ltd. 6000 Broken Sound Parkway NW, Suite 300 Boca Raton, FL 33487, USA

E-mail: orders@crcpress.com

Distributed by Taylor & Francis Ltd.

23-25 Blades Court Deodar Road

London SW15 2NU, UK

E-mail: uk.tandf@thomsonpublishingservices.co.uk

Printed in the United States of America 10 9 8 7 6 5 4 3 2 1

0-88173-615-5 (The Fairmont Press, Inc.) 978-1-4398-1571-7 (Taylor & Francis Ltd.)

While every effort is made to provide dependable information, the publisher, authors, and editors cannot be held responsible for any errors or omissions.


Pages 221-232: Compressor specifications in Appendix XX From the 2009 Compressor Technology Sourcing Supplement, courtesy COMPRESSORTechTwo magazine, published by Diesel & Gas Turbine Publications. Current compressor information can be found at www.compressortech2 or www.CTSSNet.net.

Dedication

This book is dedicated to my five grandchildren:

Amanda Rose
Anna Josephine
Carly Paige
Riley James
Nickolas Anthony

They are the future.




Contents

Preface	xi
Acknowledgements	xiii
Chapter 1—Introduction	1
History	
Flistory	1
Chapter 2—General Compressor Theory	7
Thermodynamics of Compression	7
Chapter 3—Compressor Types	15
Dynamic Compressors	
Axial Compressors	15
Centrifugal Compressors	
Variations in Compressor Design	
Positive Displacement Compressors	
Blowers	
Reciprocating Compressors	29
Preliminary Selection and Sizing	
Screw Compressors	
Screw Compressor Control	
Chapter 4—Effect of Operating Conditions	63
Effects of Temperature & Pressure	
Effects of Compression Ratio	
Effects of Specific Heat Ratio	
Chapter 5—Throughput Control	7 3
Speed Control	
Suction Throttling Control	
Discharge Valve Throttling Control	
Recycle Valve Control	74
Variable Volume Pocket Control	
Chapter 6—Description of Surge	81
Surge & Stall	

Chapter 7—Surge Control	85
Minimum Flow Control	85
Maximum Pressure Control	85
Ratio Control	87
Chapter 8—Vibration	97
Rotor Response	97
Sources of Vibration	
Chapter 9—Valve Requirements	105
Valve Types	
Valve Trim	
Chapter 10—Instrument Requirements	111
Sensor Types	
Speed of Response	
Chapter 11—Detectable Problems	
Mechanical Problems	
Electrical Problems	
Performance Problems	
Chapter 12—Controlling Reciprocatng and Centrifugal	
Compressors in Identical Processes	131
Chapter 13—Optimization & Revitalization of Existing	
Reciprocating Compression Assets	145
Chapter 14—Piston Rod Run-out is a Key Criterion for	
Recip Compressors	183
Chapter 15—Effect of Pulsation Bottle	
Design on the Performance of a Modern	400
Low-speed Gas Transmission Compressor Piston.	193
Chapter 16—Resolution of a Compressor Valve Failure:	
A Case Study	211

APPENDIX

A1	Compressor Manufacturers	221
A2	Comparison of Three Types of Compressors	233
B1	List of Symbols	234
B2	Glossary of Terms	
В3	Conversion Factors	267
C	Gas Processers Suppliers Association	
	Select Curves & Charts	272
D	Classification of Hazardous Atmospheres	310
E	Air/Oil Cooler Specifications Check List	311
F	Cylinder Displacement Curves	314
G	Compressor Cylinder Lubrication	
Н	Troubleshooting Chart	
I	Typical Starting, Operating and Maintenance	
	Procedures for a Reciprocating Compressor	324
J	Basic Motor Formulas and Calculations	
INDEX		353



Preface

Compressors have played a major role in setting our standard of living and they have contributed significantly to the industrial revolution. Early compressors like the bellows (used to stoke a fire or the water organ use to make music) marked the beginning of a series of compression tools. Without compression techniques we could not have efficiently stabilized crude oil (by removing its trapped gasses) or separated the various components of gas mixtures or transported large quantities of gas cross country via gas pipelines. Today, compressors are so much a part of our every day existence that many of us do not even recognize them for what they are. Compressors exist in almost every business and household as vacuum cleaners and heating & air conditioning blowers. Even those who have worked with compressors (usually only one or two types of compressor) have only a vague awareness of the variety of compressors in existence today.

It is always interesting to see how the inventive process takes place, and how the development process progresses from inception to final design. Therefore, included in some sections of the book is historical information on the development of various compressors. Due to the number of different types of compressors it was too time consuming to research the origins of each compressor type. For the roots blower and screw compressor the inventive process is clear as discussed in Chapters 1 and 3. However, the origin of the reciprocating compressor is somewhat obscured. No doubt the water organ devised by Ctesibius of Alexandria paved the way. Nevertheless, using water to compress air in a water organ is a far cry from a piston moving within a cylinder to compress gas. True there is significant similarity between reciprocating engines and reciprocating compressors: Just as there is similarity between turbo compressors and turbine expanders.

Many engineers/technicians/operators spend their entire careers in one product discipline (manufacturing, maintenance, test, sales, etc...). Sometimes they have had the opportunity to work in several disciplines. This book is intended to assist in the transition from an academic background to a practical field, or from one field to another. It will assist the reader in his day-to-day duties as well as knowing where to look for additional information. Also people respond better when they understand

why they are asked to perform certain functions, or to perform them in a certain order.

My intention is to provide a basic understanding of the variety of compressors. The need for this book has grown out of the request for seminars and training sessions from utilities and oil & gas companies. Most often these companies hire new employees or relocate and retrain their current employees. The reader may have some experience in the operation or maintenance of some compression equipment from previous assignments.

This book provides a practical introduction to dynamic and positive displacement compressors, including compressor performance, operation and problem awareness. In reading this book the reader will learn what is needed to select, operate and troubleshoot compressors and to communicate with peers, sales personnel and manufacturers in the field of dynamic and positive displacement compressor applications.

In addition to the theoretical information, real life case histories are presented. The book demonstrates investigative techniques to identify and isolate various contributing causes such as: design deficiencies, manufacturing defects, adverse environmental conditions, operating errors, and intentional or unintentional changes of the machinery process that precede the failure. Acquiring and perfecting these skills will enable readers to go back to their workplace and perform their job functions more effectively.

In addition to the content of this book the engineer/technician/ operator will find that the information provided in the appendix will become a useful reference for years to come.

> Tony Giampaolo Wellington, FL January 2010

Acknowledgements

I would like to recognize and thank the following individuals for their support and assistance in obtaining photographs for use in this book:

Norm Shade, President, ACI Services, Inc.

Danny L. Garcia, Project Manager, Sun Engineering Services, Inc.

Roger Vaglia, Product Manager (Retired), Cooper Ind., White Superior Division

John Lunn Engineering Manager (Retired) Rolls Royce USA

Everette Johnson, Engineering Manager, Cameron Compressor Corporation

Ben Suurenbroek (Retired), Cooper Energy Services—Europe Dave Kasper, District Manager, Dresser Roots, Inc.

I also want to acknowledge and thank Peter Woinich, Design Engineer, Construction Supervisor and Associate (Retired) of William Ginsberger, Associates for his help in proofreading this manuscript.

Also I wish to acknowledge and thank the following companies for their confidence and support by providing many of the photographs and charts that are in this book.

ACI Services, Inc.

Baldor Electric Company

Cameron Compressor Corporation

COMPRESSORTech^{Two} magazine, published by Diesel & Gas Turbine

Publications

Dresser Roots, Inc

Gas Processors Suppliers Association

MAN Turbo AG

Oil & Gas Journal


Penn Engineering

Petroleum Learning Programs

Rolls Royce USA

Sun Engineering Services, Inc.

United Technologies Corp, Pratt & Whitney Canada



Chapter 1

Introduction

HISTORY

The history of compressors is as varied as are the different types of compressors. Therefore it is fitting that we first identify the different types of compressors. As shown in Chart 1-1, compressors fall into two separate and distinct categories: dynamic and positive displacement.




Chart 1-1

Somewhere in antiquity the bellows was developed to increase flow into a furnace in order to stoke or increase furnace heat. This was necessary to smelt ores of copper, tin, lead and iron. This led the way to numerous other inventions of tools and weapons.

One of the earliest recorded uses of compressed gas (air) dates back to 3rd century B.C. This early use of compressed air was the "water organ." The invention of the "water organ" is commonly credited to Ctesibius of Alexandria¹. The concept was further improved by Hero of Alexandria (also noted for describing the principles of expanding steam to convert steam power to shaft power).

The water organ consisted of a water pump, a chamber partly filled with air and water, a row of pipes on top (organ pipes) of various diameters and lengths plus connecting tubing and valves. By pumping water into the water/air chamber the air becomes compressed. Than by opening valves to specific organ pipes the desired musical sound is created.

Ctesibius also developed the positive displacement cylinder and piston to move water.

It was not until the late 19th century that many of these ideas were turned into working hardware.

In the 1850s, while trying to find a replacement for the water wheel at their family's woolen mill, Philander and Francis Roots devised what has come to be known as the Roots blower³. Their design consisted of a pair of figure-eight impellers rotating in opposite directions. While some Europeans were simultaneously experimenting with this design, the Roots brothers perfected the design and put it into large-scale production.

It is not surprising that other compressor designs followed power-



Figure 1-1. Water Organ Developed By Ctesibius.²



Figure 1-2. Photo Courtesy of Frick by Johnson Controls.

Introduction 3




Figure 1-3. Cooper-Bessemer Z-330 Integral Engine Compressors in Krunmhorn, Germany. Courtesy of Ben Suurenbroek (Retired Cooper Energy Services)

producing designs. For example, the reciprocating engine concept easily transfers to the reciprocating compressor.

The integral-engine-compressor is a good example as its design utilizes one main shaft connected to both the power cylinders and the compression cylinders. The form and function of the compressor cylinders are the same whether it is configured as an integral engine-compressor or a separable-compressor driven by an electric motor, gas engine or turbine.

Other examples are the centrifugal compressor, (Figure 1-4) the turbo-expander, the axial compressor, and the axial turbine (Figure 1-5 and 1-6).

In 1808 John Dumball envisioned a multi-stage axial compressor. Unfortunately his idea consisted only of moving blades without stationary airfoils to turn the flow into each succeeding stage.^{4,5,6}

Not until 1872 did Dr. Franz Stolze combine the ideas of John Bar-





Figure 1-4. Barrel Compressor Courtesy of Rolls-Royce USA (formerly Cooper Industries Energy Services).

Figure 1-5. Five Stage Power Turbine Rotor From RT15 Turbine Designed For 12,000 RPM Courtesy of Rolls-Royce USA (formerly Cooper Industries Energy Services).



ber and John Dumball to develop the first axial compressor driven by an axial turbine. Due to a lack of funds, he did not build his machine until 1900. Dr. Stolze's design consisted of a multi-stage axial flow compressor, a single combustion chamber, a multi-stage axial turbine, and a regenerator utilizing exhaust gases to heat the compressor discharge gas. This unit was tested between 1900 and 1904, but never ran successfully.

Operating conditions have a significant impact on compressor

Introduction 5

INTRODUCING THE ST18




Figure 1-6. Courtesy of United Technologies Corporation, Pratt & Whitney, Canada. The ST-18 is a 2 Megawatt Aeroderivative Combining Centrifugal Compressor & Axial Expansion Turbine.

2MW AERODERIVATIVE

selection and compressor performance. The influences of pressure, temperature, molecular weight, specific heat ratio, compression ratio, speed, vane position, volume bottles, loaders and unloaders, etc. are addressed in this book. These conditions impact compressor capacity and therefore the compressor selection. They also impact the compressor efficiency. Flexibility in selection is still possible to some extent as compressors can be operated in parallel and series modes. For example, to achieve higher pressures multiple compressors can be configured in series whereby the discharge of one compressor feeds directly into the suction of a second compressor, etc. Likewise, to achieve higher flows multiple compressors can be configured in parallel whereby the suction of each compressor is manifolded together and the discharge of each compressor is also manifolded together.

Different methods of throughput control are addressed in Chapter 5, such as, discharge throttling, suction throttling, guide vane positioning, volume bottles, suction valve unloaders and speed control; and how each of these control methods effects compressor life.

This book discusses different compressors; how they operate and how they are controlled. Since the cost of process downtime and damage to a compressor can range from thousands to millions of dollars; the types of failures that can occur and how to avoid these failures is also addressed in this book.

In view of the fact that the most destructive event in a dynamic compressor is surge, compressor surge will be defined and discussed in detail. Also discussed are the various types of instrumentation (controllers, valves, pressure and temperature transmitters, etc..) available and

which are most suitable in controlling surge. Destructive modes of other compressors are also addressed.

A few algorithms are presented, primarily in Chapters 4 and 7, to help demonstrate interactions of pressure, temperature and quantify results, but their understanding is not essential to the selection of the proper control scheme and instrumentation. The reader should not be intimidated by these algorithms as their understanding will open up a broader appreciation of how the compressor works.

Footnotes

- 1 *A History of Mechanical Inventions*, Abbott Payton Usher. This Dover edition, first published in 1988, is an unabridged and unaltered republication of the revised edition (1954) of the work first published by Harvard University Press, Cambridge, MA, in 1929.
- 2 Multiple sources were found for this sketch, none of which referenced a source.
- 3 Initiative In Energy, The Story of Dresser Industries, Darwin Payne, 1979
- 4 Engines—The Search for Power, John Day, 1980
- 5 The Gas Turbine, Norman Davy, 1914
- 6 Modern Gas Turbines, Arthur W. Judge 1950

Chapter 2

General Compressor Theory

Compressors are mechanical devices used to increase the pressure of air, gas or vapor and in the process move it from one location to another. The inlet or suction pressure can range from low subatmospheric pressure levels to any pressure level compatible with piping and vessel strength limits. The ratio of absolute discharge pressure to absolute suction pressure is the compressor pressure ratio (*CR*—see Appendix B2, Glossary of Terms). Stage compression is limited to the mechanical capabilities of the compressor and, generally, approaches a *CR* of 4. To achieve high pressures multiple stages must be employed.

Compression theory is primarily defined by the Ideal Gas Laws and the First & Second Laws of Thermodynamics. As originally conceived the Ideal Gas Law is based on the behavior of pure substances and takes the following form:

$$Pv = RT (2-1)$$

Where

P = Absolute Pressure

v = Specific Volume

R = Gas Constant

T = Absolute Temperature

This equation is based on the laws of Charles, Boyle, Gay-Lussac and Avogadro (see Appendix B2 Glossary of Terms).

Note all properties should be defined in the same measuring system (for example either the English system or the metric system). Conversion factors listed in Appendix B3 can be used to assist in obtaining consistent units. Table 2-1 sums up the two systems.

Parameter	Symbol	English System	Metric System
Pressure	Р	Absolute pressure (psia)	Pascals or Kilopascals
Temperature	T	Absolute temperature (°R)	Degrees Kelvin (°K)
Specific Volume v		Cubic inches per pound	Cubic centimeters per gram or cubic meters per kilogram
Universal Gas R Constant		1545 ft-lbf/ lbm °R	8.3144 kN m/ kmol °K

Table 2-1.

The ideal gas law can be manipulated to obtain several useful relationships. By multiplying both sides of the equation by the mass "m" of the gas the specific volume becomes total volume:

$$V = mv$$

$$PV = mRT (2-2)$$

Considering that the mass of any gas is defined as the number of moles times its molecular weight than (see Avogadro's Law in Appendix B2):

 $m = n \times mw$

and

$$PV = n \times mw \times RT \tag{2-3}$$

(2-4)

and
$$\overline{R} = mw \times R$$

Where \bar{R} is the universal gas constant

$$\frac{P_1 V_1}{T_1} = n \overline{R} = mR = \frac{P_2 V_2}{T_2}$$
 (2-5)

The specific gas constant may be obtained using the universal gas

constant and equation 2-4 above. However, Table 2-2 list the specific gas constant for some of the more common gases.

Table 2-2

Gas	Formula	Molecular Weight	Specific Gas Constant $\frac{ft \times lb_f}{lb_m} \times {}^{\circ}R$
Helium	Не	4.003	386.2
Carbon Monoxide	CO	28.01	55.18
Hydrogen	H_2	2.016	766.6
Nitrogen	N_2	28.02	55.16
Oxygen	O_2	32.00	48.29
Carbon Dioxide	CO_2	44.01	35.12
Sulfur Dioxide	SO_2	64.07	24.12
Water Vapor	H_2O	18.02	85.78
Methane	$\overline{\mathrm{CH}_{4}}$	16.04	96.35
Ethane	C_2H_6	30.07	51.40
Iso-butane	$C_{4}H_{10}$	58.12	26.59

Dividing both sides by "time" the total volume becomes volumetric flow and the mass flow per unit time becomes the mass flow rate "W."

$$PQ = WRT (2-6)$$

Where

Q = Volumetric Flow Rate

W = Mass Flow Rate

A pure substance is one that has a homogeneous and constant chemical composition throughout all phases (solid, liquid and gas). For most compressor applications a mixture of gases may be considered a pure substance as long as there is no change of phase. The significance of introducing this concept is that the state of a simple compressible pure substance is defined by two independent properties.

An additional term may be considered at this time to correct for deviations from the ideal gas laws. This term is the compressibility factor "Z."

Therefore, the ideal gas equation becomes

$$Pv = ZRT (2-7)$$

and

$$PQ = ZWRT (2-8)$$

Compressor performance is generally shown as pressure ratio plotted against flow. (Note: it is more accurate to use head instead of pressure ratio, because head takes into account the compressibility factor of the gas, molecular weight, temperature, and the ratio of specific heat of the gas—and corrected flow—all at constant speed). This is discussed in more detail later in this chapter.

Other relationships that are also useful are:

Reduced Temperature and Pressure

$$T_{r} = \frac{T}{T_{c}} \tag{2-9}$$

$$P_{r} = \frac{P}{P_{c}} \tag{2-10}$$

Where

Tr = Reduced Temperature

Pr = Reduced Pressure

Tc = Critical Temperature

Pc = Critical Pressure

T = Observed Temperature

P = Observed Pressure

Partial Pressure

The total pressure is equal to the sum of the partial pressures

$$P = P_1 + P_2 + P_3 + \dots (2-11)$$

This relationship is defined by Dalton's Law (see Appendix B2).

If the total pressure of the mixture is known than the partial pressure can be calculated from the mole fraction.

$$P = P_1 + P_2 + P_3 + \dots (2-12)$$

The mole fraction "x" is

$$x_1 = \frac{M_1}{M_m}$$
; $x_2 = \frac{M_2}{M_m}$; $x_3 = \frac{M_3}{M_m}$; (2-13)

The partial pressure may then be calculated as follows

$$P_1 = x_1 \times P$$
; $P_2 = x_2 \times P$; $P_3 = x_3 \times P$ (2-14)

$$x_1 + x_2 + x_3 + = 1.0 (2-15)$$

First Law of Thermodynamics

The first law of thermodynamics states that energy cannot be created or destroyed but it can be changed from one form to another.

$$Q_{h} = \overline{W}_{w} + \Delta E \tag{2-16}$$

Where

 Q_h = Heat into the system

 \overline{W}_{w} = Work by the system

 ΔE = Change in system energy

Note: the symbol \overline{W} is used to denote work, whereas the symbol W indicates weight flow rate.

Second Law of Thermodynamics

The second law of thermodynamics states that the entropy of the universe always increases. This is the same law that indicates that perpetual motion machines are not possible.

$$\Delta s \ge 0 \tag{2-17}$$

Horse Power Calculations

The brake horsepower (BHP) required to drive the compressor can be determined by calculating the gas horsepower (GHP) and then correcting for mechanical losses.

$$GHP = \frac{H_d \times W_g}{60 \times 33,000 \times E_p}$$
 (2-18)

Where

BHP = Brake horsepower

 H_d = Head (adiabatic) – ft-lb/lb

 W_g = Weight flow of the gas – lbs/hr

 E_p = Adiabatic efficiency

and

$$W_g = \frac{SCFD \times MW}{24 \times 379.5} \tag{2-19}$$

If capacity is available GHP can be calculated directly.

$$GHP = \frac{\left\{Q_1 \times P_1 \times \left(\frac{Z_{av}}{Z_1}\right) \times \left(\frac{CR\frac{k-1}{k}-1}{\frac{k-1}{k}}\right)\right\}}{(229 \times E_p)} \tag{2-20}$$

Where

 Q_1 = Inlet cubic feet/minute (ICFM)

 P_1 = Suction pressure—psia

CR = Compression ratio

K = Specific heat ratio

Zav = Average gas compressibility factor


 Z_1 = Gas compressibility factor at compressor inlet

Then brake horsepower is

$$BHP = GHP \ x \ (1 + \% \ Mechanical \ Losses) \tag{2-21}$$

Each compressor type has its own unique characteristics that will be covered in the section specific to that compressor type.

Note: The physical and thermodynamic properties of many gases are provided in Appendix C, courtesy of the Gas Processors Suppliers Association (GPSA).



Chapter 3

Compressor Types

DYNAMIC COMPRESSORS

Two types of dynamic compressors are in use today—they are the *axial* compressor and the *centrifugal* compressor. The axial compressor is used primarily for medium and high horsepower applications, while the centrifugal compressor is utilized in low horsepower applications.

Both the axial and centrifugal compressors are limited in their range of operation by what is commonly called **stall** (or **surge**) and **stone wall**. The **stall** phenomena occurs at certain conditions of flow, pressure ratio, and speed (rpm), which result in the individual compressor airfoils going into stall similar to that experienced by an airplane wing at a high angle of attack. The stall margin is the area between the steady state operating line and the compressor stall line. Surge or stall will be discussed in detail later in this chapter. **Stone wall** occurs at high flows and low pressure. While it is difficult to detect. **Stone wall** is manifested by increasing gas temperature.

Axial Compressors

Gas flowing over the moving airfoil exerts lift and drag forces approximately perpendicular and parallel to the surface of the airfoil (Figure 3-1). The resultant of these forces can be resolved into two components:

- 1. the component parallel to the axis of the compressor represents an equal and opposite rearward force on the gas—causing an increase in pressure;
- 2. a component in the plane of rotation represents the torque required to drive the compressor.




Figure 3-1. Forces Acting on the Blades

From the aerodynamic point of view there are two limiting factors to the successful operation of the compressor. They are the angle of attack of the airfoil and the speed of the airfoil relative to the approaching gas (Figure 3-2). If the angle of attack is too steep, the flow will not follow the concave surface of the airfoil. This will reduce lift and increase drag. If the angle of attack is too shallow, the flow will separate from the concave surface of the airfoil. This also results in increased drag.




Figure 3-2. Airfoil Angle of attack Relative to Approaching Air or Gas

If the speed of the airfoil relative to the gas is too high, a shock will develop as the gas exceeds the speed of sound trying to accelerate as it passes around the airfoil. This shock will cause turbulent flow and result in an increase in drag. Depending on the length of the airfoil, this excessive speed could apply only to the tip of the compressor blade. Manufacturers have overcome this, in part, by decreasing the length of the airfoil and increasing the width (or chord).

For single-stage operation, the angle of attack depends on the relation of flow to speed. It can be shown that the velocity relative to the blade is composed of two components: the axial component depends on the flow velocity of the gas through the compressor, and the tangential component depends on the speed of rotation of the compressor (Figure 3-3). Therefore, if the flow for a given speed of rotation (rpm) is reduced, the direction of the gas approaching each blade is changed so as to increase the angle of attack. This results in more lift and pressure rise until the stall angle of attack is reached.




Figure 3-3. Velocity Component Relative to Airfoil

This effect can be seen on the compressor characteristic curve. The characteristic curve plots pressure against flow (Figure 3-4). The points on the curve mark the intersection of system resistance, pressure, and flow. (Note that opening the bleed valve reduces system resistance and moves the compressor operating point away from surge.) The top of each constant speed curve forms the loci for the compressor stall (surge) line.

Therefore, the overall performance of the compressor is depicted on the compressor performance map, which includes a family of constant speed (rpm) lines (Figure 3-5). The efficiency islands are included to show the effects of operating on and off the design point. At the design speed and flow, the angle of attack relative to the blades is optimum




Figure 3-4. Compression System Curve




Figure 3-5. Compressor Performance Curve

and the compressor operates at peek efficiency. If flow is reduced at a constant speed, the angle of attack increases until the compressor airfoil goes into stall.

As flow is increased at a constant speed the compressor characteristic curve approaches an area referred to as "stone wall." Stone wall does not have the dynamic impact that is prevalent with stall, but it is a very inefficient region. Furthermore, operation at or near stonewall will result in overtemperature conditions in the downstream process.

From the mechanical point of view, blade stresses and blade vibration are limiting factors. The airfoil must be designed to handle the varying loads due to centrifugal forces, and the load of compressing

gas to higher and higher pressure ratios. These are conflicting requirements. Thin, light blade designs result in low centrifugal forces, but are limited in their compression-load carrying ability; while thick, heavy designs have high compression-load carrying capability, but are limited in the centrifugal forces they can withstand. Blade vibration is just as complex. There are three categories of blade vibration: resonance, flutter, and rotating stall. They are explained here.

Resonance—As a cantilever beam, an airfoil has a natural frequency of vibration. A fluctuation in loading on the airfoil at a frequency that coincides with the natural frequency will result in fatigue failure of the airfoil.

Flutter—A self-excited vibration usually initiated by the airfoil approaching stall.

Rotating Stall—As each blade row approaches its stall limit, it does not stall instantly or completely, but rather stalled cells are formed (see Rotating Stall Figure 6-1). Stall is discussed in more detail in Chapter 6.

The best way to illustrate flow through a compressor stage is by constructing velocity triangles (Figure 3-6). Gas leaves the stator vanes at an absolute velocity of C_1 and direction θ_1 . The velocity of this gas relative to the rotating blade is W_1 at the direction β_1 . Gas leaves the rotating stage with an absolute velocity C_2 and direction θ_2 , and a relative velocity W_2 and direction β_2 . Gas leaving the second stator stage has the same velocity triangle as the gas leaving the first stator stage. The projection of the velocities in the axial direction are identified as Cx, and the tangential components are Cu. The flow velocity is represented by the length of the vector. Velocity triangles will differ at the blade hub, mid-span, and tip just as the tangential velocities differ.

Pressure rise across each stage is a function of the gas density, ρ , and the change in velocity. The pressure rise per stage is determined from the velocity triangles:

$$\Delta P = \frac{\rho}{2g_C} (W_1^2 - W_2^2) + \frac{\rho}{2g_C} (C_2^2 - C_3^2)$$
 (3-1)

This expression can be further simplified by combining the differential pressure and density, and referring to feet of head.




Figure 3-6. Velocity Diagrams for an Axial Flow Compressor.

Head =
$$\frac{\mu}{g_C} \times \Delta C = \frac{\Delta P}{\rho}$$
 (3-2)

where $\Delta P/\rho$ is the pressure rise across the stage and head is the pressure rise of the stage measured in feet head of the fluid flowing. The standard equation for compressor head is given below.

$$Head = \frac{Z_{ave}T_s}{MW} \left(\frac{R_c^{\sigma} - 1}{\sigma}\right)$$
 (3-3)

where Z_{ave} is the average compressibility factor of gas, and MW is the mole weight.

Before proceeding further, we will define the elements of an airfoil (Figure 3-7).

Fixed Blade Row Turning Angle $\equiv \epsilon = \beta_2' - \beta_1' xx$ Moving Blade Row Chord Length

Camber Line Leading Edge Camber or Blade Angle = β_2 - β_1 Trailing Edge Inlet Blade Angle = β_1 Maximum Thickness = tExit Blade Angle = β_2 Width = wHeight = hInlet Flow Angle = β_1 ' Aspect Ratio = ratio of blade height Exit Flow Angle = β_2' Angle of Deviation = $\beta_2 - \beta_2'$ to blade chord Stagger Angle = γ Angle of Attack or angle if incidence $\equiv i = \beta_1 - \beta_1'$ Pitch = s




Figure 3-7. Elements of an Airfoil.

Centrifugal Compressors

The centrifugal compressor, like the axial compressor, is a dynamic machine that achieves compression by applying inertial forces to the gas (acceleration, deceleration, turning) by means of rotating impellers.

The centrifugal compressor is made up of one or more stages, each stage consisting of an impeller and a diffuser. The impeller is the rotating element and the diffuser is the stationary element. The impeller consist of a backing plate or disc with radial vanes attached to the disc from the hub to the outer rim. Impellers may be either open, semi-enclosed, or enclosed design. In the open impeller the radial vanes attach directly to the hub. In this type of design the vanes and hub may be machined from one solid forging, or the vanes can be machined separately and welded to the hub. In the enclosed design, the vanes are sandwiched between two discs. Obviously, the open design has to deal with gas leakage between the moving vanes and the non-moving diaphragm, whereas the enclosed design does not have this problem. However, the enclosed design is more difficult and costly to manufacture.

Generally gas enters the compressor perpendicular to the axis and turns in the impeller inlet (eye) to flow through the impeller. The flow through the impeller than takes place in one or more planes perpendicular to the axis or shaft of the machine. This is easier to understand when viewing the velocity diagrams for a centrifugal compressor stage. Although the information presented is the same, Figure 3-8 demonstrates two methods of preparing velocity diagrams.

Centrifugal force, applied in this way, is significant in the development of pressure. Upon exiting the impeller, the gas moves into the diffuser (flow decelerator). The deceleration of flow or "diffuser action"




Figure 3-8. Velocity Diagrams for a Centrifugal Compressor

causes pressure build-up in the centrifugal compressor. The impeller is the only means of adding energy to the gas and all the work on the gas is done by these elements. The stationary components, such as guide vanes and diffusers, can only convert velocity energy into pressure energy (and incur losses). Pressure from the impeller eye to the impeller outlet is represented by the following:

$$P_{m} = \frac{G}{2g_{c}}[(C_{2}^{2} - C_{1}^{2}) + (U_{2}^{2} - U_{1}^{2}) + (W_{1}^{2} - W_{2}^{2})] = \frac{G}{2g_{c}}(C_{2u}U_{2} - C_{1u}U_{1}) \quad (3-4)$$

The term $(C_2^2 - C_1^2)/2g_c$ represents the increase in kinetic energy contributed to the gas by the impeller. The absolute velocity C_1 (entering the impeller) increases in magnitude to C_2 (leaving the impeller). The increase in kinetic energy of the gas stream in the impeller does not contribute to the pressure increase in the impeller. However, the kinetic energy does convert to a pressure increase in the diffuser section. Depending on impeller design, pressure rise can occur in the impeller in relation to the terms $(U_2^2 - U_1^2)/2g_c$ and $(W_1^2 - W_2^2)/2g_c$. The term $(U_2^2 - U_1^2)/2g_c$ measures the pressure rise associated with the radial/centrifugal field, and the term $(W_1^2 - W_2^2)/2g_c$ is associated with the relative velocity of the gas entering and exiting the impeller. The ideal head is defined by the following relationship:

Head_{ideal} =
$$P_m = \frac{1}{g_c} (C_2^2 - C_1^2)/2g_c$$
 (3-5)

Flow coefficient
$$\phi$$
 is defined as = $\frac{Q}{AU}$ (3-6)

where

Q = Cubic feet per second (CFS)

 $A = Ft^2$

U = Feet per sec

rewriting this equation
$$\phi = \frac{700Q}{D^3N}$$
 (3-7)

where D is diameter, and N is rotor speed.

The flow coefficients are used in designing and sizing compressors and in estimating head and flow changes resulting as a function of tip speed (independent of compressor size or rpm). Considering a constant geometry compressor, operating at a constant rpm, tip speed is also constant. Therefore, any changes in either coefficient will be directly related to changes in head or flow. Changes in head or flow under these conditions result from dirty or damaged compressor impellers (or airfoils). This is one of the diagnostic tools used in defining machine health.

The thermodynamic laws underlying the compression of gases are the same for all compressors—axial and centrifugal. However, each type exhibits different operating characteristics (Figure 3-9). Specifically, the constant speed characteristic curve for compressor pressure ratio relative to flow is flatter for centrifugal compressors than for axial compressors. Therefore, when the flow volume is decreased (from the design point) in a centrifugal compressor, a greater reduction in flow is possible before the surge line is reached. Also, the centrifugal compressor is stable over a greater flow range than the axial compressor, and compressor efficiency changes are smaller at off design points.

For the same compressor radius and rotational speed the pressure rise per stage is less in an axial compressor than in a centrifugal compressor. But, when operating within their normal design range, the efficiency of an axial compressor is greater than a centrifugal compressor.




Figure 3-9. Comparing Characteristic Curves of Axial and Centrifugal Compressors.

Variations in Compressor Design

Variable Guide Vane Compressor

Variable guide vanes (VGVs) are used to optimize compressor performance by varying the geometry of the compressor. This changes the compressor characteristic curve and the shape and location of the surge line. In this way the compressor envelope can cover a much wider range of pressure and flow. In centrifugal compressors the variable guide vane (that is, the variable inlet vane) changes the angle of the gas flow into the eye of the first impeller. In the axial compressor up to half of the axial compressor stages may incorporate variable guide vanes. In this way the angle of attack of the gas leaving each rotating stage is optimized for the rotor speed and gas flow.

Variable guide vane technology enables the designers to apply the best design features in the compressor for maximum pressure ratio & flow. By applying VGV techniques the designer can change the compressor characteristics at starting, low-to-intermediate and maximum flow conditions. Thereby maintaining surge margin throughout the operating range. Thus creating the best of all worlds. The compressor map in Figure 3-10 demonstrates how the surge line changes with changes in vane angle.




Figure 3-10. Composite Surge Limit Line Resulting From Variations In Vane Position

Variable guide vanes have an effect on axial and centrifugal compressors similar to speed: the characteristic VGV curves of the axial compressor being steeper than the characteristic VGV curves of the centrifugal compressor. The steeper the characteristic curve the easier it is to control against surge whereas the flatter characteristic curve the easier it is to maintain constant pressure control (or pressure ratio control).

POSITIVE DISPLACEMENT COMPRESSORS

There are many types of positive displacement compressors, but only the three major types will be discussed in this book. These are the blower, reciprocating compressor, and screw compressor. Blowers and screw compressors share some common features and a common history, while reciprocating compressors are noticeably different.

Blowers

The blower is a positive displacement compressor that was invented and patented in 1860 by Philander H. Roots and Francis M. Roots two brothers from Connersville, Indiana. Initially it was intended as a gas pump for use in blast furnaces. The blower design consists of two figure-eight elements or lobes. These lobes are geared to drive in opposite directions (see Figure 3-11).




Figure 3-11. Rotary Blower Lobes Courtesy of Dresser Roots Inc.

Since the rotary lobes need to maintain clearance between each of the lobes a single stage blower can achieve only limited pressure ratio differential—typically 2.0. However, it is capable of compressing large volumes of gas at efficiencies up to 70%. Therefore, blowers are

frequently used as boosters in various compression applications.

A typical two-lobe blower operating sequence is shown in Figure 3-12. Note that the upper rotor or lobe is turning clockwise while the lower lobe is turning counterclockwise.

Position #1: gas enters the lower lobe cavity from the left as compressed gas is being discharged from this cavity to the right and simultaneously gas is being compressed in the upper lobe cavity.

Position #2: the upper lobe cavity is about to discharge it's compressed gas into the discharge line.

Position #3: gas enters the upper lobe cavity from the left as compressed gas is being discharged from this cavity to the right and simultaneously gas is being compressed in the lower lobe cavity.

Position #4: the lower lobe cavity is about to discharge it's compressed gas into the discharge line.

Figure 3-13 shows a cross-section of a two-lobe blower. The blower discharges gas in discrete pulses, similar to the reciprocating compressor (pulsation control is discussed in more detail in the section on reciprocating compressors). These pulses may be transmitted to the downstream equipment or process and must be treated accordingly. For example, if the downstream piece of equipment is a reciprocating compressor, the scrubber and suction pulsation bottle will dampen the pulses from the blower. Some blower designs incorporate pulsation chambers in the body of the blower casing to help minimize pulses.

Blowers are used to boost low pressure gas (at or near atmospheric pressure) to the inlet of larger compressors. The various applications for blowers are listed in Table 3-1.




Figure 3-12. Typical Blower Operating Sequence




Figure 3-13. Roots Blower Courtesy of Dresser-Roots, Inc.

Table 3-1. Blower Applications

Gas Boosting
Landfill Extraction
Digester Gas
Process Vacuum
Gas Recycling
Direct Reduced Iron
Gas Blowing

Blowers are usually belt driven with an electric motor as the driver. Chain driven applications are also used where the driver is close-coupled to the blower as in reciprocating engine/turbocharger applications. An exploded view of a two-lobe blower is shown in Figure 3-14.

Table 3-2 list the general causes of problems encountered in blower operation.




Figure 3-14. Exploded View of the Roots Universal RAI Blower Courtesy of Dresser Roots, Inc.

Most problems can be avoided by first checking that the:

- Driver operates properly before connecting it to the blower;
- Blower turns freely before connecting it to the driver and process piping
- Oil type is correct and
- Oil reservoir is filled to the proper level

Blowers have been developed in both two-lobe and three-lobe configurations. A three-lobe rotor is shown in Figure 3-15.

Reciprocating Compressors

The reciprocating, or piston compressor, is a positive displacement compressor that uses the movement of a piston within a cylinder to move gas from one pressure level to another (higher) pressure level. The simplest example of this is the bicycle pump used to inflate a bicycle tire.

In the bicycle pump example we have the piston attached to a long rod, a pump cylinder (a tube or pipe closed on each end), two ball-type check valves (one inlet and one outlet), a flex hose and a connection de-

Table 3-2. Troubleshooting Chart

TROUBLE	POSSIBLE CAUSE
Will Not Start	Check Driver Uncoupled Impeller Stuck Dirty blower elements
No flow	Wrong rotation Obstruction in inlet or discharge piping
Capacity Low	Speed too low Belt tension too loose Compressor ratio too high Obstruction in inlet or discharge piping Dirty blower elements
Excessive Power Draw (Motor Amp High)	Compressor ratio too high Obstruction in inlet or discharge piping Dirty blower elements
Vibration	Misalignment Impellers unbalanced Impellers contacting Driver or blower casings loose Foundation not level Worn bearings/gears Piping pulsations Dirty blower elements
Bearing/Gear Damage	Coupling/belt misaligned Belt tension excessive
Breather Blow-by Excessive	Broken seals or O-ring Oil level too high Oil type incorrect

vice. The piston is as simple as a leather or rubber disk with two smaller diameter metal disks on either side to give the piston strength and stiffness. The cylinder is the tube that the leather-sandwiched piston moves within. The inlet or suction spring-loaded ball valves allow ambient air to flow into the cylinder as the piston is partially withdrawn from the cylin-



Figure 3-15. Three-lobe Blower Rotor Courtesy of Dresser Roots, Inc.

der (creating a partial vacuum) and closes while the piston compresses the air within the cylinder on the compression stroke; while the discharge ball valve (which is closed on the suction cycle) opens to let the compressed air flow out of the cylinder and into the receiver or tire.

Reciprocating compressors are used in many different industries:

- Oil & gas
 - Oil refineries
 - Gas gathering
 - Gas processing
- Transportation
 - Gas pipelines
- Chemical plants
- Refrigeration plants (large and small)

Reciprocating compressors types include the:

- Single-cylinder compressor
- Multi-cylinder balanced opposed compressor, and the
- Integral-engine compressor.

Single-cylinder Reciprocating Compressor

The single-cylinder reciprocating compressor (Figure 3-16) contains all the elements of any of the reciprocating compressors types.

Major elements of this compressor are the:

- Frame
- Piston
- Cylinder
- Crankshaft
- Connecting Rod
- Crosshead
- Piston Rod

The frame, crankshaft, connecting rod and piston rod define the strength or horsepower capability of the compressor. This overall strength or horsepower capability is combined into one measurement and that is rod load. Rod load is quoted in the English measurement system as pounds and in the metric system as Newtons.



Figure 3-16. Worthington HB GG 24 x 13 Single Stage Compressor before overhaul. Courtesy of Sun Engineering Services, Inc. and Power & Compression Systems Co.

Rod load is the algebraic sum of the inertia forces acting on the compressor frame, crankshaft, connecting rod, crosshead, piston and piston rod and gas loads. Therefore, rod load must take into account inertia forces of the reciprocating components and the gas load calculated at crank angle increments (usually 10 degree increments). Rod loads are defined as combined or overall loads, compression load and tension load.

Compression Rod Load =
$$0.785 \times [D_P^2 \times (P_D - P_S) + D_R^2 \times P_S]$$
 (3-8)

Tension Rod Load =
$$0.785 \times [D_P^2 \times (P_D - P_S) - D_R^2 \times P_S]$$
 (3-9)

Where:

D_P = Piston diameter – inches

 $D_R = Rod diameter - inches$

P_D = Discharge pressure – psia

 P_S = Suction pressure – psia

A change in sign of the combined or overall loads indicates a reversal in the vector loading on the bearing. This is discussed later in the section on bearings.

Frame

The frame or crankcase is generally made from cast iron although in some instances it is fabricated from steel plate. The crankcase forms the base upon which the crankshaft is supported. The crankcase also serves as the oil reservoir.

Crankshaft

The crankshaft, typically made of forged steel, consists of crankpins and bearing journals (Figure 3-17). While small crankshafts have been machined from a single forging, most crankshafts are fabricated from three parts: bearing journals, crankpins and interconnection pieces.

The crankshaft converts rotating motion to reciprocating linear motion via the connecting rod. The crankshaft journal connects to the journal bearing on the crank-end of the connecting rod and the crankpin connects to the journal bearing on the crosshead-end of the connecting rod.

Crosshead

The crosshead (Figure 3-18) rides in the crosshead guide moving linearly in alternate directions with each rotation of the crankshaft. The

Figure 3-17. Superior MH/HW Compressor Crankshaft Made From Either Forged Or Billet Heat Treated SAE 4140 Steel Courtesy of Cooper Cameron Corporation.

piston rod connects the crosshead to the piston. Therefore, with each rotation of the crankshaft the piston moves linearly in alternating directions.

The crosshead sits in the crosshead guide with the crankshaft on one end and the piston rod on the other. The crosshead guide may be



an integral part of the "distance piece" or a separate section. The guide consists of two bearing surfaces: one on top of the guide and one on the bottom. As the crosshead moves back and forth within the guide




Figure 3-18. Crosshead Assembly (Piston Rod Not Shown) Courtesy of ACI Services, Inc.

the piston rod exerts a vertical motion on it. As a result the crosshead is alternately in contact with the bottom bearing surface and the top bearing surface. Care must be taken that piston rod droop is within acceptable limits so as not to result in the crosshead cocking excessively.

Note: See Chapter 12 Case History for the article by Gordon Ruoff on piston rod run-out.

Distance Piece

The distance piece is used to provide sufficient space to facilitate separation of toxic vapors from the oil system and the atmosphere. The "distance piece" mounts to the compressor frame. Besides housing the crosshead guide the distance piece also houses the oil wiper packing (Figure 3-19). The piston rod traverses through the packing as it moves from the head-end to the crank-end thereby acting to seal the process gas in the cylinder from the lubricating environment. Due to the wear created on the piston rod resulting from contact with the packing the piston is often hardened in this contact area. The rod packing is originally assembled when the piston and rod assembly is installed. However, after assembly the sealing rings can be removed and replaced as needed.

Piston Rod

The piston rod is threaded on both ends and may even have a collar on the end that connects to the piston (Figure 3-20). Connecting the piston rod to the piston is an elaborate procedure. The piston must be secured to the rod so that the alternating inertial loading created




Figure 3-19. Rod Packing Assembly Courtesy of Cooper Cameron Corporation



Figure 3-20. Piston, Piston Rod, Rings and Wear Band Courtesy of ACI Services, Inc.

by the accelerating, decelerating and stopping of the piston with each revolution of the crankshaft does not put undue stresses on the rod or the piston ends. This is accomplished by stretching the rod between the crank-end collar and the head-end piston rod nut while simultaneously compressing the piston ends. The sketch below, though grossly out of proportion, illustrates the process (Figure 3-21).

Compressor manufacturers expend considerable amount of engineering and test man-hours to arrive at the proper lubricant and torque




Figure 3-21. Exaggerated Representation of Piston Deformation and Rod Stretch.

to stretch the rod and compress the piston while staying within the elastic limits of the materials of both parts.

The crank-end of the piston rod is threaded into the crosshead and a lock nut is used to guard against the rod backing out of the crosshead. The locknut also functions as a counterweight to compensate for loading on opposite sides of the crankshaft.

Piston

Pistons may be single-acting or double-acting. Single-acting pistons compress the process gas as the pistons moves towards the head-end of the cylinder only (see Figure 3-24). Double-acting pistons compress the process gas as the piston moves in both directions (see Figure 3-23).

Also pistons may be cast from one piece or assembled from several. Although piston balance has not been addressed by most manufacturers there have been cases where piston imbalance has caused rod failure.

Cylinders

There are two types of compressor cylinder designs: "Valves In Bore" and "Valves Out of Bore." The valves in bore design has the compressor valves located radially around the cylinder bore within the length of the cylinder bore. These cylinders have the highest percentage of clearance due to the need for scallop cuts at the head-end and crank-



Figure 3-22. Three Piece Cast Iron Pistons With TFE Riders And Flanged Rods Courtesy of ACI Services, Inc.




Figure 3-23. Piston and Cylinder Assembly Courtesy of Cooper Cameron Corporation




Figure 3-24. Single Acting Piston Operation

end of the cylinder bore to allow entry and discharge for the process gas.

The valves out of bore design consists of compressor valves at each end of the cylinder. While this design provides a lower percent clearance it is more maintenance intense. The unusually large outer head requires a large number of bolts that must be removed for routine service of the piston, wear band and compression rings. Sealing gas pressure on the crank-end is also problematic.

A compressor cylinder houses the piston, suction & discharge valves, cooling water passages (or cooling fins), lubricating oil supply fittings and various unloading devices. Medium to large compressor cylinders also include a cylinder liner.

The volume change during each stroke of the piston is the piston displacement (see Appendix F Compressor Cylinder Displacement Curves. The minimum cylinder volume is the clearance volume. There must be some clearance volume in a cylinder to avoid contact with the head-end or crank-end of the piston. See "Sizing & Selection" at the end of the Reciprocating Compression Section for details on calculating volumetric clearance and brake horsepower.

While a cylinder's capacity is physically fixed, several methods can be employed to reduce capacity and/or pressure differential.

Volume pockets (fixed and variable), volume bottles, suction valve unloaders and speed can be used to vary the compressor throughput. These will be discussed in more detail in the section on controls.

Valves

As discussed in the bicycle pump example, valves are used to control the gas flow into and out of the cylinder. There are suction valves and discharge valves.

The suction valves open at the start of the suction stroke to allow gas to be drawn into the cylinder and close at the start of the compression stroke.

The discharge valves open when sufficient pressure builds up in the cylinder to overcome the combination of valve plate(s) spring load and downstream pressure. At the end of the compression stroke (just prior to the piston reversing direction) the pressure across the valve equalizes and valve plate(s) spring load closes the discharge valve. Valve plate (or poppets) should be smooth and should not bounce as these shorten valve life. Figure 3-25 shows the correct valve operation. Figure




Figure 3-25. Correct Valve Operation Courtesy of Roger Vaglia, Product Manager (Retired), White Superior Compressors 1962-2000


3-26 indicates an incorrect valve operation, in this case resulting from higher than necessary spring force.

Valve designs may employ either plates or poppets and there are many variations on these designs.

The pros and cons in the use of each are dependent on the compression ratio and the gas characteristics. Figures 3-27, 3-28 and 3-29 provide a general overview of the two valve types.

Figure 3-26. Incorrect Valve Operation—Valve Overspringing Courtesy of Roger Vaglia, Product Manager (Retired), White Superior Compressors 1962-2000

Figure 3-27 Compressor Poppet Valve Courtesy of Cooper Cameron Corporation










Figure 3-28 Compressor Plate Valve Courtesy of Cooper Cameron Corporation

Figure 3-29. Poppet Valve Poppets Courtesy of ACI Services, Inc.

Suction valves are installed in the cylinder valve cavity above the cylinder centerline and discharge valves are installed in the cylinder valve cavity below the cylinder centerline.

API Standard 618 "Reciprocating Compressors For Petroleum, Chemical, And Gas Industry Services" stipulates that the suction and discharge valves be designed and manufactured such that they cannot be inadvertently interchanged.

Suction valve unloaders (plug or finger type—see Figures 3-30, through 3-33 and volume pockets Figure 3-34) can be used to regulate compressor throughput. The suction valve unloaders prevent gas pressure from building up in the cylinder thereby reducing that cylinder's output.

A drawback of this approach is that cylinder gas temperature will rise if the same cylinder end is unloaded indefinitely. To prevent this from happening the control system must monitor cylinder gas temperatures and cycle through various cylinder loading configurations (this is addressed in more detail in Chapter 5, Throughput Control).

An alternate approach is the Head-End Bypass offered by ACI Services, Inc. Utilizing SimPlex TM , the configuration the head-end is unloaded by porting the head-end cylinder compressed gas directly back to suction. The DuPlex TM adds a pocket unloader to increase the head-




Figure 3-30. Plug-Type Suction Valve Unloader Courtesy of ACI Services, Inc.

end clearance for a partial reduction in throughput and the head-end unloader for maximum head-end unloading.

An advantage of this approach is that the head-end may be unloaded indefinitely. As with the suction valve unloader approach additional control logic must be incorporated into the compressor controller to activate the unloader.

The plug type unloader (Figure 3-30) uses a plug or piston through the center of the valve. When the plug is retracted gas pressure cannot build up in the cylinder.


The finger type unloader uses a set of "fingers" on each valve plate to hold the valve plates open thus preventing gas pressure build up in the cylinder (see Figure 3-32 and 3-33). There are some drawbacks with each type of unloader:

- The fingers, in the finger-type unloader, are subject to fatigue due to repeated use and could break off and be ingested into the cylinder.
- Liquids and contaminates in the gas could cause the plug in the plug-type unloaded to stick or seize.




Capacity Control Devices






The Innovation Resource for Reciprocating Compressors

Figure 3-31. and Head-end Unloaders Courtesy of ACI Services, Inc.





Volume pockets increase the clearance volume (see the discussion on clearance volume and volumetric efficiency later in this chapter). This is another way to vary compressor throughput. As seen in Figure 3-34 retracting the plug increases the cylinder volume by the amount of the bottle capacity.

The only limitation to the size or number of volume bottles that can be added to a cylinder is the physical space available.

Lubrication

Lubrication is required for the main bearings, the crankshaft bearings, the crankpin bearings, the crosshead pin and the crosshead guide. Lubrication is also required for the piston.

Several methods are available to provide lubrication to the bearings and crosshead:

- Forced-feed method
- Passive gravity-feed method

The forced-feed oil lubrication uses a pump to move the oil through the compressor oil feed passages. A forced feed lube oil system is depicted in Figure 3-35.

The passive gravity method, as shown in Figure 3-36, uses a scoop or oil collector to move oil from the reservoir to a high point in the compressor. From that location the oil flows due to gravity to the bearings throughout the compressor.




Figure 3-34. Volume Bottle Unloader Assembly in the Unloaded Position Courtesy of ACI Services, Inc.




Figure 3-35. Compressor Frame Lubrication Oil System Courtesy of Petroleum Learning Programs, 305 Wells Fargo Dr., Houston, Texas 77090.




Figure 3-36. Oil Scoop can be seen directly below the bearing cap nut. Courtesy of Power & Compression systems

The force-feed lubrication system employs a shaft driven pump as the primary oil pump and an electric motor driven pump as the backup pump. Also included are dual lubrication filters. The force-feed lubrication method is usually employed in higher speed compressors (over 600rpm).

In cooler (or cold) climates a lubrication oil heater is installed in the reservoir. This oil heater is used to heat oil to a temperature at which oil will flow freely. For mineral oil this is approximately 35°F.

A separate lubrication system is employed to lubricate the piston within the cylinder. Since this method adds oil, an incompressible fluid, into the cylinder care must be taken not to add too much oil. Excessive oil supply could accumulate in the cylinder resulting in damage to the rod, piston or cylinder. The manufacturer will normally provide instructions to set the correct amount of oil supplied to the cylinder. Similar information is provided in the charts in Appendix G—Compressor Cylinder Lubrication.

Bearings

Hydrodynamic bearings are used almost exclusively in reciprocating compressors. The older, heavy-duty compressors use the split bear-



Figure 3-37. Connecting Rod and Bearings Courtesy of ACI Services. Inc.

ing design. The newer, lighter compressors use the tilt-pad designs.

Due to the way the oil distribution paths are machined into the bearing holders and supports the crankshaft may only be rotated in one direction to maintain proper oil supply.

Bearing life is affected by the condition and temperature of the lubricating oil, rod load, and rod reversal. The rod load should change from compression to tension and back to compression with each revolution. That is with each revolution the load vector on the bearing must change to allow continuous lubrication to all bearing surfaces. If the load vector does not change the flow of lube oil becomes inadequate eventually leading to bearing failure. Rod reversal is defined as the minimum distance, measured in degrees of crank revolution, between each change in sign of the force in the combined rod-load curve (Figure 3-38).

Rod reversal less than 15 degrees crank angle is cause for concern.

Pulsation Bottles

While strictly speaking pulsations bottles are not an integral part of the reciprocating compressor, they are a necessary part of the reciprocating compressor package. Pulsation bottles are placed at the inlet to the compressor and at the discharge from each compression stage. The pulsation bottle's stated purpose is to dampen pressure waves created by each compression pulse.

The suction pulsation bottle dampens the pressure pulse to the suction piping. Similarly the discharge pulsation bottles dampen the pressure pulses to the discharge piping. These pulses, if transmitted to




Figure 3-38. Red Reversal is the Shortest Distance, in Crank Angle Degrees, from Point to Point.

either the suction piping or discharge piping could be very detrimental to the operation and safety of the compressor.

Suction bottles are mounted on top of the compressor and discharge bottles are mounted beneath the compressor cylinders (Figure 3-39).

Sizing suction and discharge pulsation bottles is a complicated process. Although there are software programs that help with the calculations they should only be used by engineering personnel with experience in the seizing process and the software program. The American Petroleum Institute (API) suggests three design approaches to be followed when seizing pulsation bottles. The basic API guidelines are repeated here for the reader's convenience. However, it is strongly suggested that the entire specification be read and applied.

Reference Paragraph 3.9.2.1

"Design Approach 1: Pulsation control through the use of pulsation suppression devices designed using proprietary and/or empirical techniques to meet pulsation levels required in 3.9.2.5 based on the normal operating condition."

"Design Approach 2: Pulsation control through the use of pulsation suppression devices and proven acoustical simulation techniques in conjunc-



Figure 3-39. Dresser-Rand 7 HOSS-4 Compressors with Suction & Discharge Pulsation Bottles Courtesy of Power & Compression Systems

tion with mechanical analysis of pipe runs and anchoring systems (clamp design and spacing) to achieve control of vibrational response."

"Design Approach 3: The same as Design Approach 2, but also employing a mechanical analysis of the compressor cylinder, compressor manifold, and associated piping systems including interaction between acoustical and mechanical system responses as specified in 3.9.2.6"*

In order to size the suction and discharged bottles accurately detailed, information about the compressor and the suction and discharge piping must be available. This study is referred to as the Harmonic Resonance Analysis. Failure to perform the harmonic resonance analysis could result in pipe vibrations severe enough to rupture the gas piping.

The isometric piping drawing (see Figure 3-40) describes the piping layout, changes in elevation, size and changes in size. This information is critical to the safe design and operation of the compressor package.

^{*}API Standard 618 "Reciprocating Compressors For Petroleum, Chemical, And Gas Industry Services." Latest Edition.




Figure 3-41 is the overhauled and upgraded compressor shown in Figure 3-16. These two pictures demonstrate the longevity and usefulness of compression equipment.

Balanced Opposed Reciprocating Compressor

The balanced opposed reciprocating compressor as shown in Figure 3-42 makes use of multiple cylinders (as well as a crankshaft with multiple crankpin throws, connecting rods, crossheads, pistons and piston rods). Everything that was discussed in the section on single-cylinder compressors applies to the balanced opposed compressor.

The only limiting factor to the number of cylinders installed on a balanced opposed compressor is the load capability of the frame, the ability to maintain main bearing alignment and speed.

Balanced opposed compressors up to 12 cylinders are not unusual. Generally speaking compressors with two to six cylinders operate at speeds up to 1200 rpm. Compressors with eight or more cylinders run at speeds of 300 rpm.





Figure 3-41. Worthington HB GG 24 x 13 Single-stage Compressor after overhaul. Compliments of Sun Engineering Services, Inc., and Power & Compression Systems Co.



1 Cylinder (head-end), 2 Cylinder (crank-end), 3 Piston, 4 Piston Rings, 5 Piston Rod (Induction hardened in packing area), 6 Compressor Packing, 7 Non-reversible, noninter-changeable valves, 8 Valve Retainer, 9 Valve Cap, 10 Crosshead Guide, 11 Crosshead, 12 Replaceable Tri Metal Shoe, 13 Connection Rod, 14 Main Bearing Cap, 15 Crankshaft, 16 Tie Bar, 17 Breather Cap, 18 Top Cover, 19 Oil Filter, 20 Force Feed Lubricator, 21 Crosshead Guide Support, 22 Suction Nozzle Flange, 23 Discharge Nozzle Flange

Figure 3-42. Superior WH-64 Separable Balanced Opposed Reciprocating Compressor Courtesy of Cooper Cameron Corporation

The separable balanced opposed compressor may be driven by a gas engine, electric motor and, in rare cases, a steam turbine or a gas turbine. Whatever driver is selected a torsional analysis should be performed on the entire drive train. Torsional critical speed and response analysis will be addressed in more detail in Chapter 8, Vibration.

Integral Engine-compressor

The integral engine-compressor is not a new innovation, but in fact, an old one. Although specific dates and manufacturers are not available the integral engine-compressor was derived from the steam engine in the late 1800s. In the mid-1800s a compressor cylinder was fitted to a gas engine. The cross-section of a typical integral gas engine-compressor is shown in Figure 3-43. The concept proved successful for a number of reasons:




Figure 3-43. Integral Engine-compressor Cross-section with Power Pistons in the Vertical Plane and Compressor Pistons in the Horizontal Plane, Courtesy of Cooper Cameron Corporation

- Manufacturing technology for crankshafts, connecting rods, pistons and bearings was well developed.
- Both engine and compressor shared the same crankshaft and the same lubricating system.
- The need for a coupling was eliminated.
- The base plate was only slightly wider than the engine-only base plate.
- The engine and compressor cylinders could be shipped separately and the compressor cylinders mounted in the field. Thus reducing shipping width.

Preliminary Selection & Sizing

Compressor selection is dependent on target throughput and specific knowledge of the compressor or compressors to be considered. This

process starts with determining the specific site and design condition.

Site Conditions

Altitude = Sea level (barometric pressure)

Ambient temperature

Design conditions

Gas suction pressure = P_s

Gas suction temperature = T_s

 $Intercooler\ temperature = T_{intercooler} = (target\ 130^{\circ}F\ maximum)$

Gas discharge pressure =P_d

Required flow capacity = MMSCFD (by definition standard cubic feet per day is gas flow at 14.7 psia and 60°F).

Gas Properties

Specific gravity (SpG)
Ratio of specific heats = k = (see Appendix C—
physical properties of gases).

In addition to the calculations discussed in Chapter 2, "General Theory," the following calculations are specific to reciprocating compressors.

Determine the number of compression stages by first dividing the final discharge pressure by the initial suction pressure (all pressures must be absolute).

Overall compression ratio =
$$CR = \frac{P_D}{P_s}$$
 (3-8)

Where

Pd = Discharge pressure (psia)

Ps = Suction pressure (psia)

The potential stages are determined by taking the root (square root, cubed root, etc) of the CR. The stage CR higher than 4.0 should not be considered as this would exceed material strengths of most compressors. In most cases an acceptable CR will be between 1.3 and 3.9. The higher the CR the fewer stages required and the lower the compressor cost.

Next the adiabatic discharge temperature for each stage is calculated using the following:

$$T_d = T_s \times CR_{stage}^{\frac{k-1}{k}}$$
 (3-9)

Where

 $T_{\rm d}$ = Discharge temperature °R $T_{\rm s}$ = Suction temperature °R = Compression ratio per stage k = Specific heat ratio = $C_{\rm p}/C_{\rm v}$

The maximum allowable gas discharge temperature for general service is 350°F. If calculated temperatures exceed this than use more stages. A good rule of thumb is to select approximately the same CRs per stage.

Note: In determining the number of stages the interstage pressure drop is neglected.

Estimating the required HP is the next step in the sizing & selection process. With this information in hand one or more drivers can be considered. The required horsepower for a compressor depends on the net amount of work done on the gas during the complete compression cycle. The following equation may be used to determine the stage HP or the total HP depending upon the stage information selected.

$$\frac{\text{Theoretical HP}}{\text{MMCFD}} = 46.9 \times \frac{k}{k-1} \times \left[\left(CR^{\frac{k-1}{k}} - 1 \right) \right] \times \left[\frac{Z_1 + Z_2}{2 \times Z_1} \right]$$
(3-10)

Where

CR = Compression ratio overall or per stage

Z = Compressibility factor overall or per stage

Multiplying the theoretical HP/MMCFD by the throughput required (MMCFD) provides the total Theoretical HP. Figure 3-44 may be used to approximate HP and temperature rise.

Determining the cylinder size, or sizes for multi-stage compressors, is an iterative process that requires knowledge of the cylinder diameter, stroke and speed. These calculations are easily and accurately performed in the manufacturer's computer sizing program. However, the reader can approximate these calculations by utilizing the nomographs in




Figure 3-44. Estimated Horse Power and Temperature Rise Based on Compression Ratio

Appendix F—Cylinder Displacement Curves. By selecting the cylinder diameter, stroke and compressor speed the cylinder displacement, in thousand cubic feet per day (MCFD), is easily determined.

With this information in hand the reader can approach any compressor and driver manufacturer and determine if they have the type & size of units required.

Clearance Volume: the volume remaining in the compressor cylinder at the end of the discharge stroke. This volume includes the space between the end of the piston and the cylinder head, the volume in the valve ports, the suction valve guards and the discharge valve seats. This volume is expressed as a percent of piston displacement.

Percent Clearance (%Cl) =
$$\frac{\text{Clearance Volume}}{\text{Piston Displacement}}$$
 x 100 (3-11)

Care should be taken that the units used are consistent.

The effect that clearance volume has on volumetric efficiency (Ev) depends on the compression ratio and the characteristics of the gas (that is the "k" value of the gas).

$$\%E_{v} = 100 - CR - \left[\frac{Z_{1}}{Z_{2}} \times CR^{\frac{1}{k}} - 1\right] \times [\%C1]$$
 (3-12)

SCREW COMPRESSORS

One of the earliest, if not the earliest, screw compressors was developed in Germany in 1878 by Heinreich Krigar. The original Krigar rotor configuration resembles the Roots Blower rotor design, which was exhibited in Europe in 1867, with the exception that the Krigar rotors twist through an angle of 180 degrees along the rotor length.

In 1935, Alf Lysholm of Sweden improved the screw compressor with asymmetric 5 female—4 male lobe rotor profile that is still in use today.

The screw compressor is classified as a positive displacement device because a volume of gas becomes trapped in an enclosed space and than that volume is reduced. Within the compressor casing there are two screws with mating profiles, screw "A" and screw "B," with "A" having concave inlets and "B" having convex inlets. These screws rotate in opposite directions with screw "A" receiving power from the outside source and transmitting this power to screw "B" through a set of synchronization gears.

As the screws rotate the process gas is drawn into the inlet or suction port. Gas is compressed by rotary motion of the two intermeshing screws. The gas travels around the outside of the screws starting at the




Figure 3-45. Gas Screw Compressor courtesy of MAN Turbo AG

Controls


top and traveling to the bottom while it is being moved axially from the suction port to the discharge port. The location of the discharge port determines when compression is complete. A slide valve over the discharge ports is used to control or vary the discharge pressure.

The effectiveness of this arrangement is dependent on close fitting clearances between the two screws and sealing the suction and discharge ports. There is no contact between the screws. To improve compressor efficiency oil is injected into the inlet cavity to aid sealing and to provide cooling. Upon discharge the oil is separated from the gas stream to be recycled after filtering and cooling (as necessary). Separation of the oil from the gas can be achieved down to a level of 0.1 parts per million by weight (ppm wt) with a mesh pad and coalescing elements. Borocilicate microfiber material is typically used in coalescing elements. Depending on the application the gas may be further cooled and scrubbed to remove all traces of oil.

The oil-flooded compressor is capable of flowing over 90,000 standard cubic feet per hour (SCFH) at 200 psig. Injected oil quantities are approximately 10-20 gal/min per 100 HP.

Where oil contamination must be avoided compression takes place entirely through the action of the screws. These oil-free compressors usually have lower pressure and throughput capability. Higher throughputs can be achieved by employing multiple screw compressors in series. In this way throughputs of 120,000 SCFH at 150 psig can be achieved.

In reciprocating compressors a small amount of gas (clearance vol-



ume) is left at the end of the stroke. This gas expands on the next suction stroke thereby reducing the amount of suction gas that could have been drawn into the cylinder. At the end of the discharge process of the screw compressor no clearance volume remains as all the compressed gas is pushed out the discharge port. This is significant as it helps the screw compressor achieve much higher compression ratios than reciprocating compressors.

To isolate the screw elements from the bearings, seals are furnished next to the rotor lobe at each end of the machine. Journal bearings are positioned outside the seal area. These are typically hydrodynamic sleeve-type bearings. Tilt-pad thrust bearings are positioned outside of the journal bearings.

Both mineral-based and synthetic oils are used. The oil selected is based on compatibility with the gas being compressed.

Screw Compressor Control

Three of the four control methods used in controlling screw compressors are also used on other compressor types. They are speed control, suction valve throttling and discharge valve throttling. The one control method unique to screw compressors is the slide valve.

Slide Valve

Unloading is achieved by moving the slide valve towards the discharge port (see Figure 3-47). This effectively shortens the working




Figure 3-47. Slide Valve Operation

length of the rotor. Since less gas is compressed the required horsepower is reduced.

This control technique is used with a constant speed drive. Flow variation ranges from 100% to 15% with respective power levels down to 40%.

Variable Speed Drive (VSD)

This control technique varies the speed to match the required throughput. As in other rotating element machines attention must be paid to the critical speed of the individual rotating elements.

Suction Valve Throttling

This control technique is utilized in a constant speed application. This technique controls throughput to the desired set point by modulating gas flow into the inlet. While it is the least expensive control method is has it limitations. The two typical control modes are:

- Full Load: The suction valve is open and the unit is making 100% of its rated flow.
- Part Load: the suction valve is partially closed (or open) and restricting gas flow into the suction port.
- No Load: The unit is still turning but the suction valve is closed and there is no flow. As a result the unit is still consuming energy (15-35% of full load) but not producing any flow.

Discharge Valve Throttling

This type of control system is not recommended and is seldom used. If the discharge is closed the compressor will overheat and casing pressure could exceed safe operating limits.

Figure 3-48 summarizes the various control methods vs. power consumed.

Figure 3-49 demonstrates that screw compressors can be very large.




Figure 3-48. Capacity Control vs. Power





Figure 3-49. Screw Compressor Courtesy of MAN Turbo AG



Chapter 4

Effect of Operating Conditions

GENERAL

A compressor increases the gas pressure from the point "A" level to the point "B" level in the process of moving the gas from point "A" to point "B." This applies to both dynamic and positive displacement type compressors.

However, the gas is acted upon by its surroundings. Gas composition (molecular weight and specific heat), temperature and pres-

EFFECTS OF TEMPERATURE & PRESSURE




Figure 4-1. Effects of Temperature & Pressure

sure influence how a gas behaves. Also effecting compression is the system resistance (the pressure that the compressor must overcome) and the compressor compression ratio (CR). The compressor characteristic curve is a tool in representing how these parameters effect compressor operation. As shown in Figure 4-1 there are different characteristic curves for different pressures and temperatures. This is also true when molecular weight and specific heat are variables. As long as the deviations are small the compressor will be able to adapt to these changes through judicious control techniques.

Considering the effect of gas temperature and pressure from the equation for GHP it is evident that increases in gas inlet temperature, pressure or compression ratio will increase the required GHP necessary to compress the gas. This effect is demonstrated in Figure 4-2.

Also an increase in molecular weight or specific heat ratio will increase the horsepower requirement at constant temperature, pressure and compression ratio as show in Figure 4-3.

DYNAMIC COMPRESSORS

Specific factors that impact the dynamic compressor are surge and the different aspects of surge with varying compression stages.

As design compression ratios are increased the surge line rotates clockwise about the "Zero" point with increasing volumetric flow. (Figures 4-4, 4-5, and 4-6).

Each additional compressor stage changes the shape and location of the surge line thereby generating a composite surge line.

Speed affects axial and centrifugal compressors differently; the characteristic speed curves of the axial compressor being steeper than the characteristic speed curves of the centrifugal compressor. The steeper




Figure 4-2 Compression Ratio Effects on Gas Temperature & BHP/Flow

EFFECTS OF SPECIFIC HEAT RATIO




Figure 4-3. Effect of Specific Heat Ratio on BHP/Flow

the characteristic curve the easier it is to control against surge. Whereas the flatter the characteristic curves the easier it is to maintain constant pressure control (or pressure ratio control).

As inlet conditions change the operating point moves along the system resistance curve (assume that the system resistance curve is constant) as follows (see Figure 4-7):

- The operating point moves up along the system resistance curve to Point B as
 - Ambient pressure increases
 - Ambient temperature decreases, and the
 - Surge line moves to the right and closer to the operating point
- The operating point moves down along the system resistance curve to Point A as




Figure 4-4. Single-Stage Compressor Map




Figure 4-5. Two-Stage Compressor Map

- Ambient pressure decreases
- Ambient temperature increases, and the
- Surge line moves to the left and further away from the operating point.




Figure 4-6. Four-Stage Compressor Map




Figure 4-7. Effects of Changing Inlet Conditions

Whereas molecular weight, gas compressibility, inlet pressure and temperature have a significant impact on controlling compressor operation, their impact can be minimized. This is accomplished by recognizing the similarities in the head and flow relationships.

To demonstrate the equations for head and flow can be simplified by considering head versus flow². In so doing the equations for head and flow² can be reduced as follows:

$$H_{p} = \left(\frac{Z_{ave} * T_{s}}{MW}\right) * \left(\frac{CR^{\sigma} - 1}{\sigma}\right)$$
(4-1)

$$Q^{2} = \left(\frac{Z_{s} * T_{s}}{MW}\right) * \left(\frac{\Delta P_{os}}{P_{s}}\right)$$
(4-2)

$$\left(\frac{Z_s * T_s}{MW}\right) \approx \left(\frac{Z_{ave} * T_s}{MW}\right) \tag{4-3}$$

$$H_{p'} \approx \left(\frac{CR^{\sigma} - 1}{\sigma}\right)$$
 (4-4)

$$Q^{2'} \approx \left(\frac{\Delta P_{os}}{P_s}\right) \tag{4-5}$$

Where

 $H_p = Polytropic head—feet$

 Z_{ave} = Compressibility factor—average

 Z_s = Compressibility factor—suction conditions

 $T_s = Suction temperature - {}^{0}R$

CR ≡ Compression ratio

 $\sigma = \frac{k-1}{k^* \eta_p}$ Ratio of specific heats and $\eta_p = \text{polytropic efficiency}$

 ΔP_{os} = Differential pressure across flow orifice in suction line

 P_s = Suction pressure—psia

The reduced coordinates define a performance map which does not vary with varying inlet conditions; has one surge limit point for a given rotational speed and compressor geometry and permits or facilitates




Figure 4-8. Simplified Compressor Map Using Pressures Only

calculation of the operating point without obtaining molecular weight and compressibility measurements.

For a given rotational speed and compressor geometry, the operating point can be defined by a line from the origin to the operating point. This line can be defined by its slope = Hp/Q_s^2 . Each coordinate can be reduced by a common factor without changing the slope.

Thus the operating point can be precisely defined by: $(H_p/A)/(Q_s^2/A)$ or Hp'/Q_s^2

CENTRIFUGAL COMPRESSOR SAFETY LIMITS

- A. Performance limits (usually overspeed) are not uncommon.
- B. Surge is a serious threat to all dynamic compressors. Virtually every compressor is outfitted with some sort of antisurge protection (bleed valves, VGVs). The consequences are too severe to ignore.
 - 1. If the surge limit is crossed, there will be severe high speed oscillations accompanied by vibration and rising gas temperatures
 - 2. Surge is a high speed phenomenon—the drop from full flow to

- reverse flow can occur in 0.04 seconds.
- 3. In addition to the surge limit several other performance limits (pressure, speed, load, choke) have to be observed as well.
- 4. Usually choke will not be a problem.

POSITIVE DISPLACEMENT COMPRESSORS

With positive displacement compressors variations in gas composition (molecular weight, specific heat ratio, compressibility), gas pressure and gas temperature are less critical than they are in dynamic compressors. While small changes have a minimal effect on compressor operation, large changes could exceed the available driver power, fail to meet the required throughput or fail to achieve the required discharge pressure. In such a case the compressor could continue to operate at reduced throughput and power. However, failure to achieve the required discharge pressure would shutdown the operation.

Reciprocating compressors are designed to operate across a range of pressures or system resistances. As shown in Figure 4-9 the characteristic curve between the high and low system resistance lines is almost a straight vertical line. At very high differential pressures flow starts to decrease. Operation in this range usually results in failure (seals, piston rods, bearings).

One of the major causes of failure in reciprocating compressors is liquids or hydrates in the gas. Only very small amounts of liquid can be expelled through the discharge valve. However, prolonged operation even with a small amount of liquid will lead to valve failure. If the volume of the liquid exceeds the clearance volume either the rod will bend or the piston will fail. Therefore, it is imperative that the gas entering the compressor is dry and free from liquids or hydrates.

RECIPROCATING COMPRESSOR SAFETY LIMITS

- A. Maximum speed of the driver or the compressor.
- B. Performance limits—pressure, temperature, gas composition (molecular weight, specific heat ratio) have to be observed as well.
- C. Liquids and hydrates in the gas must be avoided





Figure 4-9. Reciprocating Compressor Characteristic Curve



Chapter 5

Throughput Control

Throughput control (capacity control or process control) is achieved by controlling the energy input to the compressor in order to reach the control objective (process set point). For all compressor types this is accomplished by using speed control, suction throttling, discharge throttling or recycle control. In addition to the above, for dynamic compressors, throughput control can be achieved by using guide vane position where applicable. Throughput control for reciprocating compressors can be achieved by using fixed or variable volume pockets and suction valve unloaders. And for screw compressors throughput control is achieved by using a slide valve. A discussion of each of these control methods follows.

SPEED CONTROL

Increasing speed moves the characteristic curve to the right (see Figure 5-1) resulting in increasing flow at a constant pressure or increasing pressure at constant flow. Speed control is the most efficient control method and it can be combined with other control methods for control fine-tuning.

SUCTION VALVE THROTTLING

This control method restricts the gas flow and pressure into the compressor inlet. Suction valve throttling is accomplished by installing a control valve (either linear or equal percentage see Chapter 9) immediately upstream of the compressor and controlling the valve's position as a function of either discharge pressure or flow. As shown in Figure 5-2 suction valve throttling moves the characteristic curve to the left.




Figure 5-1. Speed Control




Figure 5-2. Suction Valve Throttling Control

DISCHARGE VALVE THROTTLING

This control method restricts the pressure from the compressor to match the required process pressure at constant flow (Figure 5-3). Because the compressor is working harder than the process requires this control scheme is extremely inefficient. As a result this control technique is rarely used.

VARIABLE GUIDE VANE CONTROL

Variable guide vane (VGV) control applies to dynamic compressor types only. By opening the VGVs the surge point and the characteristic

DISCHARGE THROTTLING CONTROL




Figure 5-3. Discharge Valve Throttling Control

VGV CONTROL




Figure 5-4. Variable Guide Vane Control

curve move to the right. In effect this creates the largest turndown of all the control methods. It also increases the surge margin as the VGV's close. While this control method is more efficient than suction valve throttling it is also more expensive. Not only is the first cost higher for a compressor with VGVs, but also the maintenance cost is higher.

RECYCLE VALVE CONTROL

The recycle valve returns compressor discharge flow back to suction (Figure 5-5). To optimize recycle valve operation a gas cooler is usually installed in the recycle line. In this way the hot discharge gas does not increase the temperature of the suction gas into the compressor. The recycle valve may be modulated from full open to full closed position to provide a 100% range of control. Also a recycle valve may be used with suction valve unloaders to smooth the loading/unloading steps.

SUCTION VALVE UNLOADERS

Suction valve unloaders apply to reciprocating compressors only. Suction valve unloaders prevent gas pressure from building up in each cylinder end. It accomplishes this by holding the valve plates open (finger type unloader) or retracting a plug (plug type unloader) from the center of the valve (suction valve unloaders are discussed in detail in Chapter 3). Suction valve unloaders can be activated to unload one cylinder end at a time or combinations of head-ends and crank-ends as a function of the total throughput required and gas temperature. On some compressor models the gas cycling in and out of the unloaded

RECYCLE CONTROL




Figure 5-5. Recycle Valve Control

cylinder end can overheat. To address this issue a valve sequence must be created to switch unloaded ends in order to maintain acceptable gas temperatures. Considering a four cylinder single stage balanced opposed separable compressor, each of the eight ends (four head-ends and four crank ends) can be sequenced as demonstrated in Chart 5-1. Ends may be switched, not only to achieve the required throughput, but also to maintain gas temperature.

For example, the four-cylinder single-stage balanced opposed separable compressor in Figure 5-6 is used as a fuel gas booster compressor in parallel with a centrifugal compressor to supply fuel gas to a gas turbine at constant pressure and varying throughput. To meet the gas turbine flow requirements suction valve unloaders where installed on all head-end and crank-end suction valves. These valves are sequenced as shown in Chart 5-1. To achieve smooth flow and pressure transition between each load/unload step the dedicated control program also modulated the recycle valve with each step.

Figure 5-7 shows the interaction of flow, horsepower and suction pressure at each unloading step with changes in suction pressure. At 30 MMSCFD and 190 psig the compressor can operate with 4 ends unloaded and the recycle valve slightly open.




Figure 5-6. Four-cylinder Single-stage Balanced Opposed Separable Compressor

Chart 5-1. Compressor Loader/Unloader Sequence

		Specific Ends To Be Loaded							
	Sequence -	Specific Ends 10 Be Loaded							
NI. E. 1.	within	111	21.1	3H	41.1	1.0	200	20	10
No Ends		1H	2H	3H	4H	1C	2C	3C	4C
Loaded	Each Step	0	0	0	0	0	0	0	0
0	N/A	0	0	0	0	0	0	0	0
1	a	X	0	0	0	0	0	0	0
1	b	0	X	0	0	0	0	0	0
	c	0	0	X	0	0	0	0	0
	d	0	0	0	X	0	0	Ő	0
	e	0	0	0	0	X	0	0	0
	f	0	0	0	0	0	X	0	0
	g	0	0	0	0	0	0	X	0
	ĥ	0	0	0	0	0	0	0	X
							0		
2	a	X	X	0	0	0	0	0	0
	b	0	0	X	X	0	0	0	0
	c d	0	0	0	0	X	X 0	0 X	0 X
	а	U	U	U	U	U	U	λ	λ
3	a	X	Х	X	0	0	0	0	0
	b	0	0	0	X	X	X	0	0
	С	X	0	0	0	0	0	X	X
	d	0	X	X	X	0	0	0	0
	e	0	0	0	0	X	X	X	0
	f	X	X	0	0	0	0	0	X
	g h	0	0	X	X	X	0	0	0
	h	0	0	0	0	0	X	X	X
4	a	X	X	X	X	0	0	0	0
-	b	0	0	0	0	X	X	X	X
		Ü	Ü	Ü	· ·		,,	,,	7.
5	a	X	X	X	X	X	0	0	0
	b	X	X	0	0	0	X	X	X
	С	0	0	X	X	X	X	X	0
	d	X	X	X	X	0	0	0	X
	e	X	0	0	0	X	X	X	X
	f	0	X	X	X	X	X	0	0
	g h	X 0	X 0	X 0	0 X	0 X	0 X	X X	X
	n	U	U	U	λ	λ	λ	λ	X
6	a	X	X	X	X	X	X	0	0
	b	X	X	X	X	0	0	X	X
	c	X	X	0	0	X	X	X	X
	d	0	0	X	X	X	X	X	X
7	a	X	X	X	X	X	X	X	0
	b	X	X	X	X	X	X	0	X
	C	X	X	X	X	X	0	X	X
	d	X X	X	X	X	0	X	X	X X
	e f	X	X X	X 0	0 X	X	X X	X X	X
		X	0	X	X	X	X	X	X
	g h	0	X	X	X	X	X	X	X
	11	Ü	,,	,,	,,	,,	,,	,,	,,
8	a	X	X	X	X	X	X	X	X

Each step is to be sequenced as a function of TIME and GAS TEMPERATURE at the compressor end selected.




Figure 5-7. Variation in Flow & Horse Power as a Function of Suction Pressure

VARIABLE OR FIXED VOLUME POCKETS

Variable and fixed volume pocket control applies to reciprocating compressors only. Volume pockets vary throughput and efficiency by adding clearance to the piston area. Volume pockets can be either fixed or variable (manual or automatic).

Volume pockets are most easily added to the head-end of the compressor cylinder. While volume pockets could be added to the crank-end the amount of space is often limited. The p-v plot in Figure 5-8 demonstrates how the operation of the volume pockets effects volume and throughput.

AFFECT OF OPENING VARIABLE VOLUME POCKET




Figure 5-8. Affect of Opening/Closing The Head-End Variable Volume Pocket

Chapter 6

Centrifugal/Axial Compressors Description of Surge

SURGE & STALL

Surge is an operating instability that can occur in dynamic (axial and centrifugal) compressors and blowers (but not in other positive displacement compressors).

Surge and **stall** are often considered to be one and the same. In fact stall is a precursor to surge. As the compressor operating point approaches the surge line a point is reached where flow starts to become unstable.

The stall phenomena occurs at certain conditions of airflow, pressure ratio, and speed, which result in the individual compressor airfoils going into stall similar to that experienced by an airplane wing at a high




Figure 6-1. Rotating Stall

angle of attack. The stall margin is the area between the steady state operating point and the compressor stall line.

As each blade row approaches its stall limit, it does not stall instantly or completely, but rather stalled cells are formed (Figure 6-1). In axial compressors these stall cells can extend from a few blades up to 180° around the annulus of the compressor. Also these cells tend to rotate around the flow annulus at about half the rotor speed while the average flow across each stage remains positive. Operation in this region is relatively short and usually progresses into complete stall. Rotating stall can excite the natural frequency of the blades.

Stall often leads to more severe instability—this is called surge. When a compressor surges flow reversal occurs in as little as 50 milliseconds and the cycle can repeat at a rate of 1/2 to 2 hertz (cycles per second). Although complete flow reversal may not occur in every surge cycle, the fact that flow does reverse has been documented in numerous tests. The most impressive, of which, is when the axial compressor on a jet engine goes into surge (see Figure 6-2). From the point of view of passengers on board the only evidence of surge is the repeated, loud "popping" sound that accompanies surge (unless seated by a window, forward of the engines, and looking directly out at the engine inlet).

In industrial applications flow reversal is observed as fluctuations



Figure 6-2. Jet Engine Axial Compressor Surge

in measured flow simultaneous with an increase in vibrations. If close to a surging compressor a "whooshing" sound may also be heard.

Surge can cause the rotor to load and unload the active and passive sides of the thrust bearings in rapid succession. When severe the rotor may contact the stators resulting in physical damage.

The compressor map is the single most useful tool for describing surge. The compressor map shows the characteristic curves and the locus of points defining the surge line. The "X" axis is volumetric flow and the "Y" axis may be discharge pressure (Pd), differential pressure (ΔP) or compressor pressure ratio (CR or Rc).

In general, surge can be defined by the symptoms detailed in Table 6-1.

Surge happens so quickly that conventional instruments and human operators may fail to recognize it. This is especially true if the vibration does not trigger the vibration alarm setting. In cases where there was not an "observed incident," the evidence of a surge may be verified by a loss in compressor efficiency.

In industrial compressor applications the severity of surge is de-




Figure 6-3. Compressor Map

pendent on the volume of the downstream equipment including process vessels, piping, etc. The larger this volume, the greater the damage caused by surge, should it occur. Some factors leading to the unset of surge are listed in Table 6-2.

Table 6-1. Surge Description

- 1 Flow reverses in 20 to 50 milliseconds
- 2 Flow reverses at a rate if ½ to 2 Hertz
- 3 Compressor vibration (mostly axial but vertical & horizontal may also be affected)
- 4 Gas temperature rises
- 5 Surge is accompanied with a "popping" or "whooshing sound
- 6 Trips or shutdowns may occur

Table 6-2. Factors Leading to Surge						
FACTORS LEADING TO SURGE						
At Full Operation	Trips					
•	Power Loss					
	Jammed Valves (VGVs)					
	Process Upsets					
	Molecular Weight Changes					
	Intercooler Failure					
	Rapid Load Changes					
	Compressor Fouling					
	Dirty Compressor					
At Reduced Operation	Start/Stop Cycles					
•	Load Changes					

Some of the consequences of surge are listed below:

- Unstable flow and pressure
- Damage to seals, bearings, impellers, stators and shaft
- Changes in clearance
- Reduction in compressor throughput
- Reduction in efficiency
- Shortened compressor life

Chapter 7

Surge Control Centrifugal/Axial Compressors

In Chapter 5 throughput control was discussed as it applied to all compressors—dynamic and positive displacement. In this chapter, control will be discussed, as it applies to dynamic compressors only. Specifically this means controlling the dynamic compressor to avoid operating at or near surge. To accomplish this several control techniques will be employed. They are: a) minimum flow control; b) maximum pressure control; c) dual variable control; and d) ratio control.

Before proceeding it is necessary to determine where the compressor is operating relative to the surge region. For a given set of constraints (such as, compressor geometry, available control mechanisms and the process), the compressor operating location can be defined by a line from the origin to the compressor operating point (as was discussed in Chapter 4—Dynamic Compressors).

MINIMUM FLOW CONTROL

Minimum flow control is possibly the simplest and least expensive control method. As indicated in Figure 7-1, the surge margin is normally tuned to prevent surge at high pressures. But when the compressor operates at lower pressure levels, the surge margin is needlessly increased. This is a very inefficient way to control against surge.

MAXIMUM PRESSURE CONTROL

Maximum pressure control is a simple and inexpensive (flow measurement instrumentation is not required) control technique most frequently found in constant speed compressors. This control method is not very efficient and offers only, about, a 10% turndown. As Figure 7-2




Figure 7-1. Minimum Flow Control

shows, the maximum controller set point does not protect against the operating point crossing into surge at low pressures. And if the operating point goes above the controller set point the recycle valve will open even though the operating point may be far to the right of the actual surge region.

DUAL VARIABLE CONTROL

Dual variable control (Figure 7-3) is employed to control one primary variable while at the same time constraining one or more separate variables. For example, a process may require that the compressor maintain a constant discharge pressure, but at the same time ensure that other parameters (such as maximum motor current, minimum suction pressure or temperature) not be exceeded. Exceeding any of these limits




Figure 7-2. Maximum Pressure Control

could result in serious damage to the compressor, damage to the driver or damage to the process equipment (upstream or downstream).

Both flow control and pressure control techniques leave the compressor vulnerable to surge as discussed above. A more realistic control approach would be to establish a control line (or surge limit line) that mimics the actual surge line and is set up at a reasonable distance (margin) from the actual surge line. This is the approach that has proven most successful in situations where the above control methods are inadequate. This method is referred to as ratio control.

Ratio Control

Recall the equations for polytropic head and flow squared from Chapter 4 (equation 4-1 & 4-2). The same relationships are rewritten below in equation 7-1.

$$H_{p} = \frac{Z_{ave} \bullet T_{s}}{MW} \bullet \frac{R_{c}^{\sigma} - 1}{\sigma} \text{ and } Q = \sqrt{\|\left(\frac{Z_{s} \bullet T_{s}}{MW}\right) \bullet \left(\frac{\Delta P_{os}}{P_{s}}\right)\|}$$
 (7-1)




Figure 7-3. Dual Variable Control

Using the format from Figure 7-4, the surge line is renamed the surge limit line (SLL) and the surge limit set point is renamed the surge control line (SCL). To enhance the ability to control against surge over a wide range of conditions additional control ratio limits are added. These are shown in Figure 7-5 Surge Control Map, and listed in Chart 7-1.

The surge control map in Figure 7-5 shows the relationship between the actual surge line, the operating point and various control lines developed to control the compressor throughout its operating range.

These lines are defined as follows:

Using the definitions in Chart 7-1, the operating point can be defined by the slope of the line from the origin to the operating point. This is referred to as the operating point line or OPL.

Slope of the operating point line = OPL =
$$\frac{H_p}{Q_s^2} = \frac{H_{p1,red}}{q_{s1,red}}$$
 (7-2)




Figure 7-4. Ratio Control




Figure 7-5. Surge Control Map

	Chart 7-1. Surge Control Factors
SSL	Slope of the Surge Stop Line
SLL	Slope of the Surge Limit Line
SAL	Slope of the Surge Avoidance Line
SCL	Slope of the Surge Control Line
OPL	Slope of the Operating Point Line @ Design Conditions
b or b_1	Distance Between SCL and SLL
SA	Distance Between SCL and SAL
SS	Distance Between SSL and SLL
d	Distance Between Operating Point and SLL
d_{SA}	Distance Between Operating Point and SAL
T_d	Derivative Action Time Constant
T_{SA}	Time Interval Between Step Outputs
DEV	Distance from Operating Point to SCL

Similarly the surge limit line can be defined by the slope of the surge limit line and is based on the slope of the surge line. The surge limit line is defined as follows:

Slope of the surge limit line =
$$SLL = \frac{H_p}{Q_s^2} = \frac{H_{p1,red}}{q_{s1,red}}$$
 (7-3)

Furthermore, using the ratio of the two slopes, OPL and SLL a new term is defined which is based of the relationship between these slopes. This term is $G_{\rm s}$.

Then
$$G_s = \frac{OPL}{SLL}$$
 (7-4)

And the distance between the operating point and the surge limit point is defined as "d" where

$$d = 1 - G_s \tag{7-5}$$

When the slopes of the SLL and the OPL are equal, $G_s = 1$ and d = 0. which is as it should be since the distance between the lines is 0.

Also Deviation is defined as the distance from the operating point to the surge control line (SCL). Therefore,

$$DEV = d - b \cdot f \left(\Delta P_{os} \right) \tag{7-6}$$

where $f(\Delta P_{o,s})$ = function characterizing the shape of the SCL and b is the margin of safety.

$$f(\Delta P_{o,s})$$
 may be either $\frac{1}{\Delta P_{o,s}}$ or 1. (7-7)

If $f(\Delta P_{o,s}) = \frac{1}{\Delta P_{o,s}}$ then the SCL is parallel to the SLL and b is the distance between them.

If $f(\Delta P_{o,s}) = 1$ then SCL & SLL intercept at 0 and

$$b = 1 - \frac{SCL}{SLL} \tag{7-8}$$

Using the 0 intercept approach for all control lines the distance between surge control line (SCL) and the surge avoidance line (SAL) is represented by

SA output =
$$C_1 \left(C_o \cdot d_{SA} + T_d \cdot \frac{G_s}{dt} \right)$$
 (7-9)

and $b = b_1 + nb_2$ where *n* is the number of surge cycles.

The above control techniques can now be used to implement algorithms that will avoid a surge and stop surge, should it occur. The surge avoidance algorithm and the stop surge algorithm are described below.

SURGE AVOIDANCE ALGORITHM

The distance from the operating point line to the surge avoidance line is defined by d_{SA}

Where
$$d_{SA} = G_S + b_1 + nb_2 - SA - 1,$$
 (7-10)

and
$$SA = \frac{SAL - SCL}{SLL}$$
 (7-11)

When the operating point (i.e. OPL) is to the right of the SAL, d_{SA} will be <0. Only when d_{SA} goes positive is the step output to the bypass valve implemented. Also the step output is repeated in T_{SA} time intervals until the bypass valve is full open. Do not use the derivative if the signal is noisy.

SURGE STOP ALGORITHM

SS is the surge stop line distance and is defined as

$$SS = \frac{OPL}{SLL} - 1 \tag{7-12}$$

When the OPL is to the right of the SSL, SS is < 0 and no action is taken. When the OPL is to the left of the SSL, then SS > 0 and the n value for the number if surge cycles is increased a set amount (n=1, n=2, n=3, etc each time the operating point crosses the surge stop line.

An example in the use of the above surge control technique follows:

CALCULATE THE SURGE LINE SLOPE

Using the following relationship:

$$\Delta P_{os} = \frac{[1 - (d/D)^4]}{N^2 C^2 d^4 Y^2} \rho \times q^2$$
(7-13)

where d=6.373 and d=Fa d_{meas} and D=10.02 and $D=FaD_{meas'}$ and Fa is the Thermal Expansion Factor.

$$Fa = 1 @ 70^{\circ}F$$
 (7-14)

Based on a compressor map the surge point is at the following conditions:

q = 1220 acfm, flow in actual cubic feet per minute

Discharge Pressure (Pd) = 338 psia

Suction Pressure (Ps) = 118.7 psia

Also gas parameters are as follows:

Molecular Weight (MW) = 17.811

Specific Heat Ratio (k) = 1.286

Compressibility Factor (Z) = 0.98

Suction Temperature (Ts) = $70^{\circ}F = 530^{\circ}R$

Therefore, density (
$$\rho$$
) = $\frac{MW \cdot P_s}{Z \cdot R_s T_s}$ = 0.37929 (7-15)

and

Velocity of Approach Factor (E) =

(E) =
$$\frac{1}{\sqrt{1-(d/D)^4}}$$
, where $\beta = d/D \equiv$ the beta ratio. (7-16)

Rearranging and squaring the above term

$$1/E^2 = [1-\beta^4] = 0.83635 \tag{7-17}$$

Gas Volumetric Flow Factor (N) = 5.982114 from Table $9.16 pp 9.35^*$ when flow is measured in acfm.

Discharge Coefficient (C) =
$$C_{\infty} + b/R_D^n$$
 (7-18)

and C_{∞} is the discharge coefficient at the infinite Reynolds Number (table 9/1 pp 9.141*).

$$C_{\infty} = 0.5959 + 0.0312(\beta)^{2.1} - 0.184(\beta)^{8} + \frac{0.09(\beta)^{4}}{D[1 - (\beta)^{4}]} - \frac{0.0337(\beta)^{3}}{D} = 0.57874$$
(7-19)

b =
$$91.70(\beta)^{2.5}$$
 = 29.58420 and n=0.75
and from Table 9.20 equation $i pp 9.39^*$ (7-20)

$$R_D = \left[2266.970 \frac{\rho}{\mu DN}\right] \, q \text{ and } \mu = 0.0106 \ @ 1 \text{ atmosphere and } 70^\circ F \eqno(7-21)$$

from Crane Handbook.

Specific Gravity (SG) =
$$\frac{MW_{gas}}{MW_{air}} = \frac{17.811}{28.966} = 0.61489$$
 (7-22)

From GPSA curves reprinted in Appendix C the critical temperature and pressure of the gas is Tc=362.5°F and Pc=675psia

$$Tr = \frac{70 + 460}{362.5} = 1.46207 \tag{7-23}$$

$$Pr = \frac{118.7}{675} = 0.17585 \tag{7-24}$$

Then
$$\mu = 1.0176 \cdot 0.0106 = 0.0108$$
 (7-25)

$$R_{D} = 1,620,432.1 \tag{7-26}$$

$$C = 0.57939$$
 (7-27)

Gas Expansion Factor (Y) =

$$Y = 1 - [0.41 + 0.35(\beta)^4] \cdot \frac{X_i}{k}$$
 from Table 9.26 pp 9.48* (7-28)

Where Xi =
$$\frac{P_1 - P_2}{P_1}$$
 from eq 9.35, and k = $\frac{c_p}{c_v}$

$$= 1.2863$$
 (iterate as necessary) (7-29)

^{*}Values are found in Flow Measurement Engineering Handbook, 3rd Edition, by Richard Miller

Assume surge point at 25 inches of water column then $\frac{\Delta P_{os}}{P_s}$ = 0.919/118.7 = 0.00774 (7-30)

$$Y = 0.99722 (7-31)$$

$$\Delta P_{os} = \frac{\left[1 - (d/D)^4\right]}{N^2 C^2 d^4 Y^2} \rho \times q^2 = 23.95920 \approx 24 \text{ inches}$$

water column at surge point. (7-32)

and
$$q = \sqrt{\frac{\Delta P_{os}}{1.61 \cdot 10^{-5}}}$$
 (7-33)

Calculate the surge limit line (SLL)

Where
$$\sigma = \frac{k-1}{k}$$
 and $k = \frac{c_p}{c_v}$. Then $\sigma = 0.0.22258$ (7-34)


$$SLL = \frac{\left[\left(\frac{P_d}{P_s} \right)^{\sigma} - 1 \right]}{\Delta P_{os} / P_s} = 5.837 \approx 5.8$$
 (7-35)

Similarly the Surge Control Line (SCL) =
$$4.4$$
 (7-36)
Surge Avoidance Line (SAL) = 4.8 (7-37)

Stop Surge Line (SSL)
$$= 5.9$$
 (7-38)

And "b" the distance between the SLL and the SCL =

$$1 - \frac{SCL}{SLL} = 0.24386 \quad 0.24 \tag{7-39}$$




Chapter 8

Vibration

Every piece of equipment, regardless of size or configuration, has a natural or resonant frequency. Compressors are no exception and, in fact, numerous vibration analysis techniques are employed to predict compressor vibration during the design phase and to identify the source of high vibration in the operation phase. If the resonant frequency (critical speed) is below the operating frequency or speed, the unit is considered to have a flexible shaft. If the resonant frequency is above the operating speed, the unit is said to have a stiff shaft (see Figure 8-1). Almost all axial compressors are considered to have a flexible shaft; that is, the

ROTOR RESPONSE CURVE



ROTOR SPEED RATIO

Figure 8-1. Rotor Response Curve Depicting Operation from Critically Damped to Critically Undamped

normal operating speed is above the resonant (or undamped critical speed) frequency. The resonant frequency of centrifugal compressors falls on either side of the undamped critical speed line depending on the number of impellers involved and the shaft size. Blowers, integral-engine-reciprocating compressors and screw compressors generally fall into the stiff shaft category. Separable reciprocating compressors trains (driver & compressor) may fall into either flexible or stiff shaft category depending on the number of cylinders and the type of driver selected. Vibration is a major consideration in the design of compressor rotor assemblies.

Rotor designs vary widely among compressor types and, if fact, they vary even between compressors of similar frame size. Physical factors such as number, size, arrangement of impellers or pistons, and bearing spans, bearing housing design, torque requirements, coupling selection and system parameters such as volume flow, casing pressure rating, operating speed ranges all affect the natural frequency and therefore rotor design.

Each element of the drive system, as well as the complete drive system and all mechanically connected elements, must be subjected to detailed vibration analyses. Regardless of the complexity of the rotor system both lateral and torsional vibration analysis should be addressed. Furthermore, each compressor rotor and support system must be subjected to a thorough dynamic rotor stability analysis. There are a number of excellent companies, large and small, that have the capability to perform the necessary lateral and torsional analysis.

Dynamic rotor stability analysis looks for possible causes of fractional frequency whirl or non-synchronous precession such as a large vibration amplitude component at or near the first lateral bending mode that can lead to excessive rotor vibration. When encountered this vibration can reach magnitudes large enough to move the compressor on its foundation and even destroy the compressor.

Figure 8-2 is a representation of hydrodynamic bearing whirl orbits. Using this technique the rotating shaft journal may be observed as it and the oil wedge moves within the bearing.

The American Petroleum Institute Standard 618 recommends that torsional natural frequencies of the driver-compressor system (including couplings and any gear unit) shall be avoided within 10 percent of any operating shaft speed and within 5 percent of any other multiple of operating shaft speed in the rotating system up to and including the tenth

Vibration 99




Figure 8-2. Hydrodynamic Bearing Whirl Orbits

multiple. For motor-driven compressors, torsional natural frequencies shall be separated from the first and second multiples of the electrical power frequency by the same separation margins.*

The compressor rotor system (as shown in Figure 8-3 and 8-4), consisting of shaft, impellers, balance drum, etc., together with its support system (that is, bearing type, casing, supports, etc.), is subjected to analysis of its natural lateral frequency response during the design stage. The operating speed range is the most critical element in this analysis. Therefore the speed range should be limited to the predicted operating points without a large safety margin.

Identifying the lateral natural frequencies can be a slow process due to the large number of factors to be considered. Experience is a major asset in this process. For example, a centrifugal barrel compressor usually operates between the first and second lateral bending modes.

^{*}API Standard 618, 4th Edition June 1995 "Reciprocating Compressors for Petroleum, Chemical, and Gas Industry Services," Section 2.5.2

When frequency changes are necessary they can be made by modifying the compressor configuration or stiffening the rotor shaft. Frequency is directly proportional to the square root of the element spring constant and inversely proportional to the square root of its mass as shown in equation 8-1.

$$\omega^2 = -\frac{K}{m} \tag{8-1}$$

Where

 ω = natural circular frequency in radians per second,

 $k = spring \ constant \ or \ spring \ modulus \ or \ elastic \ modulus \ in \\ lb/in, \ and$

 $m = mass in lb sec^2/in$

Vibration measurements usually consist of amplitude (inches), velocity (inches per second) and acceleration (inches per second per second or "g"). These measurements are taken with probes, such as seismic probes that measure amplitude, proximity probes that measure velocity, and acceleration probes or accelerometers that measure acceleration (see Figure 8-4). By the use of integrating or differentiating circuits, ampli-





Figure 8-3. Centrifugal Compressor Cross-section Compliments of Dresser Roots, Inc.

Vibration 101



THREE DISK TORSIONAL SYSTEM

Figure 8-4. Simplified Rotor Shaft System

tude, velocity or acceleration readouts are possible from any of the three probe types. However, more accurate information can be obtained from direct measurements using the proximity probe and accelerometer.

Typical sources of vibration that are usually found in a compressor package are detailed in Table 8-1.

VIBRATION	TYPE	OBSERVATION
0.42 x ROTOR SPEED RADIC	OIL WHIRL	VIOLENT BUT SPO-
0.5 x ROTOR SPEED	BASEPLATE RESONANCE	VERTICAL MORE SENSITIVE
1 x ROTOR SPEED	ROTOR IMBALANCE	
2 x ROTOR SPEED	MISALIGNMENT	AXIAL HIGH
2 x ROTOR SPEED	LOOSENESS	AXIAL LOW
RPM x GEAR TEETH	GEAR NOISE	

Table 8-1. Typical Sources of Vibration

Note that rotor imbalance is seen predominantly at the running speed, whereas misalignment can be seen at two times the running speed and is seen on readouts from both the horizontal or vertical probe and the axial probe. Looseness due to excessive clearances in the bear-

ing or bearing support is also seen at two time's running speed, except the axial probe does not show any excursions. Hydrodynamic journal bearing oil whirl is seen at 0.42 running speed and is both violent and sporadic. Very close to that, at 0.5 running speed, is baseplate resonance. Note that baseplate resonance is picked up predominantly on the vertical probe. Gear noise is seen at running speed times the number of gear teeth. Amplitude is not the best criteria to judge acceptable or excessive vibration since a high amplitude for a low rpm machine might be acceptable whereas that same amplitude for a high rpm machine would not be acceptable.

A typical spectrographic vibration plot is shown in Figure 8-5 below. This plot is a "must have" in determining the severity of the vibration and the sources of vibration.

Another useful tool is the vibration map shown in Figure 8-6. This semi-log plot provides RPM and Hertz (cycles per second) on the horizontal scale and vibration in Mils (0.001 inches) displacement, velocity (inches per second) and acceleration (Gs) on the vertical scales. Using this chart it is easy to convert from one system to another. However, for accuracy the following equation is provided to convert Mils to velocity.




Figure 8-5. Spectrographic Vibration Plot

Vibration 103

$$V = \frac{\text{Mils} \times \pi \times \text{rpm}}{60,0000}$$
 (8-2)

Where

V = Velocity in inches per second

 \prod = Pi = Constant = 3.14

RPM = Revolutions per minute

This chart is also useful in determining when vibration is normal, smooth or rough. As shown on the chart a machine is running smooth when velocity is below 0.03 inches per second (ips), and it is always running rough when velocity is above 0.2 ips.





Figure 8-6. Vibration Map Showing Relationship between Displacement, Velocity and Acceleration



Chapter 9

Valve Requirements

Valves have numerous uses in every compressor application. In general these include process control, isolation and safety.

- The process control valve is used to regulate or control the flow, pressure and temperature of the system. The valves that best perform this function are the ball valve, butterfly valve and globe valve.
- The isolation valve is used to "shut in" a compressor. This is necessary in order to perform maintenance on the compressor. The valves that best perform this function are the gate valve, knife valve and plug valve.
- The safety valve is used to protect the compressor and personnel in the area. It is always either automatically activated or is controlled to activate in response to a critical condition. The valves that best perform this function are pressure relief valves and check valves.

Table 9-1 list the primary functions of the most frequently used valves

Valves have different flow-through characteristics as a function of their trim design (see Table 9-2). Valve trims are selected to meet the specific control application needs. In a way this is a throw- back to the days of pneumatic and electric control which were limited in their ability to manipulate valves. While today's computer control capability is sufficiently sophisticated, valve trims are still selected to minimize the programmers work. The most common valve trim characteristics are linear, equal percentage and quick-opening.

Figure 9-1 graphically demonstrates valve trim flow characteristics relative to valve travel. Variations of these three configurations are also available.

Table 9-1. Valve Types

Ball valve	Provides on/off control without pressure drop.	
Butterfly valve	Provides flow regulation in large pipe diameters.	
Choke valve	Used for high pressure drops found in oil and gas wellheads.	
Check valve	A non-return valve allows the fluid to pass in one direction only	
Gate valve	Used for on/off control with low pressure drop.	
Globe valve	Provides good regulating flow.	
Knife valve	Provides positive on/off control also used for slurries or powders.	
Needle valve	Provides accurate flow control.	
Piston valve	Used for regulating fluids that carry solids in suspension.	
Pinch valve	Used for slurry flow regulation.	
Plug valve	Provides on/off control but with some pressure drop.	

Table 9-2. Valve Trim

Linear	Flow capacity increases linearly with valve travel.
Equal Percentage	Equal increments of valve travel produce equal percentage changes in the existing $C_{v'}$
Quick opening	Large changes in flow are provided for very small changes in lift. Due to its high valve gain it is not used for modulating control but it is ideal for on/off service.

PROCESS CONTROL

Not all processes are the same and different processes require different valve trim and valve response. Throughput control may be accomplished with one or more valves in suction, discharge and/or recycle (throughput control was discussed in detail in Chapter 5). The following recommendations apply to valve selection for all compressor types:




Figure 9-1. Valve Trim Flow Characteristics

- Valve full stroke to be less than 2 seconds.
- Select linear or equal percentage valve characteristics for all but "shut in" applications.
- Minimize the length of pneumatic tubing between the I/P (pneumatic to current) converter and the valve positioner.

For surge control and reciprocating throughput control (for example, using suction valve unloaders) the valve requirements are more stringent:

- Valve full stroke to be 1 second or less.
- Select linear valve characteristics.
- Installation of line booster may be considered as necessary.

Recycle (or blow-off in the case of air compressors) valves are always used with dynamic compressors, but they can also provide flow control in other compressor applications. The following recommendations should be considered for all recycle valve applications:

- Position the recycle valve as close to the discharge port of the compressor as possible.
- Minimize the volume between the compressor discharge, the check valve in the discharge line, and the recycle valve.
- Position the check valve downstream of the "tee" to the recycle valve. The check valve should not be between the compressor discharge and the recycle valve.
- If recycle gas cooling is required, a gas cooler should be positioned downstream of the recycle valve between the recycle valve and the suction line.
- A check valve is an important component of the system to assure safety of the compressor under difficult conditions.

Valves are typically arranged around a compressor as depicted in Figure 9-2. Although both suction and discharge valves are shown, only one valve would be needed.





Figure 9-2. Typical Valve Arrangement



Chapter 10

Instrument Requirements

Instruments are devices that measure or control variables such as flow, temperature, liquid level, or pressure. Instruments include:

- Sensors—to measure
 - flow
 - temperature
 - pressure
 - speed
 - vibration
 - liquid level
- Converters to transform the signal from
 - digital to analog or
 - analog to digital,
- Transmitters (to forward the measured signal to local and remote locations),
- Analyzers (combines multiple signals to provide a corrected or related output).

According to the Instrumentation and Systems Automation Society (ISA), formerly known as Instrument Society of America, the official definition of Instrumentation is "a collection of Instruments and their application for the purpose of Observation, Measurement and Control."*

Table 10-A lists some of the most commonly used sensors.

At times more than on sensor is needed to produce an appropriate measurement. For example, an accurate flow measurement requires the

^{*}Reference: ISA std. S 51.1—(Instrument Society of America)

Parameter	Sensor
Flow	Orifice plate, annubar, rotometer, turbine meter, venturi meter
Temperature	Resistance temperature detectors (RTDs) and thermocouples
Pressure	Manometers, Pitot tubes, piezometers and transducers
Speed	Proximitor probes or magnetic pickups. Proximitors are less likely to be damaged by vibration. Proximitor probes are designed to be intrinsically safe for use in electrically hazardous areas.
Vibration	Seismic, proximitor, accelerometer
Level	Floats

Table 10-1. Sensor Types

differential pressure across an orifice, the temperature of the gas and the composition of the gas.

The accuracy of flow measurement is especially important in applications such as gas sales. In other applications, such as in dynamic compressor anti-surge control systems and positive displacement throughput control, the main criteria for flow measurement are repeatability and sufficient signal-to-noise ratio. The preferred location of a flow measuring device is in the compressor suction line as close to the inlet port as possible. A less preferable location is in the compressor discharge line as close as possible to the compressor discharge port.

Selection of the location should be based on the following factors:

- Simplification of the algorithm for throughput or surge control
- Simplification of surge protection for dynamic compressors
- Installed cost of the flow measuring device
- Cost of operation of the system as a function of the selected device.

Speed of response is also an important consideration.

• Delay in the control system due to the flow measuring device must

be absolutely minimal (head meters or gas velocity).

The flow measuring device and its transmitter should be sized based on the maximum flow of the compressor.

- Select the type and location of the flow measuring device such that the pressure differential corresponding to the maximum flow of the compressor would be 10" water column or more.
- Minimize the length of the tubing between the flow measuring device and the transmitter.

Select the transmitter type and brand based on the following:

- Reliability
- Speed of response (suggest 80 milliseconds or less)
- Thermocouples (in thermowells) are too slow for control or surge detection
- Thermocouples (exposed junction) are preferred for performance trending and surge control
- Resistance temperature detectors (RTD) are accurate in low temperature applications <500°F

Thermocouples and RTDs are made of different materials suitable for different temperature ranges. Thermocouples are classified as type J, K, T, E, R, and S. RTDs are either 10 Ω copper or 120 Ω nickel RTD. Table 10-2 lists the various temperature ranges for each type.

Pressure measurements may be in inches of water ("WC or "H₂O), inches of mercury ("Hg), pounds per square in gage (psig), or pounds per square inch absolute (psia). Transducers are the most common instrument used in pressure measurement. Both standard and smart transducers are in common use today. And both have their advantages and disadvantages. Standard transducers provide near-instantaneous readings which are critical for surge control. Smart transducers average the pressure measurements usually over a 1/4 of a second (250 milliseconds). Smart transducers should not be used for surge control.

Table 10-2. Thermocouple & RTD Temperature Ranges

ТҮРЕ	RANGE
J	−328° to 1382°F, −200° - 750°C
K	−328° to 2498°F, −200° to 1370°C
Т	−330° to 760°F, −200° to 404°C
E	−328° to 1832°F, −200° to 1000°C
R	32° to 3213°F, 0° to 1767°C
S	−40° to 3214°F, −40° to 1768°C
100Ω Pt RTD	−328.0° to 1382.0°F, −200.0° to 750.0°C
10Ω Cu RTD	−328° to 500°F, −200° to 260°C
120Ω Ni RTD	−112° to 608°F, −80° to 320°C

Chapter 11

Detectable Problems

Compressors, either dynamic or positive displacement, can experience a variety of problems, but there are relatively few diagnostic tools to identify them.

Except in cases where vibration is the issue, a thermodynamic analysis of a compressor is the most straightforward way to determine its health. However, this requires that specific instrumentation be installed on the unit. Thermodynamic analysis algorithms were discussed in detail in Chapter 2 - Compressor Theory.

Vibration was addressed in Chapter 8. In addition to the items discussed there, vibration cause and effect is detailed in Appendix H "Troubleshooting."

Fortunately many problems can be avoided before they become costly. Most of these problems can be avoided or minimized with proper and timely preventive maintenance. Obviously not all problems can be avoided. Some problems are inherent in the design. These fall squarely on the shoulders of the manufacturer.

As a rule of thumb a problem that becomes evident during the first twelve months of operation will be covered under the manufacturer's warranty. As used here "manufacturer" also applies to the "packager." The packager is a "third-party" company that installs the compressor, driver (electric motor, gas engine, gas turbine or steam turbine), various vessels, valves, piping, lubrication system and controls on or adjacent to the main skid. The packager, often referred to as the original equipment manufacturer (OEM), has a pre-arrangement with the main component (compressor, driver) manufacturers to package its equipment. Usually this arrangement includes an exclusivity agreement and price discounts. In almost all cases the major equipment warranty is a "pass through" from the specific equipment manufacturer (compressor, driver, etc.).

There are exceptions but once the unit has operated successfully for approximately twelve months any problem that surfaces is usually not covered under the manufacturer's warranty. When equipment has



Figure 11-1. Separable Balanced Opposed 6—Throw Engine Driven Compressor in Pipeline Service Complete with Off-skid Mounted Control System.

not operated successfully during the first twelve months of operation, it is imperative that the owner/operator and the OEM work together to identify and resolve the problem or problems.

When a problem becomes evident, regardless of the compressor's age or run time, the following basic questions should be addressed as soon as possible:

Is the problem mechanical, electrical or performance?

- 1. Mechanical problems are associated with vibration, sound, or leaks (air, gas, water, oil). As such mechanical problems are self-evident. Although the cause may not be obvious the symptoms are.
- 2. Electrical problems are associated with high voltage to the electric components (motors, motor starters and switchgear) or low voltage to the instruments and control systems. Diagnosing electrical problems is not as easy as diagnosing mechanical problems. However, once the problem is identified the fix is relatively inexpensive.

3. Performance problems usually result from mechanical deficiencies within the compressor (engine or turbine driver and electrical problems with a motor driver). These problems may or may not be immediately evident during operation, but they will lead to equipment failure. This type of failure is usually costly with regards to replacement parts, labor and downtime. Sometimes downtime is the most expensive result of the failure.

Regardless of the type of failure in many cases catastrophic failure can be avoided by applying the following guidelines:

- 1. Upon installation run the unit to design speed.
 - a. Record the unit's vibration signature at several points throughout the expected operating range.
 - b. Perform a gas path analysis at several points throughout the expected operating range.
 - c. Record temperatures on the compressor not monitored by control instrumentation (such as suction and discharge valve cover temperatures, cooling water temperatures, etc.)
 - d. Make note of the different sounds emanating from the compressor during startup, shutdown and at normal operating speed.
- 2. After the unit has run successfully at a stable temperature for at least four hours shut the unit down and inspect the unit with minimal disassembly (do not remove any close tolerance or close fit components).

In axial compressors surge is the single most severe and expensive failure resulting in damage to the bearings and seals and sometimes to the impellers, diaphragms, blades and vanes as shown in Figure 11-2 and 11-3. Signs of surge are vibration, gas flow instability, gas pressure and temperature fluctuation and audible "huffing" or "whooshing" sounds. Surge occurs very rapidly and it can only be avoided if proper control techniques are applied. Surge was discussed in detail in Chapters 6 and 7.

Compressor Fouling

Indications and Corrective Action

A compressor efficiency drop of 2 percent is indicative of compressor fouling. This can be calculated as shown.




Figure 11-2. Axial Compressor Stator Surge Damage



Figure 11-3. Axial Compressor Rotor Surge Damage

$$\eta_{c} = \frac{\left(\frac{CDP}{P_{in}}\right)^{\frac{k-1}{k}} - 1}{\left(\frac{CDT}{T_{in}}\right)^{\frac{k-1}{k}} - 1} \tag{11-1}$$

For the field engineer or operator, compressor fouling is best indicated by a 2 percent drop in compressor discharge pressure at constant speed and load or throughput. Another indication of fouling is a 3-5 percent reduction in load or throughput capacity at constant compressor inlet temperature or ambient air temperature.

Corrective Action

 Dynamic compressor equipment manufacturers normally specify cleaning agents. Typically, a liquid-wash is specified. In extreme cases complete disassembly may be necessary to clean the compressor.

Note: Impact damage to dynamic compressor blades or impellers can mimic compressor fouling. If performance does not recover after washing than the unit should be inspected for internal damage. Many units are equipped with boroscope ports which facilitate internal inspection with minimum downtime and disassembly.




Figure 11-4. Axial Compressor with Contamination Build-up On Blades.




Figure 11-5. Axial Compressor with Contamination Build-up on Leading Edge of Stator Airfoils.




Figure 11-6. Reciprocating Compressor Distance Piece with Piston Rod.

In addition reciprocating compressor fouling (due to either debris or liquids in the gas) may result in damage to the suction or discharge valves and the piston rod. Damage to the valves will manifest itself as an increase in temperature of the valve covers. Rod damage may be detected during operation as non-linear movement of the rod as it passes through the gland at the crosshead-cylinder interface. Also the wear pattern will become more severe as the rod wears against the packing (see Figure 11-7).

Corrective Action

- Disassemble valves, clean and replace valve plates as necessary
- Remove piston and rod assembly and replace rod.

Loose Piston

The installation of the piston rod onto the piston is a delicate procedure requiring a special lubricant, special technique and often special tools. If not properly installed the piston may become loose on the piston rod. This will result in the piston hitting the end wall at the head-end and crank-end of its travel and eventually will result in failure of the piston end wall.



Figure 11-7. Reciprocating Compressor Piston Rod Showing Wear at Location Where Rod Passes through Packing Area.

Corrective Action

- Pull the head-end cover and head-end and crank-end valves to inspect the piston
- If no damage is evident, re-torque the piston rod nut, re-assemble the compressor and test.
- Replace damaged components as necessary

Bearing Clearance (Hydrodynamic Bearings)

Excess bearing clearance can result from improper bearing installation or from journal and bearing shoe wear over a period of time. In either case the effect of bearing looseness can be detected during operation by checking the bearing whirl orbit. Bearing whirl orbits were discussed in Chapter 8, Vibration.

Hydrodynamic bearing whirl orbits should be checked at the factory as part of the unit run test (where the necessary vibration equipment is most likely to be available). At the factory this problem is relatively easy to fix.

Referring to Figure 11-10, the orbit on the left is a stable orbit while the orbit on the right is an unstable orbit. The unstable orbit will also demonstrate high vibration. However, the vibration may or may not be above maximum allowable limits. Continued running with an unstable



Figure 11-8, Compressor Piston on Inspection Table.



Figure 11-9. Typical Hydrodynamic Tilt-pad Bearing. This Bearing Pivots on Pins Specifically Sized to Obtain the Proper Bearing-to-journal Clearance.




Figure 11-10. Stable And Unstable Hydrodynamic Bearing Whirl Orbits

orbit will lead to increases in vibration that will eventually exceed acceptable limits and, therefore, should not be ignored.

Reciprocating Compressor Valves

Due to the stresses on the valve plates during normal operation suction and discharge valves are the high maintenance items in reciprocating compressors. Valve plate failure will have a negative impact on compressor performance. Gas path analysis coupled with direct measurement of the valve cover temperature is the easiest way to detect valve plate failure.

Corrective Action

- Periodic gas path analysis to monitor compressor performance is the first step in detecting a problem.
- When degraded performance is detected a check of valve cover temperature can isolate the problem valve or valves.
- Replaced the defective valves as soon as possible.

Entrained Liquids

Liquids in the gas present a major problem for reciprocating compressors. As a minimum they will result in early and frequent failure of




Figure 11-11. Reciprocating Compressor Discharge Valve Showing Carbon Build-up.

the compressor valves and when extreme can result in one or more bent rods. Liquids do not present as big a problem for dynamic compressors, screw compressors or blowers as these compressors are more tolerant to liquids in the gas. In fact the screw compressor is so tolerant of liquids that sealing oil is intentionally injected into the gas stream (as in oil flooded screw compressors) prior to compression and extracted after compression. Extremely large amounts of liquids can result in dynamic compressor surge.

Corrective Action

- The first line of defense against liquids is a scrubber or knock-out vessel. This vessel is simply a large area with a coalescing media installed upstream of the compressor where gas velocity is reduced to allow the liquid to separate from the gas. Scrubbers are also installed between stages in multistage compressors.
- Where liquid carryover is severe a cyclone separator may be employed. A cyclone separator utilizes the gas velocity and internal passages to create vortex separation.
- In addition to a scrubber, line tracing or heating may be employed to raise the gas temperature to vaporize the entrained liquids.



Figure 11-12. Reciprocating Compressor Showing Piston Rod Installed in Crank End of Piston.



Figure 11-13. Reciprocating Compressor Showing Failed Piston Rod at Mating Surface with Crank End of Piston.

Variable Volume Pocket Plug

The variable volume pocket plug is positioned via a screw mechanism. Failure of the screw mechanism (see Figure 11-16) could result in the inability to reposition the plug. Screw failure could also result in the plug being sucked into the cylinder where it can become wedged resulting in catastrophic failure (see Figures 11-14 and 11-15).

Corrective Action

 Whether the screw is turned manually or is automated via an electric or hydraulic motor this mechanism should be inspected periodically and maintained per the manufacturer's recommendations.

Lubrication Oil

Lubrication oil should be checked periodically for lubricity, contaminants and water. For small compressors the unit should be shut down and the oil replaced. For compressors with large volume reservoirs the lube oil can be reconditioned on site while the compressor is operating. Lubrication oil should be stored correctly in closed containers with the containers in a rain protected shelter. Figures 11-17 and 11-18 show near-new and failed bearing shoes. The failure was the result of




Figure 11-14. Reciprocating Compressor VVP Failure at Screw.




Figure 11-15. Reciprocating Compressor Showing Failed Distance Piece.




Figure 11-16. Reciprocating Compressor Showing Damage to the VVP Following Failure of the AdjustWer Screw.




Figure 11-17. Reciprocating Compressor Hydrodynamic Bearing Shoe Showing Normal Wear.



Figure 11-18. Reciprocating Compressor Hydrodynamic Bearing Shoe Showing Distress Following Bearing Failure.

rain water accumulating in the lube oil storage drums and than being introduced into the compressor lube oil reservoir during periodic maintenance.

A NOTE OF CAUTION: The photographs used are taken from actual projects. Therefore, the reader may recognize the manufacturer of the equipment shown in these photographs. However, the problems discussed are not uncommon and may involve any manufacturer's equipment. The reader should not assume that these problems are attributable to a specific manufacturer.



Chapter 12

Controlling Reciprocating and Centrifugal Compressors in Identical Processes

-by Tony Giampaolo

This case study addresses melding together the controllers of two separate compressor booster systems: the dynamic—centrifugal compressor and the positive displacement—reciprocating compressor. This is accomplished through the use of a supervisory control system. The supervisory controller implements the operators' selection for Primary and Secondary compressor systems unless a problem develops. If that happens the supervisory controller can take alternate action based on pre-programmed controller logic.

An edited version of this study entitled "A Unique Approach To Controlling Reciprocating And Centrifugal Compressors In A Fuel Gas Booster System" was published in *Western Energy Magazine* in the summer of 1994.

INTRODUCTION

A unique supervisory control system has enabled Harbor Cogeneration Co., operator of an 80 MW cogeneration plant in the Los Angeles area, to substantially increase the efficiency of its turbine fuel gas booster system. Normally, plant fuel gas is available at or above the 300 psig required by the turbine. However, pressure frequently drops into the 200 psig range, with an occasional excursion as low as 130 psig. During these times a 1,700 horsepower electric motor-driven centrifugal compressor is employed to boost the pressure to at least the required 300 psia.

However, since the centrifugal compressor is designed to operate at a suction pressure of 119 psig, the lowest pressure expected, its ef-

ficiency deteriorates as the inlet pressure increases above 119 psig and less compression is required. In other words the centrifugal compressor, which is designed to operate at a compression ratio of 2.3, is actually operating, much of the time, at a compression ratio of 1.1 to 1.3. Centrifugal compressors, when controlled with suction valve throttling and gas recycle, do not significantly reduce the horsepower consumed as suction pressure increases above its design pressure level. In these instances the compressor continues to pump the same amount of gas, mostly into the gas recycle line, resulting in lost energy (approximately 700 BHP) and reduced efficiency. To maintain a satisfactory level of efficiency in the plant fuel gas booster system with varying inlet pressures the company has employed a custom designed supervisory control system to integrate the existing motor-driven centrifugal compressor in parallel with a reciprocating compressor.

The choice of a reciprocating compressor was made after considering a variable frequency drive for the existing centrifugal compressor, or a second, stand-alone compressor.

- The variable frequency drive (VFD) would add another control element—speed control—and would reduce the need to recycle gas at all but the high suction pressure conditions (where recycle would still be required for surge protection). However, the VFD would also add complexity as yet another system: a system without backup, a system subject to failure. In short, the addition of the VFD would improve only efficiency. As a non-redundant system, the VFD would have an adverse affect on reliability or availability. Finally, VFDs are expensive!
- Under varying load conditions, the reciprocating compressor operates very efficiently at constant speed with suction valve unloading. The method provides good flexibility for the price as automatic suction valve unloaders do not add significantly to the package price. In this configuration, and for this application, the reciprocating compressor is slightly more expensive than the VFD. But as a complete and independent system, it is a 100% SPARE! Power savings of up to 690 BHP were expected (and have been achieved) with the reciprocating compressor compared to the centrifugal compressor. However, adding a reciprocating compressor in parallel with the existing centrifugal compressor did present an unusual control interface problem.




Figure 12-1. Parallel operation of compressors.

DISCUSSION

The reciprocating compressor chosen has automatic suction valve unloading and a small recycle line. The four-cylinder compressor provided eight load steps (two per cylinder), each step representing 12.5 percent of the total throughput. A small recycle line modulates throughput within this 12.5 percent step to maintain smooth flow to the gas turbine. A simplified flow sketch of the centrifugal and reciprocating fuel gas booster compressor in parallel is shown in Figure 12-1.

The 1,500 horsepower motor-driven reciprocating compressor operates at a constant 880 rpm. Throughput control is accomplished with fully automated suction valve unloaders and a modulated recycle line. Both the loaders/unloaders and recycle valve are pneumatically operated via solenoid valves and an I/P converter, respectively. The motor, compressor, frame and cylinder lube systems, cooling system for gas and oil and suction knockout drum are all located on the compressor skid.


THE CONTROL OVERVIEW

In designing this new operating system, Harbor Cogeneration worked with Power & Compression Systems of El Toro, CA. The supervisory control system (Figure 12-4) functions as a central control system. It provides the operator with the ability to pre-select either the



Figure 12-2. Electric motor-driven reciprocating fuel gas booster compressor package

Figure 12-3. Reciprocating compressor control panel



reciprocating or the centrifugal compressor; selection is made at the front of the supervisory control panel (Figure 12-5). Front panel lights indicate which compressor, if any, is running and if either compressor's main breaker has been locked out.

Under normal operating conditions the primary selected compressor is the running compressor. In the event the primary selected compressor is not available (aborted its start sequence, or experienced an unplanned shutdown), the secondary compressor is started. Selection of either compressor as the primary one automatically places the other compressor in the secondary mode.

METHOD OF CONTROL

General

The *start sequence* for the compressors is controlled by the supervisory control located in the main control room. This control was designed specifically by Power & Compression Systems to function as the central control system to integrate the controls of the centrifugal and reciprocating compressors.

It provides the ability to pre-select either the reciprocating or the centrifugal compressor; selection is made at the front of the supervisory control panel (Figure 12-5). Front panel lights indicate which compressor has been selected as *primary*. These panel lights also indicate which compressor, if any, is running and, if either compressor main breaker has been locked out.

Under normal conditions the primary selected compressor is the running compressor. In the event the primary selected compressor is




Figure 12-4. Control system interface

not available (aborted its start sequence, or experienced an unplanned shutdown), the *secondary* compressor is automatically started. Selection of either compressor as *primary* automatically places the other compressor in the *secondary* mode.

RECIPROCATING COMPRESSOR CONTROL

The reciprocating compressor is controlled by an Allen-Bradley PLC5-20 mounted in a control panel located next to the compressor skid (Figure 12-3). The PLC controls START, LOAD, UNLOAD, STOP and CAPACITY based on varying suction pressure and constant discharge pressure. The control panel is located off skid to isolate the panel from the vibration common with reciprocating compressors. Using analog and digital signals from the compressor, this con-



Figure 12-5. Supervisory control

trol performs data acquisition, monitoring, and diagnostics of the compressor and the control functions.

Automatic Operation

In the "compressor-auto-mode" position the controller initiates the start sequence as a function of a permissive from the supervisory controller, and gas pressure. Once initiated, the start sequence automatically starts the cylinder lube pump and (after lube oil pressures have been established) the main drive motor. The pre-lube pump is set to run continuously to maintain oil temperature and pressure.

The compressor starts with all ends unloaded and the recycle valve in the full open (100%-full recirculation) position. After a warm-up period, the compressor loads one, then two cylinder ends in 30-second intervals until "setpoint" pressure is reached and the recycle valve is modulating between 20 % and 70%. If the compressor remains at this condition for an extended period of time (that is, the recycle valve stays between 20% and 70%), the controller will load other cylinder ends (and unload the initial ends) to avoid heat build-up in the cylinders. This heatpreclude sequence is repeated at every load step when the recycle valve movement stabilizes between 20% and 70%. Each load step is initiated when the recycle valve moves to <20% open position. Similarly, each unload step is initiated when the recycle valve moves to >70% open position. At each transition the recycle valve will modulate from the closed to a partially open position to maintain smooth flow to the gas turbine. As suction pressure increases, the cylinder ends will unload in the reverse order.

Manual Operation

In the "compressor-manual-mode" position, the compressor can be started and loaded and unloaded manually. This provision is available for maintenance purposes only.

Remote Terminal Display

Also provided is a remote workstation located in the main control room. This remote workstation interfaces with the field PLC, to provide continuous operating and status information (operating conditions, parameters, and alarms). The remote workstation, a PC-based unit, continuously stores data into memory and makes these data available when requested.

Centrifugal Compressor Control

The centrifugal compressor is controlled by the plant distributed




Figure 12-6. Remote Workstation

control system (DCS) and the supervisory control. This control system is augmented by an antisurge controller mounted on the compressor skid.

Automatic Operation

In the "compressor-automatic-mode" position, the compressor initiates a start as a function of gas turbine suction pressure and a permissive from the supervisory control. The controller then modulates the suction throttle valve and the recycle valve to vary gas flow to the gas turbine. The recycle valve also functions as a surge control valve. As suction pressure decreases, the recycle valve modulates to the full closed position. As suction pressure continues to decrease, the suction valve opens.

Manual Operation

In the "compressed-manual-mode" position, the recycle valve must be placed in the full opened position and the suction throttle valve in the near closed (it never goes full closed) position prior to start. Once started, the recycle valve can be closed, and the suction throttle valve opened until the required throughput is reached. Care must be taken that the valve is moved slowly to avoid driving the compressor into surge.

POTENTIAL PROBLEMS THAT WERE AVOIDED

Several potential problems were anticipated and steps were taken in the design stage to address these.

- As each cylinder end is loaded, that volume of gas is sent to the gas turbine. This increase in flow could result in over-temperature and/or instability. Either condition would be very detrimental to the gas turbine, and to avoid them the following control elements were utilized:
 - a) Time delays were incorporated into the cylinder loader/ unloader logic to facilitate adjusting each sequence during field loop tuning.
 - b) Using open-loop response, the recycle valve was prepositioned prior to each sequence change. Also, time delays were incorporated into the recycle valve logic to facilitate field adjustments.
 - During commissioning, these timers were easily adjusted to minimize impact on the gas turbine.
- 2) When flow, suction and discharge pressure remain constant, the cylinder ends must be sequentially loaded and unloaded in order to prevent heat build-up in the unloaded cylinders. This "heat preclude sequence" is repeated over the 8-cylinder ends (and throughout the various load steps) so that no cylinder end is completely unloaded long enough for temperature to rise to an unacceptable level. To complicate this task, the torsional study recommended against loading certain end configurations (e.g. 5 ends loaded = with all 4 head ends loaded, load crank end #3 or #4, never #1 or #2).
 - a) Each heat preclude step was programmed into the logic per the results of the compressor manufacturer's torsional study. Since the actual heat build-up time was uncertain (the manufacturer claimed a minimum of 15 minutes per cylinder end) timers were built into each logic step so that they could be easily adjusted in the field. This proved to be more help than originally anticipated, since the heat build-up was actually closer to 10 minutes at the 2 and 3 ends loaded configurations.

- 3) The recycle valve had to move fast enough to compensate for the action of the suction valve loader/unloaders. The actuation speed of the loader/unloaders was not known, even to the manufacturer. However, the recycle valve could be made to move, full stroke, in less than one second.
 - a) A volume booster was designed into the operation of the recycle valve to improve its response time. Recycle valve "full stroke" speed of response was initially about 5 seconds. This was considered too slow as the loader/unloader responses, when measured, was less than 1 second. To match the responses of the loader/unloader valves and the recycle valve it was easier to improve the response of the recycle valve.
 - b) By adjusting the timers in the suction valve loader/unloader logic, valve operation could be staggered slightly.
- 4) The supervisory control had to insure that one and only one compressor was allowed to start in automatic. Furthermore, the *secondary* compressor had to start in the event that the *primary* compressor did not start as planned. Finally, regardless of the other compressor's status (shutdown, running, etc.) each compressor had to have the ability to be started manually for maintenance purposes. Figure 12-7 shows some of the ladder logic employed in the supervisory control.
- 5) Control loop tuning was accomplished with the aid of a 20-channel high-speed recorder. The recorder indicated the movement of each unloader (16 channels), the recycle valve, and suction and discharge pressure. Initially the control gain and reset rate were set. Once this provided a stable operation at each load level, then the unloaders were also controlled by utilizing open loop control of the recycle steps. The load steps were also controlled by utilizing open loop control of the recycle valve. All of these variations, and adjustments to individual controls, were monitored with the high-speed recorder. The recorder (Astro-Med MT95K2) provided easy programming, calibration, chart speeds selection, and laser printer resolution. The chart speeds utilized were 1 mm/sec, 5 mm/sec, and 25 mm/sec.

Proportional gain and reset rate was calculated using the Ziegler & Nichols technique for closed loop tuning. Initial and final recycle valve response are shown in Figures 12-8 and 12-9.




Figure 12-7. Supervisory Control Ladder Logic




Figure 12-8. Initial Recycle Valve Response




Figure 12-9. Final Recycle Valve Response

CONCLUSION

Performance tests conducted during commissioning confirm the BHP at the design condition was as expected (410 BHP). This is a significant improvement compared to the 1100 BHP required by the centrifugal compressor at the same design conditions.

Variations in pressure ratio and throughput are accomplished by automatic unloaders installed on each suction valve. This reduces the total motor load required compared to the centrifugal compressor at high suction pressures (at low suction pressures efficiencies are comparable). Also each load step (8 steps total) represents 12.5% of the throughput. Therefore, the size of the recycle line and valve are reduced, improving efficiency by eliminating excessive recycle, and the smaller recycle valve contributes to improving valve response time.

While each case is different and should be considered on its own merits, the control techniques employed here can be utilized on compressors (single or multiple configurations, operating in series or parallel) in any environment that requires variation in pressure and throughout.

Chapter 13

Optimization & Revitalization of Existing Reciprocating Compression Assets

–W. Norman Shade, PE ACI Services Inc.

Compressors, without a doubt, have the longest life expectancy of any piece of mechanical equipment. This study discusses how compressors can be revitalized and returned to service (see also Figures 3-16 and 3-41—Chapter 3—for an example of compressor reconditioning).

Many reciprocating compressors in North America and throughout the world have been in service for decades, some operating for more than half a century. Most older models are no longer optimal, and many are not dependable for current process requirements. Over time, technology has improved and energy costs have increased, making it economically attractive to optimize and revitalize existing compression assets with components that take advantage of modern technology. Efficiency, reliability and maintainability can be greatly improved through custom engineered solutions. Changes may range from conversion to better compressor valves, to the addition of properly designed automatic unloading devices for better control, to the installation of new purposebuilt compressor cylinders and components, to the complete reapplication of an entire compression system to a new service.

Even relatively new compressors can become inefficient and mismatched as production needs change. In other cases, from the time the units were installed, actual operating conditions never quite matched the design conditions specified when the equipment was ordered. In still others, manufacturers may have missed the mark when designing and applying their products, so that the equipment underperforms or is unreliable for its intended service.

Whatever the reason, changing valves or cylinders, adding unloaders and automatic control, or reapplying, existing reciprocating compressors is frequently necessary and justifiable. In the case of newer compressors, the OEMs may have standard cylinders that can be retrofitted to their frames, however that usually requires expensive changes to the process piping, pulsation vessels, and cylinder mounting. In the case of mature compressor models that are no longer in production, new OEM cylinders tend to be expensive and have long lead times, if available at all. In some applications, when new compressors are selected or used compressors are redeployed, the standard OEM cylinder line-up may not include the optimal cylinder bore size or working pressure rating for the desired operating conditions. Any of these situations are candidates for custom engineered cylinders and unloading devices that provide cost-effective solutions for preserving the value and reducing the operating cost of existing compression assets.

NEW CUSTOM ENGINEERED REPLACEMENT CYLINDERS

With over 30 years of designing and manufacturing custom engineered compressor cylinders, internal components, valves, and unloading systems, the author's company has helped a large number of compressor users improve their competitive edge by providing creative solutions that improve their existing compression assets to improve performance, efficiency, reliability, maintenance cost, and safety. These efforts have provided solutions to operating problems, have improved the performance and have increased the reliability of reciprocating compressors. The extensive experience in designing and manufacturing custom engineered compressor cylinders is represented in Figures 13-1 and 13-2. Custom engineered cylinders have been applied on all major brands of compressors ranging from small 3.0 in. (76.2 mm) stroke, 1800 rpm high-speed models to giant 20.0 inch (508.0 mm) stroke, 330 rpm frames, with bore sizes ranging from 1.33 to 36.0 in. (33.8 to 914.4 mm), and working pressures from as low as 50 psig (3.5 bar) to as high as 12,000 psig (827.4 bar) for upstream, gas transmission, gas storage, chemical process, refinery, high-pressure air and other services.

New compressor cylinders can be custom engineered and purpose

built to meet customer specifications or to solve problems with existing OEM designs. In most cases, the cylinders can be "bolt-in" replacements to match existing process piping connections and mounting locations, which avoids expensive system piping and foundation modifications. Cylinders can be jacketed (water cooled) or non-jacketed (air cooled) and made from appropriate material for the application. Ductile iron castings are most commonly used in recent years, although gray iron, steel or stainless castings are also used, as are steel and stainless steel forgings. Reduced hardness materials are available for sour gas and other applications requiring NACE specifications. Cylinder bores may be supplied in the virgin material condition, ion nitride hardened for improved wear resistance, or lined with a replaceable sleeve. Depending on the requirements, existing internal components may be reusable, however new valves, piston rod packing and maintenance friendly piston and rod assemblies are often included. A wide range of manual and automatically controlled clearance volume pockets and end deactivators are also available, custom engineered for the specific application requirements.

Case History 1: Increased Pipeline Compressor Capacity

In the first example, a mid-continent USA natural gas pipeline operator had several existing Clark HBA and HRA integral engine compressors with cylinders that no longer served the operating needs




Figure 13-1. Custom cylinder experience—bore dia. vs. stroke




Figure 13-2. Custom cylinder experience—pressure rating vs. bore diameter

of the compressor station. The customer specifications dictated an approximate 32% increase in bore size in a new cylinder that provided maximum operating efficiency. In addition, the cylinder was to have external dimensions that permitted the use of the existing piping system, cylinder supports and foundation. It was readily apparent that a conventional cylinder design would never meet all of the requirements of the specification. The OEM, who supplied the engines, agreed, but offered a conventional design that did not meet the specifications. The Four-PosterTM cylinder offering was sufficiently unique that the author's company received a patent on the new design.

In addition to meeting all the specification requirements, the cylinders were offered at a lower price and shorter delivery than offered by the OEM. In this design, all valves were accessible from the top of the cylinder and the front and rear head, piston assembly, liner and packing case were accessible from the front of the cylinder. A total of 42 new 12.50 inch (317.5 mm) bore, 1000 psig (69.0 bar) cylinders were retrofitted onto multiple 17.0 in. (431.8 mm) stroke compressors. Closed loop tests certified the efficiency of the cylinders. Significant savings resulted from the re-use of the piping and cylinder supports and the absence of foundation changes. Subsequent to the supply of these 42 cylinders, other orders were received for four more identical cylinders and sixteen cylinders with slight modifications for another OEM's 14.0 in. (355.6)




Figure 13-3. Retrofitting custom engineered cylinders increased bore size by 32% on this 17 in. (431.8 mm) stroke Clark integral compressor.

mm) stroke engines. All cylinders delivered trouble free service.

Case History 2: Improved Service Life

A USA Gulf Coast chemical plant had a Worthington BDC off gas compressor with cast iron cylinders that were constantly under chemical attack from extremely corrosive gas. Cylinder life was typically only 3 to 5 years, and the OEM had not resolved the problem to the satisfaction of the customer, who required a functionally equivalent cylinder design that would directly replace the existing cylinder to the extent that all other parts of the assembly could be re-used with the new cylinder body.

The customer had attempted to produce replacement cylinders of the same geometry in a ni-resist material, however, the cylinder geometry and jacketed design were not compatible with ni-resist foundry practices and requirements. As shown in Figure 13-4, the author's company redesigned the exterior of the jacketed, 400 psig (27.6 bar), 12.0 in. (304.8 mm) bore, 9.5 in. (241.3 mm) stroke cylinder body to simplify and enhance foundry procedures. Proper core support and clean out and pattern orientation in the mold resulted in sound castings when produced in ASTM A316 series stainless steel.




Figure 13-4. This custom engineered ASTM A316 cast stainless steel cylinder eliminated a severe corrosion problem with the cast iron cylinder that it replaced.

The change to A316 stainless steel resolved the corrosion problems and eliminated the periodic safety inspections that had been required with the original cast iron cylinders. For more than 20 years, the replacement cylinders have been more productive, and maintenance costs have been reduced. Similar replacements of this type were subsequently provided for 19.5 and 7.75 in. bore (495.3 and 196.9 mm) cylinders for adjacent stages.

Case History 3: Providing Safe and Reliable Production Operation

A large Cooper Bessemer V250 integral engine compressor in an Austral-Asian fertilizer production plant had experienced repeat failures of the 3rd stage syn gas cylinder. The 6.50 in. 5 (190.5 mm) lined bore diameter, 20 in. (508.0 mm), 6000 psig (413.7 bar) forged steel cylinder was a design that employed transverse tie-bolts for reinforcement. After several years of service, cracks would originate in the discharge valve pockets and migrate to the tie-bolt clearance holes as shown in Figure 13-5. A thorough engineering analysis revealed very high stresses and unacceptable fatigue safety factors in the valve seats as shown in Figure 13-7.




Figure 13-5. 3rd stage syn gas cylinder showing location of leak detection.

Since the high-pressure 3rd stage was normally operating at 93% of rated rod load, and the 1st and 2nd stages were lower at 77% and 59%, respectively, a performance study was completed to determine an optimal bore size for the new 3rd stage cylinder. Interacting with the plant engineering staff, it was agreed that the new cylinder bore diameter could be reduced to 6.00 in. (152.4 mm), which cut the normal operating rod load to 84% of rated, while still maintaining acceptable rod loads of 79% and 68%, respectively, on the 1st and 2nd syn gas stages. It was also determined that the low molecular weight permitted a reduction in valve diameter, which significantly reduced the preload on the valve cap bolting, while also increasing the section thickness in the critical corners where the valve pockets intersected the main bore.

A new 6.00 in. (152.4 mm) AISI 4140 forged steel bolt-in replacement cylinder was designed and extensively analyzed to achieve acceptable fatigue safety factors. The new jacketed cylinder, shown in Figure 13-6, was fully machined from a solid block forging that was 3 in. (76

mm) thicker than the original cylinder. The problematic tie-bolts were eliminated, and the critical valve pocket fillet geometry was carefully controlled and then shot peened after machining to provide beneficial compressive preload stresses. Water jacket side covers were fully machined from aluminum plate material to eliminate a corrosion problem that was prevalent with the original cast iron side cover design.

Case History 4: Eliminating Extremely Serious Piston Failures

A major oil company was experiencing frequent and rapid piston failures on the 2nd stage of a reapplied 4000 hp (2983 kW) Superior W76 compressor used for sour gas lift service on an offshore platform. Not only was downtime causing six figure daily production losses, operating personnel were fearful that the piston failures could lead to a breach of the lethal sour gas, which would be extremely dangerous on an offshore



Figure 13-6. New AISI 4140 forged steel cylinder with water jacket, weighing more than 10,000 lb. (4335 kg).




Figure 13-7. Finite element stress analysis of high-pressure cylinder body showing high stresses in valve seat fillets.

platform. The OEM and another compressor service company had both tried to solve the problem with new pistons, but failures continued in as little as 8 days of operating time. Upon being consulted for help, the author's company conducted a thorough assessment and found that very high 2nd stage operating temperature, coupled with rod loads that were at or above the manufacturer's rating, were the root causes of the rapid, catastrophic failures of the 18.0 in. (457.2 mm), 7.0 in. (177.8 mm) stroke multi-piece aluminum and ductile iron pistons. As shown in Figure 13-9, the cylinder was an unusual shape that resulted in a very short piston length relative to the diameter. A finite element stress analysis, as shown in Figure 13-8, showed that the original piston design had a fatigue safety factor of less than 1.0 at the required operating conditions, which explained the rapid failures. Unfortunately, the alternatives for resolving the problem were very limited.

The short cylinder and OEM limits on the permissible reciprocating weight precluded the use of a stronger, less temperature sensitive ferrous material piston. Adding interstage cooling to reduce the 194°F (90°C) suction temperature was not practical on the offshore platform due to space limitations. The OEM did not have an alternative cylinder that would solve the problem, and lead time for a complete new




Figure 13-8. Multi-piece Piston finite element stress plot.




Figure 13-9. Original 18.0 in. (457.2 mm) OEM 2nd stage cylinder [left] that experienced frequent rapid, catastrophic piston failures due to a mis-application.


replacement compressor package was about 18 months at the time. A custom engineered replacement cylinder was determined to be the preferred solution, but lead time was also prohibitively long. Concurrent design and analysis efforts established that a one-piece solid aluminum piston, although not having infinite life, would operate for a longer and reasonably predictable period of time. This was adopted as a temporary measure until a new replacement cylinder could be designed and

manufactured. With the one-piece pistons providing additional time for development of a permanent solution, further review of the operating conditions of the 1st and 2nd stages showed that further benefits were achievable by changing the two 1st stage cylinders along with the 2nd stage. By changing the two 1st stage cylinders from 20.0 in. (508.0 mm) to 21.0 in. (533.4 mm) and the 2nd stage from 18.0 in. (457.2 mm) to 18.125 in. (460.4 mm), a better balance of rod loads and interstage temperatures was achieved, while providing the compressor with an increased capacity rating that was an unexpected bonus for the operator.

All three of the new ASTM A395 ductile iron cylinders were designed longer to accommodate longer ductile iron pistons that were capable of the required loading. In order to do this while also maintaining process piping connection points, special cast ductile iron offset adapters were designed and manufactured for the suction and discharge connections. The pistons were high-performance, two-piece ductile iron castings with internal ribs. Both the cylinders and the pistons were extensively analyzed with finite element stress models. Standard Ariel variable volume clearance pockets were adapted to the new 1st stage cylinders. The new cylinders received hydrostatic tests at 1.5 times working pressure, followed by helium submersion tests at working pressure. Field-installed on the original frame as shown in Figures 13-10 and 13-11, the new cylinders have completely eliminated the piston failures, while providing the production platform with several percent more capacity than was achievable with the original OEM cylinder configuration.

Case History 5: Increasing Compressor Efficiency and Throughput

A single-stage, gas engine driven, Dresser Rand 6HOS-6 compressor was applied in natural gas pipeline service. The operating conditions of the pipeline were such that the engine driver was fully loaded making it the limiting factor for throughput of the compressor station. Performance tests of the original OEM cylinders, which were misapplied, showed that valve losses were very high for the low ratio application because of insufficient valve sizes and gas passages in the OEM cylinders being used on the frame. New 10.5 in. (266.7 mm) bore, 6.0 in. (152.4 mm) stroke, 1200 psig (82.7 bar) bolt-in replacement cylinder assemblies were designed with larger valves and generous internal gas passages. As shown in Figure 13-12, the new cylinders were installed in place of the original cylinders in less than two days, maintaining all existing process piping connections and mounting. Performance tests of



BELOW: Figure 13-11.

New 21.0 inc. (533.4 mm) bolt-in 1st stage replacement cylinders with manual variable volume clearance pockets.








Figure 13-12. The first of six new high-efficiency bolt-in replacement cylinders [left] is installed on a six-throw, single-stage D-R 6HOS-6 frame. Two of the original OEM cylinders are shown on adjacent throws [right] prior to replacement.

the new cylinders showed an efficiency gain of about 10%, bettering the guarantee of 8% and leading to a corresponding 10% throughput gain for the compressor station.

Case History 6: Increasing Cylinder Working Pressure

A USA natural gas storage facility had a requirement for increased operating pressure. The compression was provided by four Cooper Bessemer GMVA-10 integral engine compressors each having four older style vertically-split valve-in-head cylinders. The OEM, as well as the author's company, was asked to re-rate the original cylinders; however with large gasketed joints as shown in Figure 13-13, the cylinders were only marginally adequate for their original pressure rating and therefore incapable of further uprating. The OEM offered new higher-pressure cylinders, however, they would require major modifications to the ASME coded pulsation bottles and process piping, greatly increasing

the cost and the installation time for the project. The author's company measured critical interface dimensions on site without removing the old cylinders and then designed new 12.0 in. (304.8 mm) bore, 14.0 in. (355.6 mm) stroke, 1200 psig (82.7 bar) ASTM A395 cast ductile iron bolt-in replacement cylinders as shown in Figure 13-14. The design was able to accommodate the use of the original double deck valves, packing cases and automatic fixed volume clearance pockets. As the new cylinders were completed, the original valves, packing, and pockets were reconditioned, and the valve pocket volume bottles were re-rated for the higher working pressure. The field conversion went smoothly and the customer's facility was available, on schedule, to handle the higher operating pressure.

Another USA natural gas storage facility required increased operating pressure. The facility had five 1940s vintage Cooper Bessemer GMV compressors with valve-in-head cylinders. As shown in Figure 13-15, the original cylinders had two separate suction and two separate discharge connections, and the cylinders were vertically split so that the outboard suction and discharge flange connections had to be disturbed whenever it was necessary to access the piston, rod or packing for maintenance. Although the OEM indicated that a modest pressure re-rate of the cylinders might be possible, the station operators were concerned about the safety since the existing cylinders sometimes had gasket leakage problems at the original pressure rating. They wanted to avoid any gas piping or pulsation bottle changes and they wanted higher pressure cylinders that eliminated the problematic gaskets and the cumbersome and costly maintenance procedures that required disturbing gas piping connections to access the cylinder bore. In order to meet this challenge, a special valve-in-barrel cylinder design was developed, and 20 new 7.0 in. (177.8 mm) bore, 14.0 in. (355.6 mm) stroke, 2000 psig (137.9 bar) ASTM A395 cast ductile iron, jacketed, cylinders were manufactured and installed on the existing compressors as shown in Figure 13-16. Valves, packing and unloaders were reconditioned and reused in the new cylinders.

Case History 8: Emergency Replacement of Obsolete Cylinders

A chemical plant had an emergency when a critical Pennsylvania ATP off gas compressor unexpectedly developed internal process gas leaks into the cooling water jacket. The OEM no longer had the original cylinder body pattern, so their lead time for a new cylinder approached



Figure 13-13. Original OEM 1100 psig (75.8 bar) valve-in head type cylinders.




Figure 13-14. New custom engineered 1200 psig (82.7 bar) bolt-in replacement valve-in-barrel type cylinders.




Figure 13-15. Original problematic valve-in-head cylinders required disturbing the outboard piping connections to access the piston, piston rod and packing.




Figure 13-16. New bolt-in replacement valve-in-barrel cylinders reused original valves, packing and cylinder unloaders. Piping connections are no longer disturbed for piston, rod, and packing maintenance.

one year. Since loss of this compressor required shutting down the entire plant, emergency temporary repairs were made to the cylinder, and the author's company was contacted to provide a new cylinder. Critical interface measurements were made on site, and a new design 20.5 in. (520.7 mm), 11.0 in. (279.4 mm) stroke, 150 psig (10.3 bar) cylinder was expedited from ASTM A395 cast ductile iron to strengthen the weak, corrosion sensitive sections. The new cylinder was delivered in only 20 weeks, including the time for design, pattern construction, casting, machining, hydrostatic testing and installation of a new ni-resist liner (Figures 13-17 & 13-18).

Case History 9: Extending OEM Standard Cylinder Offerings

An upstream production company had a relatively new Ariel JGJ/6 compressor used for acid gas injection to stimulate oil production. The 600 hp (447 kW), 1500 rpm compressor was originally configured as a 5 stage unit. Once the field was operating, however, it became evident that production could be enhanced by increasing the injection pressure to a level that exceeded the capability of the compressor as originally configured. It was determined that a 6th compressor stage was required, but the OEM did not have a suitable high-pressure cylinder for that



Figure 13-17. Liner installation.



Figure 13-18. Finished cylinder.

particular frame.

In addition, the aggressive nature of the acid gas required the use of material produced to NACE specifications; and the limited physical size constraints required a higher material strength than could be achieved with the use of reduced hardness alloy steels. 17-4PH stainless steel was therefore the material of choice for the new cylinder. With the approval of the OEM, the author's company designed and manufactured a special 2.75 in. (69.9 mm) bore, 3.5 in. (88.9 mm) stroke, 3000 psig (206.8 bar) cylinder. The tail rod design, which is shown in Figure 13-19, was completely machined from a solid 17-4PH double H1150 heat treated stainless steel forging. This cylinder was added to the original compressor as a 6th stage to increase final injection pressure.

Case History 10: Filling gaps in OEM Standard Cylinder Offerings

A distributor packager of new Gardner Denver and remanufactured Joy 7.0 in. (177.8 mm) stroke high-pressure air compressors used in portable diesel engine driven compressor packages for the rotary drilling industry was encountering application conditions for which the OEM cylinders were not optimally suited. Given the maturity of the compressor product line, the OEM was not very interested in modifying the existing cylinder designs or creating new cylinder designs.

The author's company reviewed the range of required application conditions, measured the mounting interface dimensions, and subsequently developed a family of new 7.0 in. (177.8 mm) cylinders that fit the compact vee-type Joy and Gardner Denver compressor frames and that were optimally sized for the air drilling application requirements.




Figure 13-19. Special 3000 psig (206.8 bar) 17-4PH stainless steel tail rod cylinder designed for acid gas injection service.

The bore sizes of the ASTM A395 cast ductile iron, jacketed cylinders, ranged from 3.5 to 4.5 in. (88.9 to 114.3 mm) with a working pressure of 2500 psig (172.4 bar). Cylinders are now supplied on a regular basis to meet this distributor packager's needs, and additional bore sizes are being considered to further expand the range of pressures and flow rates offered to meet the needs of the drilling market as shown in Figure 13-20.

Many more examples can be provided, however, the forgoing list shows the various kinds of applications for which new custom engineered, purpose built reciprocating compressor cylinders can be attractive alternatives for optimizing and revitalizing existing compression assets.

RE-APPLIED COMPRESSOR CYLINDERS

Although new, custom engineered and purpose-built cylinders can provide optimal performance and reliability, there are frequent




Figure 13-20. 2500 psig (172.4 bar) cylinder family developed to fill a gap in the OEM's offerings for high-pressure air drilling service.

examples where surplus or previously decommissioned cylinders can be reconditioned and reapplied onto existing compressor frames. New OEM cylinders can also be installed on different OEM frames that have similar strokes and rod diameters. Of course, diligent and experienced engineering design is required to match the different mounting, bolting, piston rod and, if the stroke is different, the piston. Consideration must also be given to matching reciprocating weights with the compressor frame's capability. Maximum pressure ratings, Internal gas and inertia rod load ratings, and pin reversal requirements must be considered in the reapplication as well. Done properly, reapplication of cylinders is a reliable alternative that can often reduce the capital cost and will almost always reduce the cylinder lead time. Several examples demonstrate the potential of this engineered approach.

Case History 11: Adapting Remanufactured Cylinders to An Existing Compressor

A natural gas pipeline transmission station had two 1950s vintage I-R KVG 10/3 integral engine compressors in service. Although having a provision for three compressor throws, only two of the throws were previously equipped with cylinders, the center throw being unused for more than 50 years. Conditions had changed over that period of time so that the 600 hp (447 kW), 330 rpm compressors were no longer fully loaded. The pipeline operator had determined that, by adding another identical cylinder to the inactive throw in parallel with the existing cylinders in a single-stage configuration, the engine could be fully loaded to increase the station's capacity. Inquiries were made to the OEM and several other companies. The OEM still had the original pattern and was able to quote new identical cylinders, however lead time for that option was about 40 weeks. The author's company also offered to design and manufacture new bolt-in replacement cylinders, however, the best possible lead time was 26 weeks. Neither of these alternatives were adequate for the operator's requirement to have the conversion completed so that both compressors would be in service within no more than 20 weeks after the release of the order. An extensive search for identical used or surplus cylinders produced no results either, although the author's company was able to find two similar 15.0 in. (381 mm) stroke I-R process cylinders, Figure 13-21, that had the same flanges and distance between flanges. It was determined that with modifications to the combination crank end head and distance piece, the process cylinders

could be adapted to fit the existing KVG compressors. A performance model, Figure 13-22, showed that the cylinders would meet the required operating conditions if all cylinders were modified by lining to a 10.16 in. (258.1 mm) bore diameter.

Having no time to lose, two used cylinders were purchased and taken to the factory for cleaning, inspection and hydrostatic testing to confirm that the cylinder bodies were sound. The cylinders were then modified to fully restore all fit dimensions, sealing surfaces and threads to ensure their integrity for the reapplication. All new bolting, seals and gaskets were installed. After machining, a second hydrostatic test of the remanufactured cylinders was conducted at 1.5 times maximum working pressure, as shown in Figure 13-23. Concurrent with the completion of the "new" remanufactured cylinders, new liners, non-lube piston and rod assemblies, double deck poppet valves, valve cages, valve caps, outer end automatic fixed volume clearance pocket heads, and highly efficient radial poppet suction valve deactivators were designed and manufactured for the four existing cylinders on the two compressors as well as for the two remanufactured cylinders. A complete API 618 design approach 2 pulsation study was also conducted on the entire system




Figure 13-21. One of two used I-R cylinders prior to the remanufacturing process.




Figure 13-22. Performance model for 3-cylinder, single-stage I-R compressor showing all load steps required for system flexibility without overloading at the maximum specified discharge pressure.

with the new configuration. This study revealed high pressure drops in the existing plant suction pulsation control arrangement with the higher flow, three cylinder configuration, and mitigating actions were quickly identified and added to the conversion plan.

When all components and cylinder assemblies were completed, the station was taken off line for the conversion. The suction and discharge bottles were removed and taken to an ASME code welding shop for addition of the incremental connections, followed by recertification. Some simple piping modifications were also made to mitigate the pressure drop problem that had been revealed by the pulsation study. Using special field machining equipment, the existing liners were machined out of the existing cylinders without removing them from the compressor. New liners and the other new components were then installed along with the incremental remanufactured cylinders. The revised bottles were reinstalled and the system was completed and commissioned on schedule. One of the completed units is shown in Figure 13-24. At this time the compressors have been in service for over 3 years.




Figure 13-23. Remanufactured cylinders with new fixed volume clearance pocket heads and valve caps undergoing an 8-hr factory hydrostatic test.



Figure 13-24. One of two reconfigured KVG units after adding a 10.16 in. (258.1 mm) diameter remanufactured cylinder [center] and adding new clearance pockets, radial poppet suction valve deactivators, and other new components to all the cylinders.

Case History 12: Mixing Used OEM Cylinders and Frames to Optimize Performance

A natural gas processing plant wanted to reapply an existing 2000 hp (1491 kW), 900 rpm gas engine and compressor package for a propane refrigeration process. Process conditions were fixed, so that cylinders had to be carefully selected to match the operating requirements. Using the preferred 6.0 in. (152 mm) stroke Superior WH64 compressor frame, initial performance sizing resulted in a selection of 25.5 in. (648 mm) diameter Superior cylinders for both the 1st and 2nd stages, however the 2nd stage cylinders would have had to operate very close to their working pressure limit. The same concern existed for the 20.0 in. (508 mm) 3rd stage cylinder. The OEM was not interested in producing special cylinders for a single unit, and no used cylinders with an adequate working pressure could be found.

As a result, a new 6.5 in. (165 mm) stroke Ariel JGC/4 compressor was considered, but this resulted in concern about the reliability of the valves with the heavy propane gas. Switching to a 5.5 in. (140 mm) stroke Ariel JGD/4 compressor made the valve reliability more promising, but it could not produce the required flow with the available standard Ariel cylinders. It was finally determined that the solution could be optimized by adapting Ariel JGD cylinders to fit on the Superior WH64 compressor frame. Ariel 22.0 in. (559 mm) diameter JGD cylinders were selected for the 1st stage and the two 2nd stage cylinders, and an Ariel 19.625 in. (499 mm) diameter JGD cylinder was selected for the 3rd stage. Used Ariel cylinders were found that could be reconditioned for all but one of the four that were required, however since the JGD cylinders are designed for a 5.5 in. (140 mm) stroke, their use on the Superior frame required redesigning the piston and piston rod to accommodate the longer stroke. In addition, special mounting adapters were required to match the different bolt patterns on the cylinders and the frame, as shown in Figure 13-25. The author's company provided the special engineered components to accomplish this adaptation. At this time, the unit, shown in Figure 13-26, has been in service for approximately 3 years.

Case History 13: Extending Obsolete Compressor Life with New OEM Cylinders

A natural gas production company had an obsolete 6.0 in. (152.4 mm) stroke Knight KOCA-2 compressor frame with fabricated (welded) steel cylinders, as shown in Figure 13-27. The cylinders were susceptible




Figure 13-25. Adaptation of 5.5 in. (140 mm) stroke Ariel cylinders to a Superior 6.0 in. (152 m) stroke Superior compressor frame.



Figure 13-26. 2000 hp (1491 kW), 900 rpm, gas engine driven 3-stage propane refrigeration compressor.

to cracking problems in service and were no longer safely repairable. The original compressor OEM had been out of business for more than two decades, so neither new nor repairable used cylinders were realistic alternatives. Lead time for new compressor packages was close to 52 weeks and production losses would be substantial if the compressor could not be returned to service in a much shorted time. The author's company was asked to evaluate alternatives. Although new custom engineered cylinders were an option, lead time was still somewhat longer than desirable, considering the cost of lost production. A much shorter lead time was possible by adapting new Ariel JGK cylinders to the KOCA frame. As long as changes were going to have to be made to the cylinders, bottles and piping anyway, the producer decided that it would be desirable to optimize the compression system to accommodate an anticipated suction pressure decline over time, while still utilizing as much of the gas engine driver power as practical to deliver flow. This ultimately required converting from a single-stage to a 2-stage configuration with 8.375 in. (212.7 mm) and 6.25 in. (158.7 mm) bore cylinders, which provided optimal coverage of the operating conditions and maximum driver power utilization as shown in Figure 13-28. Even more importantly in this case, the solution could be implemented in less than 20 weeks time.

New 5.5 in. (139.7 mm) stroke Ariel cylinders were converted to 6.0 in. (152.4 mm) stroke with new custom-engineered piston and rod assemblies, rod packing and wiper assemblies, and mounting adapters to match the KOCA frame. New ASME coded pulsation bottles were also designed and manufactured, as shown in Figure 13-29, and piping modifications were made to adapt to the original skid and utilize the process gas cooler. An API 618 Design Approach 2 pulsation study was conducted, and the system piping design was tuned to provide effective pulsation control over the broad operating range. The unit was been in service for more than two years, and additional units are now being considered for similar conversions.

Case History 14: Completely Reconfiguring an Existing Compressor

An existing 600 hp (447kw), 588 rpm, 4-throw, 3-stage, 7 in. (177.8 mm) stroke Joy WB14 compressor was originally configured as shown in Figure 13-30 to compress 1303 cfm (42.5 m3/min) of bone dry nitrogen. Requirements changed such that only 314 cfm (10.3 m3/min) was required. The cost of recycling 76% of the flow was not acceptable, but



Figure 13-27. Obsolete KOCA-2 compressor prior to conversion.




Figure 13-28. Loading map for new 2-stage configuration.



Figure 13-29: Obsolete KOCA/2 frame with new Ariel cylinders applied.

the cost of a complete new, but smaller, machine was equally difficult to justify. The owner/operator wanted to reconfigure the existing compressor at minimal cost to operate more efficiently at the lower flow rate. In order to evaluate possible alternatives, a complete performance model was developed for the existing configuration having two 16.0 in. (406.4 mm), one 10.5 in. (266.7 mm) and one 7.0 in. (177.8 mm) cylinders. The model was then revised in an iterative manner to evolve a solution that let replacing the two 1st stage cylinders with reconditioned used 8.0 in. (203.2 mm) cylinders, moving the original 7.0 in. (177.8 mm) 3rd stage cylinder to the 2nd stage, and installing a reconditioned used 4.0 in. (101.6 mm) cylinder on the 3rd stage. The bottles were modified with new flanges to adapt to the smaller cylinders. Most of the existing piping was reused by adding adapter sections.

By reconfiguring the compressor with reconditioned used cylinders and reapplying one of the existing cylinders, as shown in Figure 13-31, this solution provided a cost effective solution that saved significant operating cost and preserved the original investment of the compressor frame, motor and the balance of the system.



Figure 13-30: Prior to reconfiguring, this oversized 3-stage Joy WB14 nitrogen compressor required 76% of the flow to be recycled.



Figure 13-31: The reconfigured unit was sized to meet the process requirements without significant recycled flow.

COMPRESSOR OPTIMIZATION AND AUTOMATION WITH CUSTOMIZED UNLOADING DEVICES

In addition to hundreds of successful examples of custom designed new cylinders and countless innovative adaptations and reapplications of new and used OEM cylinders, there are even more examples of compressor optimization with automatically actuated devices, often called unloaders, that control the load and flow.

Case History 15: Automation of Propane Refrigeration Compressor

A natural gas processing plant used a 400 hp (298 kW) Ajax compressor with no automatic control. The 2-stage, 2-throw unit served as the low-pressure stage of a multi-unit propane refrigeration system. As ambient conditions changed, the propane boil-off rate varied, necessitating manual adjustments of the compressor's clearance pockets. Since the unit was not attended 24/7, the operators kept the unit under-unloaded so that it could handle upsets without shutting down. Unexpected shutdowns stopped the liquid stripping process and led to serious problems downstream from the gas plant.

The solution involved the combination of a discrete step unloader and an infinitely variable unloader providing, in essence, infinite variability over a broad range of operating conditions, as shown in Figure 13-32. This gave the plant maximum compressor loading (and maximum plant refrigeration and liquid stripping capacity) without the risk of unexpected shutdowns.

The compressor conversion involved installing a hydraulically actuated head end variable volume clearance pocket on the 1st stage cylinder along with a pneumatically actuated fixed volume clearance pocket on the head end of the 2nd stage cylinder as shown in Figure 13-33. The control pressure for the hydraulically actuated variable volume unloader was provided by the use of discharge pressure acting on an external accumulator containing hydraulic fluid separated by a bladder. This approach eliminated the need for separate pumps and power requirements. The control pressure for the fixed volume pocket was provide by plant air pressure.

Control algorithms, that were derived from a robust reciprocating compressor performance modeling program developed by the author's company, were programmed into a PLC, which then automatically controlled the unit with the two unloaders. The conversion required about




Figure 13-32. Fine unloading steps for a wide range of operating conditions are provided by a combination of fixed and variable unloaders.




Figure 13-33. New automatic clearance pockets added to propane refrigeration compressor.

two days of installation time, and it has been operating continually for more than 3 years.

Case History 16: Pipeline Compressor Automation

A pipeline operator required the reapplication of five large Clark TCV-12 and TLA-6 19.0 in. (483 mm) stroke integral engine compressors. An increased range of pressure ratios required a reduction of existing fixed clearance. The budget was tight and required reusing as much of the existing hardware as possible. The author's company modeled the compressor performance and developed an optimum unloading configuration. The front and rear heads and liner ports were reconfigured to reduce the cylinder fixed clearance. The large 14.0 in. (355.6 mm) diameter cylinders were lined down to 12.5 in. (317.5 mm). The compressor valves were redesigned to maximize the lift area and minimize fixed clearance. A total of 116 fixed volume clearance pocket unloaders having volumes of 150 in3, 300 in3, 600 in3, or1500 in³ (2.5, 4.9,9.8 or 24.6 L) provided the flexibility necessary to meet the wide range of compression ratios associated with the new application. Novel piston designs permitted the use of existing piston rods while pro-viding piston to rod attachment features that resulted in easier and safer assembly techniques. The revamped units, shown in Figure 13-34, provided the required performance, which was more flexible and reliable than the OEM's offering.




Figure 13-33. One of five large 19.0 in. (483 mm) stroke integral engine compressors that were completely configured for automatic operation with a broad range of pressure ratios.

Case History 17: Replacement of Variable Speed Engine with Synchronous Electric Drive

A natural gas producer had a 2-throw, 2-stage Superior W-72 reciprocating compressor driven by a 1600 hp (1193 kW), 900 rpm gas engine that had become obsolete, was inefficient and was expensive to maintain. In addition, due to local air quality restrictions, and electric motor drive was considered as a preferred replacement for the engine drive. The primary mode of flow control was via speed control on the engine, which provided a high level of flexibility. However the operator did not want the complexity or cost of a variable frequency electric motor drive. Use of a constant speed, synchronous motor drive, then, appeared to be impractical for the application that had to have a wide range of flow control capability. The author's company was requested to propose unloading equipment that would provide optimal flexibility at reasonable cost. After weighing various options, the preferred solution involved simply replacing the outer heads of each compressor cylinder and adding plug-type suction valve deactivators to the head ends of both cylinders. As shown in Figure 13-35, the new 1st stage head was configured with a custom engineered design having 3 different clearance pockets of 73, 146 and 292 in³ (1.2, 2.4 and 4.8 L) respectively.



Figure 13-35. Twothrow compressor speed with multiple clearance pockets on each compressor cylinder head end.

The 2nd stage head was configured with a custom engineered design having 2 identical clearance pockets of 170 in³ (2.8 L). Each pocket was controlled with its own integral pneumatic actuator that was controlled by a PLC control panel mounted on the compressor package. Together with the two sets of head end suction valve deactivators, this arrangement resulted in 31 discrete load steps that provided the very fine control shown in Figure 13-36. As shown, the arrangement actually provided about 36% more turndown capability than the original variable speed drive.

Case History 18: Automation of Field Gas Gathering Compressors

A U.S.A. Appalachian natural gas producer was operating three 2-stage Ajax DPC-600 compressors. Suction pressure swings lead to the units shutting down to prevent overloading, thus reducing each unit's run time and requiring personnel to travel out to the remote units to restart them. The operator therefore had been running the units conser-




Figure 13-36. The multiple pocket unloaders, together with valve deactivators on the two head ends, provided more flexibility with a synchronous motor drive than the same compressor had with a 33% speed turn down.

vatively in order to accommodate the pressure swings without shutting down, however that resulted in less overall production.

An engineering study was commissioned to evaluate the compressor configuration to identify the best means for operating each unit via automatic control and unloading to cover the entire operating range. Goals were to keep the engines running safely as field condition changed, and also to increase capacity during normal operation to minimize the number of units that had to be operated at any time. Various alternatives were evaluated including a single 685 in³ (11.2 L) fixed volume pocket; parallel 192 and 383 in³ (3.1 and 6.3 L) fixed volume pockets; parallel 114, 228, and 342 in³ (1.9, 3.7 and 5.6 L) fixed volume pockets, and an automatic variable volume pocket. In order to evaluate the alternative solutions, performance was compared at more than 1000 operating points within the operating range noted in Figure 13-38. The highest flow possible at each point was plotted for each case at each condition and the curves were overlayed for comparison. Over




Figure 13-38. Two-throw compressor speed with multiple clearance pockets on each compressor cylinder head end.



Figure 13-39. 3-volume clearance pocket unloader.

the range of 160 to 240 psig (11.0 to 15.5 bar) suction and 900 to 1000 psig (62.1 to 69.0 bar) discharge, the highest average flow was possible with the automatic variable volume pocket, however, the 3-volume pocket (the 2nd from the top surface in Figure 13-38) provided average flow that was within 1% of the variable pocket (top surface). The 3-pocket heads, Figure 13-39, were also slightly lower in cost and significantly easier to control. This solution was also a more practical alternative for a remote field application with limited technical support and maintenance available.

SUMMARY

The list of examples can go on and on, but the foregoing case histories provide a range of good examples. Optimization and revitalization has been successful on compressors used in air drilling, nitrogen, air procession, air separation, chemical processing, field gas gathering, gas boosting, gas lift (EOR), gas transmission, gas injection and withdrawal, refinery, refrigeration and specialty applications. Virtually any size and model can be considered for improvements, whether or not the com-


pressors are currently supported by OEMs or are obsolete. Experience includes Ajax, Alley, Ariel, Chicago Pneumatic, Clark, Cooper-Bessemer, Dresser-Rand, Delaval, Enterprise, Gardner Denver, GE Gemini, Hurricane, Joy, Knight, Neuman Esser, Norwalk, Penn Process, Superior, Thomassen, and Worthington.

Acknowledgement

The author acknowledges the legacy provided by many decades of technical leadership, innovation and dedication of respected industry experts William Hartwick, Richard Deminski, Edward Miller, and Richard Doup, as well as the ongoing contributions of Chad Brahler, Dwayne Hickman, Charles Wiseman, Larry Burnett and their capable teams.

References

- Brahler, C.D.; Hickman, D.A. & Shade, W.N., Performance Control of Reciprocating Compressors - Devices for Managing Load and Flow, Gas Machinery Conference, Albuquerque, NM, Oct. 7, 2008.
- Brahler, C.D. & Schadler, H.C., One Compressor OEM May Not Have the Optimum Equipment Selection, Gas Machinery Conference, Dallas, TX, Oct. 1, 2007.
- 3. Harbert, P.; Hickman, D.; Mathai, G., & Miller, R., An Automation Method for Optimizing and Controlling A Reciprocating Compressor Using Load Step, Speed and Suction Pressure Control, Gas Machinery Conference, Dallas, TX, Oct. 2, 2007.
- Shade, W.N., Custom Engineered High-Performance Cylinders Revitalize Existing Compressor Assets, GMC Today, Oct. 4, 2004.
- Shade, W.N., DCP Midstream Upgrades LaGloria Gas Plant, COMPRESSORTech-Two, Oct. 2007.
- Shade, W.N., Modern Replacements for Old Valve-In-Head Compressor Cylinders, GMC Today, Oct. 2, 2007.
- Shade, W.N., Re-Engineering Extends the Utilization of Pipeline Compressor Assets, GMC Today, Oct. 3, 2006.



Chapter 14

Piston Rod Run-out is a Key Criterion for Recip Compressors

-Gordon Ruoff

INTRODUCTION

Proper assembly, installation and maintenance are the keys to compressor efficiency and life. And the major key is piston rod runout. Even though the compressor may have been test run at the factory, piston rod run-out must be rechecked on site as part of the compressor installation. Thereafter, any time the piston or rod is serviced, rod runout must be checked. This paper established the criterion for rod run-out and was included in API "Standard 618 Reciprocating Compressors for Petroleum, Chemical, and Gas Industry Services", Appendix C.

This article, published on October 12, 1981 was provided courtesy of *Oil & Gas Journal*. The article was written by Gordon Ruoff.

Piston rod run-out is a criterion used by engineers and operating personnel to determine piston-rod alignment in relation to cylinder and crosshead alignment on horizontal reciprocating compressors. Stringent rod run-out requirements are frequently part of the purchase specifications for reciprocating compressors.

Factory witness of a rod run-out check is often a requirement of the inspection of a new compressor. Rod run-out is usually always checked as a part of normal recip compressor maintenance, especially after overhaul and reassembly of the gas ends.

HORIZONAL RUN-OUT

Horizontal rod run-out readings can be used as a direct indication of horizontal alignment from the crosshead through the distance pieces



Figure 14-1.

to the cylinder. Horizontal rod run-out is measured by placing a dial indicator pickup on the side of the rod.

For perfect alignment, the indicator should read zero as the rod is moved through the length of the stroke. Variations of ± 0.00015 in./in. of stroke are usually considered acceptable.

Horizontal rod run-out should be the same whether the unit is cold or hot. Excessive horizontal rod run-out is corrected by realignment of components involved. This may include cylinders, heads, distance pieces, crossheads, crosshead guides, rod, and piston. Squareness of rod threads relative to piston-rod nut threads and face and crosshead threads and face is a critical factor.

VERTICAL RUN-OUT

Normal expected cold vertical rod run-out is not an indication of misalignment. For perfect alignment, it is the result of the difference between the normal cold running clearance of the piston to bore and the crosshead-to-crosshead guide, which in large cylinders causes the piston




Figure 14-2. Basic geometry of cold vertical rod run-out (As measured by a dial indicator during a manual bar-over)

centerline to lay below the crosshead centerline. This basic geometry is illustrated in Figure 14-2.

Note that the piston and crosshead centerlines lay below the perfect alignment centerline by one half of the running clearances. In cylinders where the running clearance is greater (or less) than the crosshead running clearance, the piston will lay below (or above) the crosshead centerline by one half the difference in the cold running clearances.

The result is normal critical rod run-out. For purpose of calculating normal vertical rod run-out, this one-half clearance difference is designated as the differential drop (Δ drop).

From Figure 14-3, it can be seen that the vertical rod run-out had a direct relationship between these normal running clearances, Δ drop, rod length, and stroke. This creates a nearly proportional right-triangle situation such that the normal expected cold vertical run-out can be calculated with sufficient accuracy when these values are known.

Vertical rod run-out is measured by placing a dial indicator on the top or bottom of the rod. As the rod is moved through the entire stroke length, it will "run-out" by an amount equal to the ratio of the stroke-to-rod length times the Δ drop, i.e., half the difference between the running clearances (Figure 14-3).

It is generally desirable that the measured vertical cold rod run-out




Figure 14-3. Vertical rod run-out relationships.

be within the calculated value (for the involved cylinder and crosshead clearances, rod length, and stroke) by ± 0.00015 in./in. of stroke. Any amount of rod run-out outside of these limits may indicate some misalignment.

While it may be thought by some that "zero" vertical cold rod run-out is highly desirable and is a sign of perfection, it may actually be an indication of some misalignment, particularly at the time of new unit assembly where large nonlube cylinders with aluminum pistons and Teflon rider rings are involved. It is necessary, in fact, to consider the run-out at both ambient and normal operating temperatures.

NORMAL RUN-OUT

For large cylinders with aluminum pistons and Teflon rider rings, there can be a significant difference between the normal cold rod run-out and the run-out at normal operating temperatures. This is due to the high expansion rate of the aluminum piston and Teflon rider rings which can make a significant difference in the differential clearance between the piston and the crosshead.

On the other hand, there may be operating conditions with low suction temperatures such that normal operating temperatures may be no

greater than the ambient temperature upon which the normal expected cold vertical rod run-out is based. These situations must be given special consideration with the cold rod run-out adjusted accordingly.

ACCEPTABLE VERTICAL RUN-OUT

What is an acceptable vertical rod run-out figure? API-618 2nd Edition requires 0.00015 in./in. of stroke at normal operating temperatures. Although this figure is deemed by most manufacturers as being too stringent, especially where large cylinders are involved, it can usually be accomplished by shim adjustment of the crosshead shoes. Shim adjustment must be made on the determination of both the normal expected cold rod run-out and the expected run-out at the normal operating temperatures.

A thorough study of the figures and readings is required to determine what adjustments, if any, are needed to obtain the desired run-out at operating temperatures. It is felt by some that 0.001 to 0.002 in./in. of stoke may be perfectly acceptable for normal operating vertical run-out, especially where large cylinders are involved. This amount of run-out creates just enough movement in the packing rings to keep them from sticking in cups, especially in dirty gas applications.

Where there is much concern about rod run-out, each application needs to be studied carefully to make the right decision and proper adjustment. There are many compressors operating successfully with the higher rod run-out figures.

MEASURING ROD RUN-OUT

With regard to vertical rod run-out, some clarification of positive and negative magnitude is needed. Rod run-out should always be measured starting with the rod at the extreme end of the stroke.

If the rod is all the way "back," i.e., with the piston at the crank end of the cylinder, and the dial indicator placed on top of the rod at the 12 o'clock position and set at zero as in Figure 14-3, when the rod is stroked "forward," i.e., out toward the head end, the indicator will read positive, indicating that the rod is sloping downward from the crosshead to the piston as shown in the illustration. (If the indicator

is placed on the bottom of the rod at the 6 o'clock position, it would read negative.) This is the normal situation encountered where cylinder clearance exceeds crosshead clearance.

If the rod is all the way out (piston to head end) and the indicator is set at zero, then it will read negative as the rod is stroked "back." This negative reading in this direction still indicates the rod is sloping "downward," as does the positive reading obtained when the rod is stroked outward during the reading.

To avoid confusion, it is suggested that all rod run-out readings be taken on a forward stroke with the dial indicator set at zero when the rod is all the way back. On multithrow units, this is important so that relative readings among the throws can be properly compared and evaluated.

CORRECTING VERTICAL RUN-OUT

Vertical rod run-out should never be adjusted or corrected by forcing the cylinder and/or distance piece up or down by use of support adjusting screws. This can put excessive forces and stresses on the components involved. Cylinder alignment and cylinder level at both cold and normal operating temperature conditions should be determined and adjusted so that components will be free of harmful stresses at normal operating temperatures. Then rod run-out should be checked and corrected if necessary.

If alignment is determined to be basically correct, and it is decided that some adjustment to the normal vertical rod run-out is absolutely necessary, this can be done by means of shims under the crosshead shoes, e.g., taking shims from the bottom shoe and placing them under the top shoe drops the centerline further below the perfect alignment centerline while maintaining the same running clearance. This decreases the Δ drop and thus decreases the positive rod run-out.

Once crosshead shims have been shuffled to adjust rod run-out, it is important to always install the crosshead "top" side up following removal for maintenance.

Sometimes much effort and cost is expended uselessly to obtain the required API-618 rod run-out limit of 0.00015 in./in. of stroke, especially when adjustments are made to reduce the normal expected rod run-out.

Take the case of a 24-in. nonlube cylinder on a 9-in. stroke compres-

sor where the normal vertical cold rod run-out would be about 0.006 in. with a 60-in. long rod and about 0.0045 in. with an 80-in. long rod (cylinder running clearance is 0.090 in. and crosshead running clearance is 0.012 in., making Δ drop equal to (0.090-0.012)/2 or 0.039 in.

If rod run-out is adjusted to zero when cold, it will be about a negative 0.003 in. when hot, i.e., it will be laying upward, instead of downward as shown in Figure 14-3.

However, a 24-in. nonlube piston has a rider ring design with about 0.060 in. of allowable wear built into it. Over time, as the rider ring wears, the piston will drop below the centerline of the crosshead by the amount of the allowable wear. Thus, when it is time to replace the rider rings, rod run-out will be about 0.009 in. with the 60-in.-long rod.

If periodic crosshead shim adjustments have been made in an attempt to keep rod run-out at or near zero, then all the shims that were changed must be put back in their original positions. To do this is unnecessary and costly in relation to any benefits gained. Further, vertical rod run-out that is set precisely at the factory with much time and effort usually has to be readjusted in the field after shipment and handling.

EVALUATING VERTICAL RUN-OUT

In evaluating vertical rod run-out, normal rod sag may occasionally have to be taken into account. Consider a 9-in. stroke cylinder end with a 1-3/4 in. diameter rod with a length of 70 in. between crosshead and piston (cylinder end uses a double distance piece arrangement between crosshead guide and cylinder, resulting in a long rod).

If piston clearance is 0.040 in. and crosshead clearance is 0.020 in., the normal expected vertical rod run-out (from the formula of Figure 14-3) is (9/70)(1/2) (0.040-0.020) or about 0.001 in. ± 0.0014 in.

Considering normal sag, the maximum deflection is calculated from the formula $(5/384)(Wl^3El)$ for a beam supported at both ends. Assuming the rod to be steel with a weight of 8.17 lb/ft, E (modulus of elasticity) or 30×10^6 , and 1 (moment of inertia) of 0.40604; then:

normal sag = $(5/384) \times [(47.7 \times 70^3)/(30 \times 106 \times 0.4606)] = 0.0115$ in.

However, the projected straightline deflection is about 1.5 times the

calculated sag, or about 0.023 in. This is the figure that must be used to calculate the expected rod run-out relative to sag conditions (Figure 14-4). The effective rod length is now only 1/2 the full length or 35 in. Since short rods result in greater run-out, the effective run-out due to sag is "amplified."

With this sag condition, and with the piston and crosshead in perfect alignment, i.e., with no Δ drop, when an indicator is placed next to the crosshead, or next to the packing area (closest to the piston as possible) expected rod run-out due to sag will be 9/35 x 0.023, or about 0.006 in. This, of course, is a condition that cannot be readily corrected.

To determine if rod sag is contributing to what appears to be excessive rod run-out, an indicator placed on the rod next to the crosshead will result in a positive reading as the rod is stroked outward toward the headend, while another indicator next to the pressure packing will result in a negative reading during the same stroking.

An indicator placed on the rod at about its midpoint will result in little or no run-out reading.




Figure 14-4. Rod run-out relative to sag.

In reality, when the crosshead and piston are subject to rod sag they tend to lay in the crosshead guide and cylinder as shown exaggerated in Figure 5. During the outward stroke when the rod is in compression, the column effect creates even further "sag." Then when the stroke reverses and the rod is in tension it tends to straighten out. This sometimes causes the rod to appear to jump up and down when viewed in operation with the naked eye.

Instruments used to detect rod dynamics during actual operation sometimes record the reversal at the end of each stroke as a significant "jump." If a dial indicator is placed at the lowest point of rod sag during a bar-over test, the difference in deflection from rod compression to rod tension can often be seen, resulting from the frictional drag of the piston in the bore, especially if it is a large nonlube cylinder.

In summary, horizontal rod run-out should ideally be zero, with a variation of no more than ± 0.00015 in./in. of stroke. Excessive horizontal rod run-out can be an indication of misalignment.

Normal vertical rod run-out is not an indication of misalignment. Rather it is the result of the difference between the piston and crosshead running clearances, with its magnitude further affected by the length of the piston rod, and by the stroke. It needs to be calculated for each cylinder end. Normal variation from the calculated value should be within ± 0.00015 in./in. of stroke.

Some axioms relative to vertical rod run-out are as follows:

 The larger the cylinder and the more the running clearance, the more the run-out.




Figure 14-5. Crosshead and piston subjected to rod sag.

- The longer the stroke, the more the run-out.
- The longer the rod, the less the run-out.
- Short rod, long stroke = greater run-out.
- Long rod, short stroke = lesser run-out.
- The larger the cylinder, the longer the stroke, the shorter the rod = greater run-out.
- The smaller the cylinder, the shorter the stroke, the longer the rod = lesser run out.

There are many compressors successfully running with rod runouts that exceed any of the limits and parameters established above. In some rare cases rod sag may contribute to a misleading excessive run-out reading which cannot be improved by further alignment or crosshead adjustment

Rod run-out that is set precisely to stringent requirements at the factory with the expenditure of much time and effort usually has to be readjusted in the field after shipment, handling, and installation if the same precise run-out is required.

Chapter 15

Effect of Pulsation Bottle Design On the Performance of a Modern Low-speed Gas Transmission Compressor Piston

-Christine M. Gehri Ralph E. Harris, Ph.D. Southwest Research Institute

INTRODUCTION

Pulsation bottle design is typically thought of as a means to minimize harmonic responses in the suction and discharge piping. As this chapter shows, there is a lot more to pulsation bottle design. With proper design not only will harmonics be controlled but compressor efficiency will be improved.

This study was presented at the 2003 Gas Machinery Conference by Christine M. Gehri and Ralph E. Harris, Ph.D.

Dynamic pressure drop refers to the calculation of instantaneous pressure drop at each point through the crank rotation. The horsepower cost is computed by integrating the instantaneous pressure drop over a cylinder cycle. If the instantaneous velocity across a square law restriction is much higher than the mean velocity, then the cycle integrated horsepower cost will be much higher than the horsepower cost estimated by mean flow estimates. Field analyses have documented instances where dynamic pressure drop effects have incurred hundreds of excess horsepower and, in some cases, were so high as to inhibit full load op-

erations. In one such case, strong cylinder interactions combined with a significant pressure drop restriction downstream of the compressor cylinder valves resulted in excessive horsepower losses.

This paper presents a case study of a low-speed reciprocating compressor unit installed in a natural gas transmission service. Onsite testing following start-up indicated total losses of approximately 55 percent of the indicated horsepower while operating on the bottom load step at rated speed. Interim modifications to the existing primary suction and discharge pulsation bottles were made, which allowed the units to operate much more efficiently through the winter. Redesign of the primary pulsation bottles was necessary to further minimize cylinder interaction and the associated horsepower cost. Full documentation of the design process is presented in this paper, along with supporting field data.

INTRODUCTION

Bottle design is a key component in a successful compressor installation. Traditionally, bottle design focused on controlling pulsation levels, and ultimately vibration, through resonance avoidance. The majority of the low speed integral units installed in the US gas transmission industry were designed using analog technology. The analog approach focused on locating acoustic resonances outside of the normal operating speed range and limiting bottle unbalanced shaking forces to a target value. Empirical loading values, and not stress calculations, were key design parameters. The success of this approach is evident in the continued operation and long life of this compressor fleet. With traditional design tools, the effect of the bottle design on compressor performance is difficult to establish. Because of the linear nature of the solution, the role of valve performance and pulsation levels on the predicted pressure-volume cards was not accurately represented. Moreover, the effects of pressure drop through the bottle system were not reflected in the predicted horsepower, or any equivalent accounting in the design. Following installation, a bottle design was typically viewed as successful if it achieved acceptable vibration and compressor performance, as measured by cylinder performance testing.

It is very difficult to measure the impact of the pulsation bottle design on cylinder performance in the field. Although pulsation levels

are easily measured, differential pressure measurements between various locations in the bottle design or between the cylinder nozzle and header are not only unreliable, the values are difficult to interpret with regard to horsepower costs. Pressure drop through the cylinder valves and orifice pressure loss may show up as differential indicated pressure on the pressure-volume card, but through the bottle system, these losses are typically seen as a spread in the cylinder toe pressures. A survey of compressor efficiencies¹ in the installed base of integral units in the US gas transmission industry revealed a significant spread, as shown in Figure 1. This spread in efficiency represents a loss of pipeline capacity as well as excess fuel consumption. Given our improving ability to predict and understand the role of bottle design on compressor performance, a significant component to the observed spread must be attributed to pulsation bottle designs.

The increasing use of high-speed compression in various applications has prompted the development of design tools that better meet the demanding requirements of today's high-speed compressor packages. Pulsation bottle design, in particular, has taken on new challenges. Resonance avoidance on variable high-speed units is much more difficult to achieve, and resonance management is required. High-speed units have a more difficult time achieving traditional compressor performance efficiencies, and pulsation control through pressure drop can drive unit efficiencies down further.

Dynamic pressure drop refers to an increase in static pressure drop through a component or an entire system of pulsation control elements, resulting from pulsating flow. Because pressure drop is proportional to the square of the velocity through an element, dynamic flow results in more pressure drop on the swings above the mean flow than is saved on the portion of flow below the mean flow value. When acoustic resonances are involved, the dynamic flow can be significant and produce surprisingly large horsepower losses. Since the compressor is the prime mover of the gas, these dynamic pressure losses are reflected in the horsepower consumed by the compressor cylinder and seen in the pressure-volume cards. With the ongoing transition to digital acoustic analysis, calculation of dynamic pressure drop can be automated into the design process of future systems. However, the large body of existing compressors may benefit from reevaluation of the pulsation control system, particularly when electric drives are involved or capacity limitations have been met.

COMPRESS OR EFFICIENCY SURVEY - Data Set His togram in Percentage




Figure 15-1. Efficiency Survey in the Installed Base of Integral Units in the US Gas Transmission Industry.

CASE STUDY 1

Figure 2 is a photograph of a Cooper GMW330 installed in 1996 at the Enterprise Compressor Station operated by Southern Natural Gas Company. This is one of the last low-speed integrals installed in the US gas transmission industry. The unit is rated at 3,920 HP and has two 21-inch bore cylinders. The cylinders are down connected with the primary suction and discharge bottles located below the compressor deck. The unit operates over a speed range of 255 to 330 rpm, with fixed clearance pockets and a total of 19 load steps. The original primary bottle design, shown in Figure 3, used a baffled, center fed bottle with a perforated choke to reduced second order pulsations. This is one of three identical units installed as part of an early horsepower replacement project. Following installation, the unit could not run off of the bottom load step without exceeding the rated engine torque. Figure 4 presents the cylinder pressure data from Cylinder 2 at 330 rpm. As shown, compressor efficiency (based on ideal compressor horsepower between toe pressures)



Figure 15-2. Cooper GMW330 with 21-inch Bore Cylinders.




Figure 15-3. Cooper GMW330 Original Bottle Design - 1996.




Figure 15-4. Cylinder Performance for the Original Bottle Design at 330 rpm.

was on the order of 46 percent. Note that the differential indicated power (DIP) above and below toe pressures is consistent with very large valve losses, or perhaps nozzle orifice losses. Simultaneous measurements of pressure behind the suction and discharge valves, overlaid with cylinder pressure data clearly indicated that high valve loss was not the root cause of the excessive losses.

Using the measured dynamic pressures, combined with the acoustic model developed for the system, an estimate of the static and dynamic losses through the choke tube was made. Figure 5 illustrates the nature of these calculations. The flow through the perforated choke tube is first established. From this flow estimate, the pressure drop is estimated using the static loss coefficient. Using the mean flow and static loss coefficient, the estimated pressure drop is 2.8 psi. Using the same loss coefficient and the dynamic flow, the average estimated pressure drop is 17 psi. Using mean flow and mean pressure drop estimates, the cost of the perforated choke is estimated to be 30 HP. Using the dynamic flow and dynamic pressure drop estimates, the cost of the perforated choke is estimated at 600 HP. Field modifications of both the suction and discharge bottles consisted of shortening the choke tubes and removing the perforated section, as shown in Figure 6. Shortening the choke resulted in significantly raising the choke's resonant frequency, an acoustic mode involving strong cylinder-to-cylinder interactions.

Figure 7 presents the cylinder pressure data following modifications to the suction and discharge primary bottles. Based on the improved cylinder efficiency, 440 of the estimated 600 HP were recovered. This particular station typically operates at a low ratio, which makes it difficult to achieve low pulsation levels and consistently high cylinder efficiencies. Based on data acquired at various speeds and operating conditions, a simple relationship between pulsation driven cylinder losses and combined suction and discharge nozzle pulsations was developed. As shown in Figure 8, combined suction and discharge nozzle pulsations of less than 40 psi peak-to-peak would be required to drive losses to less than 50 HP per cylinder end.

The units operated with this bottle configuration until 2002, when interest was expressed to recover more of the lost horsepower through the pulsation control system. A bottle system was designed that would completely isolate cylinder-to-cylinder interactions. A goal of the design was to use the existing secondary bottle located outside of the compressor building. Figure 9 presents a schematic of the new design approach.




Figure 15-5. Source of Excessive Horsepower Loss for the Original Bottle.




Figure 15-6. Cooper GMW330 Modified Bottle Design - 1997.





Figure 15-7. Cylinder Performance for the Modified Bottle at 330 rpm.



Pulsation Dip HP versus total pulsations

Figure 15-8. Effect of Residual Pulsations on Cylinder Performance for the Cooper GMW330 Unit.

Both cylinders are acoustically isolated from each other by using a long choke to connect the primary bottle chamber for each cylinder to the external bottle. Figures 10 and 11 present pictures of the dual choke configuration leaving the primary bottle and the small bottle used to recombine the flow prior to entering the exterior secondary bottle. Figure 12 presents cylinder pressure traces following modifications to the bottles. Table 1 summarizes the current performance of the unit. Compressor performance is now up to 92 percent at comparable operating conditions.




Figure 15-9. Current Bottle Layout for the Cooper GMW330 Unit.



Figure 15-10. Dual Choke Configuration.



Figure 15-11. Special Fitting for Dual Chokes.

A final concern expressed by the unit operators was an apparent variation in discharge pressure between the three units. The center unit (Unit 12) displayed higher discharge pressure than Units 11 and 13. The pressure sensors for all three units were located in the center of the choke tubes between the primary and secondary bottles. Again, dynamic flow losses were thought to be driving the variation in discharge pressures. Dynamic pressure data were acquired in the center of the suction and discharge choke tube as a function of unit speed. Figure 13 presents the results and clearly shows the choke tube resonance excited at 300 rpm. Figure 14 presents the static discharge pressure recorded at the same location. Clearly, the dynamic response is driving the increase in apparent static pressure.




Figure 15-12. Cylinder Performance for the Current Bottle Layout at 330 rpm.

Table 15-1. Performance Summary for Current GMW330 Bottle Layout.

Cylinder End	HE No. 1	CE No. 1	HE No. 2	CE No. 2
Total Cylinder HP	18	52.2	200	8.5
Discharge DIP	2	8.4	2.3	7.1
Suction DIP	3.8	1.5	4.3	1.1
Total Discharge DIP	- 5	.2	4	.8
Total Suction DIP	2	.6	2	.6
Cylinder Efficiency	9:	2.2	92	2.6
Cylinder MMSCFD	71.1	62.7	68.5	67.9
Cylinder Ratio	1.	28	1.	28
Total Unit IHP	3860.7			
Total Unit Flow (MMSCFD)	270.2			
Compressor IHP/MMSCFD	14.3			

Choke 4th Order Versus Unit Speed




Figure 15-13. Unit 11 Choke 4th Order Dynamic Pressure Versus RPM.




Figure 15-14. Unit 11 Discharge Pressure Versus RPM.

CASE STUDY 2

Figure 15 is a photograph of a Dresser-Rand HHE reciprocating compressor unit operating in a storage application. There are three identical units at this station, installed in the late 1970's. The units are separable electric driven compressors operating at 327 rpm and rated at 6,000 HP. The units can be operated in either a single or two-stage injection/withdrawal service with discharge pressures up to about 3,000 psig or a single stage withdrawal service with discharge pressures of about 900 psig. The operating company plans to install a fourth identical unit and requested a reevaluation of the existing bottle designs. SwRI's digital Interactive Pulsation-Performance Simulation^{2,3} (IPPS) code was used to evaluate the current bottle design. The IPPS code automates the calculation of dynamic flow losses at pressure drop elements and the analysis indicated excessive losses on both the first and second stages (Figure 16). The primary discharge bottles are three-chamber with chokes in series, as shown in Figure 17. Based on the model predictions, the excess losses appear to be associated with dynamic flow through the exit choke between Cylinders 2 and 4. This choke tube carries the flow of two cylinders, and is sized such that the velocity is greater than the



Figure 15-15. Dresser-Rand HHE Low-Speed Separable Unit.




Figure 15-16. IPPS Pressure Drop Predictions for Second-stage Discharge Choke.




Figure 15-17. Existing Bottle Configurations for HHE Units.

flow through the choke connecting the Cylinder 4 and Cylinder 6 bottle chambers.

As part of an on going GMRC research effort to evaluate and enhance the SwRI/GMRC design tools, a field test effort was completed to document system performance. Cylinder performance data were used to quantify unit losses. Figure 18 presents the head end and crank end traces for Cylinder 2. Table 2 summarizes the unit's cylinder efficiency. Note that, as predicted, there is excess loss of horsepower for Cylinders 2 and 4. Predicted losses are approximately 160 HP on the high-pressure side and 60 HP on the low-pressure side. Combined, the total losses are approximately 4 percent of rated horsepower at the conditions analyzed.

We anticipate that the losses will be greater under different operating conditions. Modifications were developed that should minimize the horsepower cost. At this time, we are recommending that the exit choke tubes be shortened to shift the acoustic response frequency. For electric drive units, the potential savings in horsepower is magnified by demand charge costs, which can significantly alter the economics of unit operation.

SUMMARY

There is a wide range of compressor efficiencies in the installed base of horsepower in the US gas transmission industry. Traditional bottle design methods typically did not quantify the impact of pulsation control on compressor performance. This chapter has shown how dynamic flow losses can significantly reduce compressor efficiencies. Based on our current understanding of the relationship between pulsa-




Figure 15-18. Cylinder 2 Performance for Existing Bottle Design.





Table 15-2. Cylinder Efficiency for Existing HHE Bottle Design.

tion control and compressor performance and our continually developing predictive capabilities, we suspect that there are many existing compressor installations that would benefit from a reevaluation of the bottle design. In some cases, even marginal increases in compressor performance can translate directly to significant savings in operating costs due to decreases in fuel consumption and increases in system capacity.

References

- Berry, Renee, "Gas Transmission Compressor Efficiency Survey." GMRC Research Project Conducted by Southwest Research Institute, 1995.
- Gehri, Christine and Harris, Ralph, Ph.D., "High Speed Reciprocating Compressors The Importance of Interactive Modeling." Presented at the Gas Machinery Conference, Houston, TX, October 1999.
- 3, Gehri, Christine and Harris, Ralph, Ph.D., "Technology for the Design and Evaluation of High-Speed Reciprocating Compressor Installations." Presented at the European Forum for Reciprocating Compressors, Dresden, Germany, November 1999.



Chapter 16

Resolution of a Compressor Valve Failure: A Case Study

–Steve ChaykoskyDresser-Rand CompanyPainted Post, NY

This study addresses the various components of reciprocating compressor valves (i.e., valve plate type, valve plate lift, valve plate impact velocities) the effects of particulates in the gas and how each influences compressor performance and overall operation.

This study has been provided courtesy of Dresser Rand, Inc., the owner of this material. Furthermore, Dresser Rand, Inc., has granted copyright permission for the use of this study in this book.

ABSTRACT

The commissioning date of three critical path ethylene compressors at a Belgian chemical plant was in jeopardy because the original compressor valves failed within hours of start-up on the final stage of compression. The valve supplier attempted to resolve the failures twice, without success. The failed concentric ring valve design was evaluated by the compressor OEM and determined to have marginal reliability characteristics. A different type of compressor valve, the ported plate valve, was proposed as a potential solution. Although a slight decrease in compressor efficiency was expected with the alternative valve technology, the client deemed this an acceptable compromise to meet his production schedule. The new valves were installed in April 1999 and continue to run without problems.

INTRODUCTION

Valve problems are reported as the primary reason for reciprocating compressor shutdowns. The anecdotal evidence is confirmed by a recent survey of hydrogen compressors, which finds that 36% of unscheduled downtime is due to valve failures.

Compressor valves fail for a variety of reasons, which can generally be divided into design factors and operational factors. Design factors include application and selection errors. Operational factors are related to the process gas conditions and to how the compressor is run and maintained.

Discovering root causes of failure depends on a full exchange of information between the valve manufacturer and his client. The client must be willing to provide complete operational data and the valve manufacturer must be willing to review and modify his valve design. Since each reciprocating compressor is unique in the way it is operated and serviced, the circumstances surrounding each case of valve failure and its resolution are also unique.

This case study illustrates how a valve failure can be attributed both to valve design considerations and to operational problems. As the case is discussed, emphasis will be placed on the analysis of valve dynamics, the relationship of valve lift to valve life and compressor efficiency, and elements of valve failure analysis.

The client reported that failures of the 3rd stage discharge valves occurred within hours of achieving full pressure load on 2 of 3 newly commissioned ethylene compressors. The failed valve components were multiple concentric rings made of PEEK, a high-strength thermoplastic.



Figure 16-1. Concentric Ring Valve

Figure 16-2. Ported Plate Valve

Figure 16-1 shows an example of a concentric ring valve. The original valve supplier reported that excessive stresses were imparted in the rings due to unexpected radial, fluttery movement. Their response was to design and manufacture a different type of concentric ring element to better resist the lateral motion.

As the compressor OEM and a valve manufacturer, Dresser-Rand was solicited for comments but did not have enough information to perform a formal failure analysis. However, plant startup was imminent, so the client contracted us to provide valve hardware in case the original supplier's modified valves were unsuccessful. We had the freedom to provide whatever valve style we believed would work best. By day's end, a ported plate valve was selected, a dynamic valve analysis (DVA) was performed based on the reported field conditions, new valve drawings and programs for the N/C (numerically controlled) machine tools were created, and the manufacturing floor was alerted to expect a crisis order. Figure 16-2 shows a ported plate valve.

Two days later, the client contacted us in the morning to say that the original 3rd stage suction ring valves had also failed and wanted to know if ported plate suction valves could be delivered with the new discharge valves. Suction and discharge valves for all 3 compressors were manufactured and shipped that afternoon. A set of ported plate valves was installed in one compressor immediately upon receipt.

Ten days after the problem arose, the original valve supplier transmitted simulated P-V (pressure-volume) indicator cards and valve motion diagrams of the failed valves for our evaluation. The data suggested that the original valves were closing on time. However, the original valve supplier's modified valves continued to fail.

By the second week, a second set of ported plate valves were fitted to another compressor, and a site visit by Dresser-Rand personnel yielded the first reports of oil sticktion problems and of particulates in the gas stream.

Since the 3rd stage discharge valves failed first, the client initially believed debris and/or liquids could be eliminated as the problem source because the 3rd stage suction valves, which are upstream of the discharge valves, remained intact. However, the 3rd stage suction valves failed the day after the discharge valves failed, and the client eventually acknowledged that there was debris in the gas stream.

The original valve supplier explained that the radial movement of the concentric rings was caused by valve flutter, which occurred because the compressor did not achieve full pressure fast enough. Flutter is a phenomenon in which the moving elements of a valve open and close several times throughout one compression cycle. To minimize flutter, an accelerated load profile was attempted, which brought the compressor to full pressure faster. However, the 3rd stage discharge valve rings failed again after just a few hours at full pressure.

When asked to comment on the cause of failure, we could only conjecture because failed hardware was not available to evaluate, a dynamics study of the original valve design was not initially provided, and not all of the operational facts were known.

Proprietary DVA software is the tool that was used to generate simulated lift diagrams of the concentric ring and ported plate valves. Since the failed concentric ring valve data was not immediately available, we estimated the configuration of rings and springs in order to perform a DVA study. Figure 16-3 shows the estimated head end discharge valve motion of the concentric rings. Note that all of the rings close before reaching the top dead center (TDC) crank angle of 360°. This is important because it means that the original rings should have closed on time. The original valve supplier's simulated lift diagrams were transmitted to us later, and their valve motion study also indicated on-time closing. Since we developed the ported plate valve data for the DVA, there was a high degree of confidence in the valve motion simulation, and Figure 16-4 shows that the ported plates do indeed close well before TDC.

Lift diagrams illustrate the importance of proper valve closing but do not indicate whether the impact velocities of the moving elements (plates, rings) are acceptable. DVA software calculates impact velocity, but this parameter is useful only if the application limits of each valve type are well known. Different plate and ring geometries have different




Figure 16-3. Lift Diagram Concentric Ring Valve Head End Discharge Valve

allowable impact velocities, which are experientially derived.

Ported plate valves were selected for this high-pressure ethylene application with the assumption that oil sticktion and excessive plate impacts factored into the failures. Confirmed reports of oil sticktion and debris in the gas stream were received almost 2 weeks after the initial failures occurred.

The emergent nature of this field problem forced a rapid evaluation of potential valve designs. The final selection was certainly based on parts availability and shop capacity, but the foremost customer requirement was also achieved: reliability.

The ported plate valve has less flow area than the original failed ring valve because the lift is lower. Although the client preferred not to have compressor efficiency degraded by a valve change, he deemed it an acceptable compromise. After all, a compressor that shuts down on valve failures has zero efficiency. The effective flow area (EFA) of the ported plate valve is 41% less than the reported EFA of the failed concentric ring valve. A valve's EFA is determined by laboratory flow testing and is typically 40% to 70% of the valve lift area. Valve lift area is a calculated quantity based merely on valve geometry and is open to interpretation by different valve manufacturers. Therefore, EFA is the relevant flow area for the valve designer, not lift area.

The original valve supplier's 2nd modification of the concentric ring valves involved lowering the lifts. The ported plate inlet valves have 17% less flow area than the ring valves with reduced lift; the ported plate discharge valves 29% less. Although the EFAs of the ported plate valves are less than the modified ring valves', an October 1999 monitoring report based on Recip-Trap measurements states that the 3rd stage valve losses were "very low," as were the plate impacts. Simulations




Figure 16-4. Lift Diagram Ported Plate Valve Head End Discharge Valve

predicted a 4.5% increase in 3rd stage power consumption with ported plate valves installed, but the measured losses were actually much less. This points out a common fallacy in calculating a cylinder's power losses. Algorithms that only consider the valve losses and ignore pressure losses over the cylinder passages, cylinder ports, and valve cages are not comprehensive. All these losses are additive. Therefore, a reduction just in valve flow area does not necessarily translate into a proportional power increase and consequent efficiency decrease.

A valve with very low pressure loss appears very efficient on paper. Even when proper springs are chosen to close the valve, there may not be enough pressure drop to hold the moving elements completely open, which will cause flutter. Flutter decreases the effective lift and therefore increases the predicted power losses. Flutter can be eliminated with lighter springs, but then there is a risk of late valve closing, which will reduce cylinder capacity and cause the moving elements to slam shut. If the gas forces slam a valve closed, the moving elements could fracture from the associated high closing impact velocities.

FAILURE ANALYSIS

Design factors working against reliability of the original valve design:

High valve lift. Lift is simply the distance traveled by the valve's 1. moving elements from the fully closed position to the fully open position. The higher the lift, the higher the flow area of the valve. The higher the valve's flow area, the lower the pressure drop across the valve. The lower the pressure drop across the valve, the lower the horsepower consumed by the compressor's driver (motor, engine, or turbine.) The lower the power consumption, the more efficient the compressor, and the happier the client. By such transitive logic, the client should be happier with higher valve lift, but not in this case. The lift of the original failed concentric ring valve was .079 inches, whereas the lift of the ported plate valve that has been running problem-free for over a year is .040 inches. The lift chosen by the valve designer depends on the valve type and the compressor operating conditions. Different valve styles have different flow characteristics. Ported plate valves have excellent

flow areas at relatively low lifts, but there are quickly diminishing returns as lift is incrementally increased, and there is a certain lift beyond which no more flow area can be obtained. Concentric ring valves are often used at higher lifts than ported plate valves. At the upper end of their useful lift range, concentric ring valves have equivalent or slightly higher flow areas than ported plates, but the impact velocities of the rings at those higher lifts will exceed those of the ported plates. Poppet valves have yet more flow area than concentric ring valves when used at their highest practical lifts, but the poppet's impact velocities may be markedly higher than the rings'. Therefore, choosing the appropriate lift for a given application depends on knowing the impact velocities that different valve types can withstand. In this case, a .040 inch lift ported plate valve works well at the 3rd stage conditions, yet a .079 inch lift concentric ring valve proved unreliable and not measurably more efficient.

Excessive impact velocities. The laws of physics rarely allow some-2. thing for nothing, and the price to pay for higher lift is higher impact velocities of the valve's moving elements. Since increased durability of the moving elements depends on relatively low impact velocities and therefore low lifts, the relationship between compressor efficiency and valve reliability is inverse. Reliability and efficiency are competing properties of compressor valves, and an acceptable compromise often means sacrificing efficiency for reliability. In this case, the original valve supplier did not divulge the predicted impact velocities of the concentric rings that failed. However, our estimation of the valve motion indicates that the opening impacts of the original .079 inch lift concentric ring discharge valves may have been 40% higher than the opening impacts of the .040 inch lift ported plate valves, and the closing impacts may have been 38% higher. Lift is not the only factor that determines impact velocity. Compressor speed, cylinder pressure, valve springing, and sticktion are also contributors. Impact velocity increases with higher speeds, higher cylinder pressures, heavier spring rates, and increased sticktion. In this case, the compressor speed of 328 rpm is considered low, but the cylinder pressures of 1000 psi inlet and 3200 psi discharge are relatively high, and the increased 3rd stage oil viscosity and lubrication rate contributed to a relatively high sticktion level.

Lateral ring motion at off-design condition (reduced pressure break-3. in phase.) Although a compressor valve is often able to work over a range of operating conditions, it is optimized for a single design case, i.e. a single combination of pressures, temperatures, speed, cylinder clearance, gas molecular weight, lubrication rate, and pulsation level. When one of these parameters changes, the valve necessarily runs at an off-design condition, and proper timing of the opening and closing events is disrupted. Conditions of service that are slightly off-design are usually tolerated, but major changes to any of the parameters can pose a severe detriment to the valve motion and sometimes result in failures of springs and moving elements. In this case, the original valve supplier blamed the fluttery, non-synchronous movement of the rings on a slow rate of pressurization of the 3rd stage. The supplier stated that the rings were very sensitive to sticktion effects and special startup conditions and subsequently redesigned the valve a 3rd time with radiused rings of a different thermoplastic material to fight the sticktion problem and the high impact loading. However, the redesigned concentric ring valves were not installed, so it is not known whether this would have solved the failures.

As the moving elements of a valve open and close, they never move perfectly perpendicular to both stopping surfaces. The plates and rings always wobble before they momentarily rest against the seats and stopplates. Consequently, the initial opening and closing impacts always occur on an outer edge of the plate or ring, which is usually where plate or ring fractures initiate. The ported plate that solved this field problem employs scalloped edges on the outer periphery. Since the plate tips as it moves off the seat and stopplate, the initial impacts will be forced to one of the scalloped edges. Figure 16-2 illustrates the scalloped plate, which is a patented design. Each scallop provides a region of higher cross-sectional area to better absorb the opening and closing impact velocities. Since this increased area can better resist impact stresses, the likelihood of plate failures is reduced. The ported plate is also precisionguided with a center ring and with rollpins to minimize lateral movement. In this case, the plate valve design, which consists of a

single ported PEEK plate, resists non-uniform, lateral motion better than the concentric rings.

Client requested the original valve type that failed. Many clients are accustomed to using a particular style of valve in their compressors, and they often develop a comfort level with a given valve type. Preferences are usually experience-based, but price has also been known to enter into the specification process. While customer input is welcomed and encouraged, the valve supplier must know his product's application limits, which are primarily based on pressure, temperature, and compressor speed. Valve designs are customized to satisfy specific operating conditions, and not all valve types will work for all conditions, so it is the valve designer's responsibility to select and advocate the appropriate hardware. While preferences should be honored whenever possible, clients are advised not to dictate final valve design.

Operational factors working against valve reliability:

- 1. Particulate ingestion. The suction strainers on all 3 stages were regularly plugged with small metallic particles. The 2nd & 3rd stage accumulations were associated with cylinder lube oil holding the particles together. The source of the particulates, which were reported to be a reality of the plant's gas process for years, was not divulged. Incompressible substances in the gas stream can become lodged between a moving element (plate or ring) and the stationary parts (seat and stopplate) of a compressor valve. The plate may become overstressed at the point where it hinges on the foreign particles and fail. Plastic plates, such as PEEK or Nylon, will often embed metallic debris and continue to operate properly, but the embedded metal fragments can prematurely wear the sealing surface of the valve seat.
- 2. Oil sticktion. The 3rd stage cylinder lubrication system is independent of the first two stages, which is atypical for reciprocating compressors. The 3rd stage uses a slightly different blend of oil and feeds it at a higher rate than the lower stages. The 3rd stage pressures and temperatures are 1000 to 3200 psi and 95° to 225° F, respectively. Ethylene evidently takes oil into solution at this pressure and temperature combination, so an adhesive agent was added to the 3rd

stage lubricating oil to ensure that it would stick to the cylinder bore, piston rings, and piston rod packing. The additive also caused the oil to stick to the moving parts of the valve. Sticktion is defined as the viscous adhesion of oil between the moving and stationary parts of a valve, and is detrimental to valve reliability in two ways. First, sticktion inhibits plate opening, causing the plate to slam open when the pressure force exceeds the sticktion force, which can cause damage not only to the plate but to the underlying springs. Second, sticktion delays plate closing, which elevates the plate's closing impact velocity. If the plate closes so late that there is backflow through the valve, then there is not only a greater potential for plate damage but there is also an actual loss of cylinder capacity. In this case study, the high oil viscosity and increased lubrication rate contributed to the sticktion effects.

CONCLUSIONS

- 1. The reasons for valve failures can be divided into design problems and operational problems.
- 2. Valve lift, plate impact velocity, operating at off-design conditions, valve flutter, oil sticktion, and liquids and debris in the gas stream are factors to consider when evaluating valve failures.
- 3. There are several different types of compressor valves, each of which has application limits, so a good understanding of how to reliably apply each type is paramount.
- 4. Successful resolution of valve failures often means having to employ new or redesigned valves that are less efficient. Sacrificing some compressor efficiency for increased valve durability is often an acceptable compromise.
- 5. Timely resolution of valve failures depends on accurately analyzing complete operational data and any available failed hardware.

Acknowledgements

The author wishes to thank Dr. Derek Woollatt for his thoughtful comments and suggestions on the technical content. Thanks are also due to Anne Lacey for her insightful review. Finally, thanks to Dresser-Rand Company for the opportunity to present this case study.

Appendix A1

Compressor Manufacturers

The following tables list compressor equipment manufacturers and compressors by model. The list is divided into two categories: dynamic compressors and positive displacement compressors. The information provided is instrumental in identifying units with comparable capability.

Note that most positive displacement compressors are packaged by independent companies. These companies package a compressor with a driver per the purchaser specifications (included in the packager's scope of supply are suction & discharge vessels, valves and controls).

This information, provided courtesy of COMPRESSORTech^{Two} magazine "Compressor Technology Sourcing Supplement" published by Diesel & Gas Turbine Publications. Current compressor information, as well as Natural Gas Engines, Mechanical Drive Gas Turbines, Electric Motors, Variable Speed Drives, and Mechanical Drive Steam Turbines can be found at www.compressortech2 or www.CTSSNet.net.

Compressor specifications in Appendix XX From the 2009 Compressor Technology Sourcing Supplement, courtesy COMPRESSORTechTwo magazine, published by Diesel & Gas Turbine Publications. Current compressor information can be found at www.compressortech2 or www.CTSSNet.net.

Dynamic Compressor Specifications

	H	A	xial F	*IOW			radial	Flow		-+	Then	mai		Inlet Flow Rai	nge - acfm (m3/min)	-		-	Maximu	im Input Power	Speed Ran	nge - RPM
Manufacturor	Model Designation	Muli Stage	Fixed Stator Vanes	Stator Va	Single Stage	Multiple State	Horizontally Split	Vertically Split	Integral Gear	Integral Electric	Single Stage	Multiple Stage	OF = Oil Free/OI = Oil Injected	пh	шах	MAWP Maximum Allowable Working Pressure - psig	MAWP Maximum Allowable Working Pressure - bar	Compression Ratio (per stage)	표	KW	speed_min	
Atlas Copco Energas GmbH	GT-Serie	T-	1	\top	x	x	x		x				DF	175 (5)	141,000 (4,150)	1,305			26,820 26,820	20,000	1,000	50,0
illas Copco Energas GmbH	T-Serie		-	+	X		x	1		-	-		OF .	2,760 (80)	141,000 (4,150)	725	51		26,820	20,000	1,000	18,0 40,0
Mas Copco Energas GmbH Mas Copco Energas GmbH	H-Serie ZH-Serie	1	+	1	×	. <u>'X</u>	×	1	ĵ		+		DF DF	4,950 (140) 2,300 (65)	24,000 (680) 9,200 (260)	406 145			5,360 2,150		16,000 26,400	50,0
ameron's Compression Systems Group	TA-2000	+-	+	1	-	-x	×	1	x x				OF.	2,000 (00)	1,610 (46)	150		3 1.6	350			3,6
Carneron's Compression Systems Group	TA-2020	\top			-	×	×	1 1	x x		†		OF		1,940 (55)	150		3 1.6	400			3,6
Cameron's Compression Systems Group	TA-3000					×	×		x. x				OF		3,960 (112)	150		3 1.6	800			3,6
Cameron's Compression Systems Group	TA-6000		1			х	x		х х				OF		8,080 (229)	150		3 1.6	1,700			3,6
Cameron's Compression Systems Group	TA-9000		!	-		×	×		× ×	:	- 1		OF		11,800 (334)	150		3 1.6	2,250		\rightarrow	3,6
ameron's Compression Systems Group	TA-11000		i			×	X		×	:	- 1	8	OF.		12,000 (337)	250 510		7 1.6 5 1.6	2,500 4,750	1,900	\rightarrow	3,6
ameron's Compression Systems Group ameron's Compression Systems Group	TA-20000 MSG-Alpha	+	+	-	-	X	×		x x	-			OF		21,000 (595) 3,800 (108)	1,200		5 1.6	1,250			3,6
ameron's Compression Systems Group	MSG-2	+	+	+	1	î	î		î î	:		1	OF.		4,500 (108)	1,125	77	5 1.6	1,850	1,370	-	3,6
ameron's Compression Systems Group	MSG-3		T		1	x	x		x x		:		OF	1	7,000 (198)	1,120	7	7, 1.6	5,100	3,800		3,6
ameron's Compression Systems Group	MSG-4					x	x		x x	:			OF		14,000 (397)	725	51.	5 1.6	7,000	5,220		3,6
ameron's Compression Systems Group	MSG-8		_			x	x		x x				OF.		30,000 (849)	725		1.6	11,500			1,8
ameron's Compression Systems Group	MSG-12		<u> </u>		ļ	х	x		x x	١			OF .	l	46,000 (1,303)	687		1.6	17,000			1,0
resser-Rand	Pipeline PDI	+	-	_	X	X	-	X	-	-	\rightarrow		OF .		60,000 (1,700)	1,500	10:		50,000			14,5 27,0
resser-Rand	DATUM P	+	-		-	X	X	x	\rightarrow	-	-		OF OF		230,000 (6,513) 59,000 (1,671)	10,500			120,000		\rightarrow	17,0
esser-Rand esser-Rand	DATUM C	+-			· · ·	- -	+-	x		-+			OF		59,000 (1,671)	3,000			27,000		+	17,0
esser-Rand	DATUM ICS	+			×	x	-	x	l2		-		OF		20,100 (570)	3,000			20,100			17,
esser-Rand	Centrifugal	1	†		100	×	×	x		-			OF		230,000 (6,513)	10,500			120,000			38,
esser-Rand	Axial	x	х	X)F		875,000 (8,580)	80		5	125,000	93,000		8,4
liott Company	Α	×	, x	×	Ļ	<u> </u>	ļ						OF		396,000 (11,200)	80					2,680	7,2
liott Company	M	-	-	+	ļ.,,	×	x	-					OF		320,000 (9,065)	1,000			120,000			25,0 25,0
liott Company	P-LINE	+	+	1	×	-X	+	x	-	\rightarrow	-		OF OF		154,000 (4,360) 190,000 (5,380)	10,000			120,000			15,0
Mott Company Mott Company	PH-LINE	+		1	Ŷ	+	+	x		-+			OF .		45,000 (1,275)	900			15,000			15,0
liott Company	TC	-			x	+	_	x		\neg			OF.		56,500 (1,600)	1,450			40,200			18,5
S Elliott	PAP Plus				I	×		x :	x					866	30,60	0		12	3,500			3,6
aro	VC	1			x	X		х					OF	-17			1.5	5 1.2		400	3,000	6,0
aro	VAP	-	-	-	x	x	-	x	_	-			OF .	-17				1.2		2,000	3,000	6,0
aro	CC (Galileo)		+ -		Χ	X	┿-	X :	×		: - 1:		OF OF	-17			34		30,000	2,000 22,000	4,000 3,000	42,0 17,0
E Oil & Gas AC E Oil & Gas AC	V	_	+	+		×	-	X	_	- 1,			OF		60,000 (1,700) 100,000 (2,830)	5,000			30,000		3,000	15,
E Oif & Gas AC	D		+	i		<u> </u>	- ×	V.	1	1	2 1	` 1	OF		260,000 (7,370)	150			30,000	22,000	5,500	10,
E Oil & Gas AC	DH	-	+	-	x		+	x		Ţ,			OF.		50,000 (1,420)	750			20,400	15,000	1,200	17.
E Oil & Gas Nuovo Pignone	AN (Air Service)	×	1	x		1	1						OF.	58,860 (1,667)	353,150 (10,000)	360	2		95,200	70,000	3,000	8,
E Oil & Gas Nuovo Pignone	AN (LNG Service)	x		X		1	1						OF T	58,860 (1,667)	176,550 (5,000)	360	2		95,200		3,000	8,
Oil & Gas Nuovo Pignone	BCL-HP (>350bara)	1			1	x		×	- 1	- 1	. [OF		6,003 (170)	14,500			40,800		7,000	18,
Oil & Gas Nuovo Pignone	BCL-LP/MP (<350 bara) MCL		-	+		×		X		-+	⊦		OF OF		29,430 (833) 294,290 (8,333)	5,075	351		54,400 95,200		3,000	20,
Oil & Gas Nuovo Pignone Oil & Gas Nuovo Pignone	PCL	-	+			x	×			-	\rightarrow		OF.	-	58,860 (1,667)	1,890			54,400		3,600	13,
E Oil & Gas Nuovo Pignone	SRL	†	1	1	Ŷ.		+	×	× :	+			OF.	 	206,000 (5,833)	1,015	71		20,400		3,000	50,0
E Oil & Gas Nuovo Pignone	SRt. (overhung, single stage)	-		+	x	-		- 1	×				DF.		58,860 (1,667)	1,015			20,400		1,500	20,0
Oil & Gas Thermodyn	RA	İ	1	<u> </u>	L.	x		х					OF/OI	230 (6)	10,000 (300)	2,900	201		20,000		10,000	20,0
Oil & Gas Thermodyn	BCL-LP/MP	1			i	×	·	X	- 1				OF		29,430 (833)	5,075	201		20,000		1,500	20,0
Oil & Gas Thermodyn	ICL	-			ļ	x		x	X)F	700 (20)	17,000 (500)	2,900	201		20,000		3,000	14,0
achi, Ltd./Hitachi Plant Technologies, Ltd.	2BCH 2MCH	 	+	+	1	X	-	Χ	- 4	+				88 (2) 280 (8)	56,500 (1,600) 204,800 (5,800)	10,900 650			67,000 67,000		3,000 3,500	18,0
achi, Ltd./Hitachi Plant Technologies, Ltd. achi, Ltd./Hitachi Plant Technologies, Ltd.	3MCH	+	+-	+		×	X	\vdash		+	+	-			204,800 (5,800)	650			67,000		3,500	18,0
achi, Ltd./Hitachi Plant Technologies, Ltd.	BCH	+	1		1	×	÷-	×	\rightarrow	\rightarrow	\rightarrow	\rightarrow		88 (2)	56,500 (1,600)	10,900			67,000		3,000	18,0
achi, Ltd./Hitachi Plant Technologies, Ltd.	MCH	T	:	+ -	T	×	×		†	-	-	\neg		280 (8)	204,800 (5,800)	650	4		67,000	50,000	2,500	18.
tachi, Ltd./Hitachi Plant Technologies, Ltd.	PCH	1.	_	\Box	×	×	L.,	×		J				280 (8)	204,800 (5,800)	1,740	121	1.3	35,500	25,000	3,000	14,
tachi, Ltd./Hitachi Plant Technologies, Ltd.	POB-CH	I.	1	Ι.	x	<u>i</u>	Γ	x	- [1,770 (50)	35,300 (1,000)	1,160			35,500		3,000	14,
	POB-GH	1	-		×	4	4	х :		-	_			1,770 (50)	35,300 (1,000)	1,160			35,500		3,000 5,000	14,
		1													6,357 (180)	29		2 3	268	200	5 000	33,
tachi, Ltd./Hitachi Plant Technologies, Ltd. owden Process Compressor	SG26	1	ļ.,		X	+	×.		X				DF DE	4,238 (120)	18 478 (240)			3		450	E 000	22
owden Process Compressor owden Process Compressor	SG26 SG30		<u> </u>	1	X	+	x		x			()F	4,238 (120)	8,476 (240)	29		2 3	603	450	5,000	33,
wden Process Compressor	SG26		ļ.,	-	X X	-								4,238 (120) 4,238 (120) 4,238 (120) 6,357 (180)	8,476 (240) 10,595 (300) 14,832 (420)			2 3 2 3 2 3		450 500	5,000 5,000 5,000	33, 33,

www.CTSSNet.net Data Courtesy COMPRESSORTechTwo magazine. Additional current data available at www.compressortech2.com or

Dynamic Compressor Specifications

		A	dal Flo	-		Γtd	idial F	IUW		-+'	hem	ai -		IIIHBL FIOW PCE	inge - acfm (m3/min)			+-	Wiaxiiii	m Input Power	Speed
Manufacturor	Model Designation	Muti Stage	Fixed Stator Vanes	Variable Stator Vanes	Single Stage	Multiple Stage	Horizontally Split	Vertically Split	Integral Gear	integral Electric	Single Stage	Multiple Stage	OF = Oil Free/OI = Oil Injected	min min	шах	MAWP Maximum Allowable Working Pressure - psig	MAWP Maximum Allowable Working Pressure - bar	Compression Ratio (per stage)	£	KW	
Howden Process Compressor Howden Process Compressor	SG52 SG60	1 1			×		×	×				0		12,713 (360) 14,832 (420)	25,427 (720) 31,784 (900)	29 29		2 3		1,600 1,800	5,0i
Howden Process Compressor	SG65						×	×		+	-	0		16,951 (480)	33,903 (960)	29		2 3		2,000	5,0
Howden Process Compressor	SG70	1:1		11	ĸ İ		×	x		1		0		21,189 (600)	40,259 (1,140)	29		2 3		2,600	5,0
Howden Process Compressor	SG80	Ii			× T		×	x				O		25,427 (720)	52,973 (1,500)	29		2 3		3,000	5,0
Howden Process Compressor	SG92						×, ,	X			-	. 0		33,903 (960)	63,567 (1,800)	29		2 3		4,000	5,0
Howden Process Compressor Ingersoll Rand	SG105 Centac CH	+		-			× I	X			+	0		44,497 (1,260) 800 (23)	84,757 (2,400) 6,000 (170)	29 35		2 3		5,000 448	5,0
Ingersoll Rand	Centac 2CIIDF	1 1			K	. +		X				0		3,300 (35)	9,000 (170)	35		3 3			
Ingersoll Rand	Centac CV	1-1				x	- 1	c x	×		1	0	F	800 (23)	2,450 (69)	135		9 3	500	373	
Ingersoll Rand	Centac EPF/EPC	1			1	x	,	x x	×			0		1,000 (28)	2,300 (85)	255		8 3		597	
Ingersoll Rand	Centac C250/C350	+	i	-		×		K X				0	F	1,100 (31)	2,700 (76)	150		0 2		373	
Ingersoll Rand	Centac C750 Centac C700	+-		+		×		x x			+	0		1,800 (50)	2,100 (60) 4,200 (122)	610 150	4	3 3	1,000	671 746	
Ingersol Rand	Centac 2CIISB	1	j			X	- 13	×			+	0		3,000 (85)	4,600 (130)	350	2			1,306	
Ingersoil Rand	Centac C1050					x		K X	x			0	F	3,800 (108)	3,800 (108)	610	_4	3 3	1,500	671	
Ingersoll Rand	Centac C950					x		K X				0		4,200 (122)	6,000 (170)	150		0 2	1,500	1,119	
Ingersoll Rand	Centac 3CII					×			x		_	0		6,000 (170)	9,000 (255)	175		2 2		1,492	
Ingersoll Rand Ingersoll Rand	Centac C3000 Centac 5Cli	+ +		\rightarrow		×		K X	×		-	0		9,000 (255) 12,500 (354)	15,000 (425) 30,000 (849)	150 150		0 2	3,500 6,000	2,611 4,476	
Ingersoll Rand	Centac 3C/4C			_		x			×	-	_	ŏ		5,000 (142)	15,000 (425)	375	2	6 3		3,357	
Kobe Steel (Kobelco)	VH Series						,	K			1-	10	F	1,059 (30)	58,951 (1,670)	5,000	35	0	28,000	20,000	5,0
Kobe Steel (Kobelco)	VGS / VGSP Series				K	×.		×		.		0		1,765 (50)	105,900 (3,000)	1,150	8		21,000	15,000	5,0
Kobe Steel (Kobelco) Kobe Steel (Kobelco)	DH Series V-VS-VSS Series		_		K	x	×)	K	+	_	÷	0		1,059 (30)	50,126 (1,420) 200,151 (5,670)	1,300	5	0	14,000 21,000	10,000 15,000	1, <u>5</u> 5,0
Kobe Steel (Kobelco)	VG / VGP Series		_				^	×	+	_	_	0		1,765 (50)	105,900 (3,000)	1,150	- 8		21,000	15,000	5,0
MAN TURBO AG (Oberhausen)	A, AV	x	x	×				- 1	7		+ -	ō		29,000 (835)	900,000 (25,450)	360	2			120,000	
MAN TURBO AG (Oberhausen)	AG, AK, AKF	×	х	×								0		17,500 (835)	785,000 (21,660)	280		9		125,000	
MAN TURBO AG (Oberhausen)	AR HOFIM ™	x	x	X :	_	.	-	_		_	+	0		17,500 (835)	765,000 (21,660)	280	30	9		165,000	
MAN TURBO AG (Oberhausen) MAN TURBO AG (Oberhausen)	RB	1 - 1		+		×	- >	-	×			0	F	115 (4) 140 (4)	21,000 (595) 136,000 (3,800)	4,350 14,500			-	30,000 80,000	
MAN TURBO AG (Oberhausen)	TURBAIR @ (RC)				,	x	x	`				0		5,300 (150)	115,000 (3,300)	29		2	İ	5,400	
MAN TURBO AG (Oberhausen)	RG				()	x		x				. 0		1,500 (42)	210,000 (5,840)	3,200	22			60,000	
MAN TURBO AG (Oberhausen)	RH DIKE DIG	\vdash	_	,	K 2	x :	x	+	-	-	-	0		450 (13)	388,000 (11,000)	1,160	8			80,000 100,000	
MAN TURBO AG (Oberhausen) MAN TURBO AG (Oberhausen)	RIK, RIKT, RIO MOPICO ® (RM)		.	-		× :	×	: +	-		-i	0	F	17,000 (485) 1,000 (30)	388,000 (11,000) 18,000 (500)	2,200	15	0	-	30,000	
Mitsubishi	Integrally Geared			3	()	x	- 15	(x		-	-	o		1,000 (00)	247,200 (7,000)	725		0 2.5	35,500	25,000	
Mitsubishi	V Type		.	;	()	x !		<u> </u>		1	- 1		F/OI		325,000 (9,200)	7,250	50		53,600	40,000	2,5
Mitsubishi	H Type	:	_	2			x	-					F/OI	*	425,000 (12,000)	860	6			40,000	2,5
Mitsui Engineering & Shipbuilding Mitsui Engineering & Shipbuilding	H Series V Series				-	×	×	, -	+	· · · ·	+	0		353 (10) 353 (10)	177,000 (5,000) 35,300 (1,000)	9,400			42,900 42,900	32,000 32,000	
Mitsui Engineering & Shipbuilding	MA Series	x		×		^ -		<u> </u>	-	1	+	0		555 (10)	353,000 (9,200)	145		0 7	134,100	100,000	
Pedro Gil S.A.	RNT					· · i				x	1	0	F	4 (1)	6,000 (170)	29		2	420	315	
Rolls-Royce	RFBB-20	H				x		(- -	1	-	0			12,720		14		20,000	14,900	9,0
Rolls-Royce Rolls-Royce	RFA-24 RFBB 30	-	-	;		×	- 2		+	+	+	0			25,300		14 22		20,000 75,000	14,900 56,000	9,0
Rolls-Royce	RFBB-36	Η,		-:				-	-+	+	+	0		-	45,400		15	5	75,000	56,000	3,6
Rolls-Royce	RFA 36			1			,				1	0	F		60,500	1,800	12	5	50,000	37,300	3,6
Rolls-Royce	RFBB-42	1)	× T	>			1	\perp	0			62,800		10		75,000	56,000	3,6
Rolls-Royce Rolls-Royce	RBB RCB	\vdash	- 1	-		x	- 2		+	+	+	0			6,000 13,500		31 22		35,000 50,000	26,100 37,300	8,0 5,0
Rolls-Royce	RDB	tt		1-	- 1	Ŷ			-		-+-	- 0			22,000		14		60,000	44,700	4,5
Rolls-Royce	REB	\Box			- 5	×	- 5		_			Ö			35,500		8		75,000	56,000	3,5
SAMSUNG TECHWIN	SM Series						_	_ <u>i</u> _	Ϊ.	1								-			
SAMSUNG TECHWIN	SM7000 SM6000	1	1	1		× 2	×	×			-	O		12,713 (360)	27,016 (765)	363 383	2	5	7,200	5,369 2,386	
SAMSUNG TECHWIN SAMSUNG TECHWIN	SM5000	++	_				×	<u>×</u>		+	-+-	0		8,723 (247) 4,838 (137)	12,466 (353) 8,193 (232)	363	2	5	3,200 2,130	2,385 1,588	
SAMSUNG TECHWIN	SM4000	 			()		<u>-</u> +	×			+ -	O	F	3,426 (97)	4,838 (137)	363	2		1,280	955	
SAMSUNG TECHWIN	SM3000			5	6	<u>. </u>	×	×				O	F	1,836 (52)	3,178 (90)	363	2		850	634	
SAMSUNG TECHWIN	SM2000)	()	x 2	×	×	1.		Ţ	O		953 (27)	1,766 (50)	125	8.		350		
SAMSUNG TECHWIN	SM1000	+			<u> </u>	×	×	хх	-i		-+	O	F	494 (14)	812 (23)	125	8.	5	175	130	
SAMSUNG TECHWIN	SD Series	1 1	- 1																1	l .	

Dynamic Compressor Specifications

		Ay	dal Fi	ow		R	adial I	Flow		TI	herma	al		Inlet Flow Ra	nge - acfm (m3/min)				Maximu	m Input Power	Speed Ran	ige - RPN
Manufacturor	Model Designation	Muti Stage	Fixed Stator Vanes	Variable Stator Vanes	Single Stage	Multiple Stage	Horizontally Split	Vertically Split	Integral Gear	Simle State	omitie orane	Multiple Stage	OF = Oil Free/OI = Oil Injected	main	шах	WAWP Maximum Allowable Working Pressure - psig	MAWP Maximum Allowable Working Pressure - bar	Compression Ratio (per stage)	Ē	KW	speed_min	
SAMSUNG TECHWIN	SD1000			- !		x	×		×	÷	+	OF		459 (16)	706 (20)	100		7	150	112		59.0
SAMSUNG TECHWIN	SL Series			-																	-	
SAMSUNG TECHWIN	SL7000	1			×	1 "	×	×	-1	1	1	OF	-	18,752 (531)	27,016 (765)	363	2	5	2.078	1,550		3,6
SAMSUNG TECHWIN	SL6000	1 1	1		x		x	x		1	-	OF	-	8,723 (247)	12,466 (353)	363	2	5	924	689		3,6
SAMSUNG TECHWIN	SL5000				x		x	х		î		OF	=	4,838 (137)	8,193 (232)	363	2		615	459		3,6
SAMSUNG TECHWIN	SL4000				x	1 1	x	×		-		OF		3,426 (97)	4,838 (137)	363			370	276	i	3,6
SAMSUNG TECHWIN	SL3000				x	-	x	х			\top	OF		1,836 (52)	3,178 (90)	363			245	183		3,6
SAMSUNG TECHWIN	SL2000				X			×			1.	OF		953 (27)	1,766 (50)	363	2		101	75		3,6
SAMSUNG TECHWIN	SL1000	1 1	- 1		×		×	×	1			OF		494 (14)	812 (23)	363			51	38		3,6
SAMSUNG TECHWIN	TM Series						-	Ť			+	101		V-9.	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1			- 1			,,,
SAMSUNG TECHWIN	TMx					x	×	×		1	1.	OF	- 111	4,591 (130)	7,946 (225)	152	10.	5	1,790	1,335		3,6
SAMSUNG TECHWIN	TMY			1 1		x	×	×				OF		3,249 (92)	4.662 (132)	363	2	5	930	694		3,6
SAMSUNG TECHWIN	TM2	-		4			x	×				OF		1,695 (48)	3,037 (86)	363	2:		610	455		3,6
SAMSUNG TECHWIN	SG Series						^	^^			_			1,000 (10)	0,000 (00)							
SAMSUNG TECHWIN	SG 3000	1 1		,		x	×			-+-		OF	. 1		854 (1,450)	95	1 13	7	250	186	1,800	3,6
Siemens AG	STC-GV					Ŷ	^	x x	-	_		OF		-8			200		250	100	1,000	45,0
Siernens AG	STC-GO			-	x	^		x x		+	+	OF		-20				1.6			- 1	43,0
Siernens AG	STC-SV		_			x		x			+	OF		-4			1,000.00	1.7				20,0
Siemens AG	STC-SP			-	x	!^ →		x	_	-	+	OF		-50				1.4				15,0
Siemens AG	STC-SO				Ŷ		x	^-		-	+	OF		-8				1.5				61,0
Siemens AG	STC-SH			-	^		×	_	-	-	+	OF					01	1.7				20,0
Siemens AG	STC-GC	_					^			+		OF		-60			61					40,0
Siemens AG	STC-Sx	×	x	ł., ł		X X		x x				OF		-833				1.2				9,0
Siemens AG	STC-SR			x			x	-	-	+	-	OF		-833				3 1.8				9,0
Siemens AG	STC-SI		х.		×					+	+	OF		-20			15					4,3
Siemens AG	STC-GVT	-			x	X		×				OF		-20				3 2.6				45,0
Siemens AG Siemens AG	STC-STO					x		x x		-+-	-	OF		-85				2 2.6				30,0
	STC-STO	\rightarrow			×			X X	-	+	-	OF		-63					-			40,0
Siemens AG Siemens AG	STC-ECO		_	- 1	х			x x	-	+	+-	OF		*36	-3,333	3		3.1		20,000		
		_	_	-		Χ	}		×	-+-	+-	OF.		450 (5)			11.00	1.7	45.000			12,2
Solar Turbines Incorporated Solar Turbines Incorporated	C16 C16 Series/Parallel				× -	x		X X		+-				150 (5)	1,800 (50) 3,200 (90)	3,500 1,500	24		15,000	11,185		23,8
	C33	-	_		^					+	+	-		150 (5)					15,000	11,185		22,3
Solar Turbines Incorporated	C33 Series/Parallel	\rightarrow	_		x	x		x x		+	+	-		800 (25)	9,500 (270)	2,700	186			15,290		19,8
Solar Turbines Incorporated		_	_		х.	X		x x		-	+			800 (25)	16,300 (460)	1,200		3	20,500	15,290		16,5
Solar Turbines Incorporated	C40 Multistage			- 1	×	×		x x			+			800 (25)	9,000 (255)	2,500	25		20,500	15,290 15,290		14,3
Solar Turbines Incorporated	C41	4-	-			×		x x		+	+	- i-		150 (5)	15,000 (425)	3,750			20,500			12,0
Solar Turbines Incorporated	C50			- 1	x	X		x x		+				2,200 (65)	20,000 (565)	1,500			20,500	15,290		14,0
Solar Turbines Incorporated	C61		-	-	<u> </u>	Χ .	.	X X	+		+			1,000 (30)	15,000 (425)	3,000	20		20,500 30,000	15,290		12,0
Solar Turbines Incorporated		4			х _	x		x x		+				5,000 (142)	21,000 (595)					22,370		10,1
Solar Turbines Incorporated	C40 Pipeline			1	X	X		x x		+	-	_		1,200 (35)	9,500 (270)	2,700	184		10,310	7,690		15,5
Solar Turbines Incorporated	C45 Pipeline	\rightarrow	_	- 1	x	X		х		1	i	.		2,800 (80)	13,000 (370)	1,800	124		20,500	15,290		12,0
Solar Turbines Incorporated	C65 Pipeline	1 - +			Χ	X		x x						3,500 (100)	20,000 (565)	1,600			20,500	15,290		10,5
Solar Turbines Incorporated	C85 Pipeline	+ :			х.	X		x x			-			8,000 (230)	45,000 (1,275)	1,600	110		30,000	22,370	0.05	7,0
Sundyne Corporation	LMC	++			×	\vdash		x x	-	-	-	OF		50 (85)	8,000 (13,600)	2,160			400	300	2,950	34,0
Sundyne Corporation	ВМС	+ +		H	×	- 4		x x	-			OF		50 (85)	8,000 (13,600)	2,160	. 149		400	300	2,950	34,0
Sundyne Corporation	Pinnacle	-41	- 1		×	X		x x		\perp	i-	OF		100 (170)	12,000 (20,400)	4,400			4,000	3,000	5,000	50,0
York/Frick (JCI)	M_25B	-					x	_	_	\perp		OF		400 (11)	1,800 (51)	600			2,500	1,865		24,9
York/Frick (JCI)_	M_25A			\sqcup		x	X				1	OF		1,000 (28)	2,650 (75)	600		1	2,500	1,865		20,6
York/Frick (JCI)	M_28B	1 1	- 1	l l			×					OF		2,100 (60)	3,900 (110)	600			5,000	3,730		16,9
York/Frick (JCI)	M_26A		i				x		4			OF		3,300 (94)	5,600 (159)	600	4		5,000	3,730		13,9
York/Frick (JCI)	M_388	1. 1	i	į l		x	×	1	1	1	1	OF		4,600 (130)	8,400 (238)	600			10,800	8,055		11,4
York/Frick (JCI)	M_38A	\perp		L]		x	x		1			OF		7,000 (198)	12,200 (346)	600			10,800	8,055		9,4
York/Frick (JCI)	M_55B	\perp		I			x		\perp			OF		10,000 (283)	18,500 (524)	450			17,300	12,900		7,7
York/Frick (JCI)	M 55A				-		x		_			OF		14,200 (402)	23,000 (651)	450	3		17.300	12,900		6,5

 $\label{lem:decompression} Data\ Courtesy\ COMPRESSORTech Two\ magazine.\ Additional\ current\ data\ available\ at\ www.compressortech 2.com\ or\ www.CTSSNet.net$

			_	_	Kecip	rocatir	1g			-1-	Rotary	'.		Inlet Flow Ra	ange- acfm(m3/min)		Pressure		Allowable Load		Maximur Pow		Speed	∌d R
Manufacturer	page	Model Designation	Single Stage	Multiple Stage Integral Engine Driven	Separable	Balanced Opposed	Diaphragm		Helical Lobe Screw	Sliding Vane	Scroll	Trochoidal	Liquid Ring OF ≈ Oil Free/O! = Oil Injected	min	пах	Bysd	bar	Max Rod Load-Ib	Max Rod Load Newtons	Compression Ratio per stage	н	KW	min	
riel Corporation		JGM:P	-		×	x				-+-		İ	01			6,100	421	7,000	31,138	Ť.	170	127		+-
iel Corporation		JGN:Q	5	<	x	x					1.]	.01			6,100	421	11,000	48,930		280	209	. '	13
ief Corporation		JG:A			x	x					1		OI			6,100	421	11,000	48,930		840	626		7
iel Corporation		JGR:J	- (>	< .	x	x	1						OI			6,100	421				1,860	1,387		
riel Corporation		JGH:E	>		x	х	L_i]	1	1			OI	1		7,800	538	32,000			3,210	2,394		1
riel Corporation		JGK:T	>	c	x	х					7	1	OI	1		7,800	538	40,000	177,929	1	3,900	2,908	-	1
iel Corporation		JGC:D	>	(×	×	- 1	- 1					OI			7,800	538	60,000			6,210			-
riel Corporation	!	JGU:Z	· /		×	x					1		OI			6,700	462	80,000	355,858		7.800	5,816		
riel Corporation		KBB:V	×	<u> </u>	X	x				- !	1		OI			6,700	462	100,000	444,822	-	10,000	7,457		-
riel Corporation		RG282M	- [.			x		\perp			OI	1	3,035.00 (86.00)	230	16				800	597		-
iel Corporation		RG357M						×			I	L	OI	1	5,225.00 (148.00)	230	16				1,375			7
row Engine Company		VRC-2	х	<u> </u>	.x	x	. [[OF		1,000.00			14,000	1		130			1
las Copco-Crepelle			x x	ιT .	:	x							OF/	70.00 (2.00)	2,350.00 (67.00)	1,450	100			4	760	560	400	
ckmer	1 . [HD162/HD163	x :				1			I		1	OF	7.	1 16.9	335	23	2,650		5	10		400	
ckmer		HD172/HD173	X							. ['	I		OF	3.			41	2,650		5	10	"	400	1
ckmer		HDL172/HDL173 (Watercooled)	×		1			1			ш_		OF	3.	5 8.4	600	41	2,650	1	5	10		400	
ckmer	.]	HD362/HD363	×		Ĺ.,				\perp				OF	15.3	3 36	335	23	3,400		5	15		400	o† -
zkrner		HDL362/HDL363 (Watercooled)	x									i	OF	15.3	3 36	335	23	3,400		5	15		400	``` إد
ckmer			x				L1			1	1		OF	3.0			69	3,400		5	15		400	ľ
kmer		HDL342/HDL343	x	1-	l	i				1	7		OF	6.1			52	3,400		5	15		400	ĭ
kmer		HD372/HD373	×	<u> </u>	_			i_					OF	10.			41	3,400		5	15		400	
ckmer	44	HDL372/HDL373 (Watercooled)	×		_			_			<u> </u>		OF	10.3			41	3,400		5	15		400	_ [ر
okmer		HD602/HD603	×						. !				OF	27.3			23			5	40		400	
ckmer		HDL602/HDL603 (Watercooled)				1							OF	27.			23	5,000		5	40		400	
ckmer	-		×	_	-	<u> </u>			-				OF	13.4			52			. 5	40		400	
ckmer	4	HD612/HD613	×		-	l i					i		OF	22.			28	5,000	L I	5	40		400	
ckmer		HDL612/HDL613 (Watercooled)	×		-	i					-		OF	22.1			28	5,000		5	40		400	
ckmer			×		i	ļ ļ		-					OF	52.4			24	7,000	l i	5	50		400	
ckmer RSIG ZM Compression GmbH		HDL942 (Watercooled)	×		-	-	_	-		-	ļ		OF	52.4			24	7,000		. 5	50		400	
RSIG ZM Compression GmbH		C200 BG090			+	x		-		+	+		OI		1,130.00 (32.00)	4,350	300			4	335	250		
RSIG ZM Compression GmbH			x x		-	× -				+-	-	-	OF /		1,695.00 (48.00)	8,702	600			4	200	149		
RSIG ZM Compression GmbH			x x		-	× -			_	-		-	OF /		2,895.00 (82.00)	8,702	600			4	295	220		
RSIG ZM Compression GmbH			x x		-	X		-+	+	+		ļ	OF /		8,760.00 (248.00)	8,702	600			. 4	900	672		
RSIG ZM Compression GmbH			××		+	x	-	+				Ļ	OF /		20,130.00 (570.00)		600			- 4	2,350	1,755		
RSIG ZM Compression GmbH			x x			0 -	†		+		-		OF /		30,760.00 (871.00)		600 600			4	3,538	2,640		
RSIG ZM Compression GmbH			î x			î.		_		-+	+		OF/		45,200.00 (1,280.0	8,702 8,702	600			- 4	4,556	3,400 4,250		
RSIG ZM Compression GmbH			î î		_	x		-+	-		į.		OF /		68,450.00 (1,280.0				· }	- 4	5,695	10,780		
ckhardt Compression AG			x x		+-	x				ł		·	OF/		0.068,1) 00.004,00	14,500	600	· · · · · · · · · · · · · · · · · · ·			14,445	10,760	150	4
ckhardt Compression AG			x x		1	1-	1	- 1 -	+	÷	1		OF			4,350				\rightarrow	2,800			+-
ckhardt Compression AG			x x		1	x	\rightarrow	-	_	_	†	1	OI.	+	+	50,000				1	47,600			1-
neron's Compression Systems Group			x		_	i :			+	-+-	1	1 1	OI	!		5,500	379	40,000	54,233	6	970	722	265	:
neron's Compression Systems Group			x x		1	1-1	1		-+-			1	01			5,500	379	40.00D	54,233	6	845	630		
neron's Compression Systems Group			x x				- 1	-+-	\neg		,	1 1	OI		†	5,500	379	40,000	54,233	6	800	597		
neron's Compression Systems Group			x x	×	T					1	1 1	1	OI	:		5,500	379	40,000	54,233	6	726	541		
neron's Compression Systems Group		AJAx DPC 2803 STD	K X			† · ·	i				1		OI	T		5,500	379	40,000	54,233	6	633	472		
eron's Compression Systems Group		AJAx DPC 2803 LE	K X			- 1				1	1 1		OI	1		5,500	379	40,000	54,233	6	600	447		
eron's Compression Systems Group			ĸ x		-	1 1	- 1	.*		1 -			OI			5,500	379	33,000	44,742	6	465	347		
eron's Compression Systems Group		AJAX DPC 2802 STD	K X	X	Ш.								01	i	1	5,500	379		44,742	6	422	315		
neron's Compression Systems Group			x x	X		1					I 1		OI	i	1	5,500	379	33,000	44,742	6	384	298		
eron's Compression Systems Group		AJAx DPC 3401 LE	K X	x	l								OI			5,500	379		40,675	6	232	173		
eron's Compression Systems Group			κ x	x									Oi	1		5,500	379	30,000	40,675	6	192	143		
neron's Compression Systems Group		AJAx DPC 2801 LE	K X	x		1			1.	1			OI	1		5,500	379		40,675	6	192	143	265	,:-
neron's Compression Systems Group		AJAx DPC 2202 STD	K X	×				i					01	1	I	5,500	379	30,000	40,675	6	295	220	265	
neron's Compression Systems Group			ĸ [x		1		i].	L				01		1	5,500	379			6	295	220	265	
neron's Compression Systems Group			ĸ x	×	L .		1	T	1	I			OI			5,500	379	30,000	40,675	6	147	110	265	
neron's Compression Systems Group			c x	x	Ш.		1	1		II.	أك		OI		l'	5,500	379	30,000	40,675	6	147	110		
neron's Compression Systems Group		SUPERIOR C-Force 34			×	x		1.							I	5,808	400	13,000	57,827		580	432		
neron's Compression Systems Group			∢ [x	1.7	x	x	-	_Ľ.	I						1	5,808	400		57,827		290	216		
neron's Compression Systems Group	1		∢ İx		x	x		T	-	1		i i			T	2,200	152		177,929		1,188	886	600	
eron's Compression Systems Group		SUPERIOR RAM54																						

Positive Displacement Compressor Specifications

				,	Recip	rocati	ng	!			Rota	ary			Inlet Flow Range-	acfm(m3/min)		Allowable Pressure		Allowable Load	- ;	Maximum Pow		Spee	ad R
Manufacturer	page	Model Designation	Single Stage	Multiple Stage Integral Engine Driven	Separable	Balanced Opposed	Diaphragm	ght	Helical Lobe Screw	Siding Vane	Soroll Soroll	Trocholdal	Liquid Ring	OF = Oil Free/OI = Oil Injected	min	max	Bisd	par	Max Rod Load-lb	Max Rod Load Newtons	Compression Ratio per stage	ይ	KW	min .	
ameron's Compression Systems Group	1	SUPERIOR MH62	× 1	< :	×	×	 		ł	1	+ -			. •			8,000	552	52,000	231,308		1,800	1,343	600	0 1
ameron's Compression Systems Group		SUPERIOR MH64	X :	< !	×	x	L					- 4 -					8,000				I	3,600	2,685		
ameron's Compression Systems Group			X :		x	×			_		_			1			8,000					5,400	4,027		
ameron's Compression Systems Group			× į		×	×											8,000					1,800	1,343		
ameron's Compression Systems Group		SUPERIOR WH64	× :		x	×		\perp	_	_	_						8,000					3,600	2,685		
ameron's Compression Systems Group			×		×	×				-+-							8,000					5,400	4,027		
ameron's Compression Systems Group			× i		X	×	-	- 1		-		-	-	1			8,000					1,700	1,268		
ameron's Compression Systems Group			× :		×	×		\vdash	+	_	+	-	-				8,000					3,400 5,100	2,535		
ameron's Compression Systems Group ameron's Compression Systems Group		SUPERIOR WG62	K .	:	× .	X	····		- 1	+	1		_	+			8,000				-	3,000	3,803		
ameron's Compression Systems Group			K .		×	x	\vdash	+	+	+	-i-		+-	+			8,000				-	6,000	4,474		
ameron's Compression Systems Group			K .		×	×		l t	+-	-+-	•	*	+	+			8,000					9.000	6,711		
ameron's Compression Systems Group		SUPERIOR WG72	2	· ·	.^			1	1	+	*	+-	-	_			8,000	552				2,500	1,864		
ameron's Compression Systems Group					x	x			$^{+}$		+-			1			8,000				\rightarrow	5,000	3,728		
ameron's Compression Systems Group		SUPERIOR WG76	x 1	<	×	x	1 1				7		1		1		8,000				- 1	7,500	5,593		
ombined Heat & Power, Inc.		250		(×			QI			300					30	22		٥
ombined Heat & Power, Inc.		275	K :	<				. I.			×		T	01			300					40	30		
ombined Heat & Power, Inc.		312	K :	(1						×			01			300					40	30		
ombined Heat & Power, Inc.		350		(_					x			Ol	1		1,100					150	112		
ombined Heat & Power, Inc.	_	410				<u> </u>				ļ	x			OI.			1,100					225	168		
ombined Heat & Power, Inc.	- 1	500	<_ :			-					X	_		OI			1,100					338	252		
ombined Heat & Power, Inc.		700			-	-			—i	_	x	_	_	OI			1,100					900	671		
ombined Heat & Power, Inc.		1000			+	-		-	-	_	X	-		OI			1,100					2,910	2,170		
ombined Heat & Power, Inc.		7*ESH/ESV	K	١.	+	-	-				×	+	_	OF/O			1,200	83		2,585	52	4,500	3,356		
resser-Rand		11"ESH	-1	-	+	+							_	OF/O			12,000	827 827		5,621	112	4	180		
resser-Rand		38KVR			+		-		_	_	_		1	10170			1		150,000	5,021	672	- O		2,237	
resser-Rand		410KVR	i fi	. X	-	+				-+				1					150,000		672			2,797	
resser-Rand		412KVSE		x x	+					1 -	-			_					95,000	-	426	- 1		2,126	
resser-Rand		412KVSR	()	×									1 .						95,000	1 1	426	- 1		2,115	
resser-Rand	- 1	512KVR	()						- [1			- †	1	!		1		150,000	1	672			3,356	
resser-Rand		AVIP	1	1	×	x				-1-	-			OF/O			6,600	455	15,400	68,500	69	4	1,300	969	ě
resser-Rand		BDC-OF8.5	,	(x			-					OF/O			12,000	827	38,500	8,656	172	4	4,000	2,983	3
resser-Rand		BDC-OFI2H		(x			_ [OF/O			12,000			20,234	403	4		6,115	
resser-Rand		BDC-OF18H3				X								OF/O			12,000	827		1,712,000	1,725		38,000		
resser-Rand		BOS	;	c	x	X		<u>i _</u>				1		OF/O			8,800	607	90,000	400,320	403	4	11,250	8,389	ð
resser-Rand		BVIP			X	X						- 1	1 -	OF/O			6,600	455	24,200	107,640	108	4	2,125	1,585	ŝ
resser-Rand		CVIP		-	x	х		_		_	_		-	OF/O			6,600	455		146,780	148	4		2,148	
resser-Rand resser-Rand		DVIP HHE-F8	- +3	:	×	X				-	+			OF/O			6,600 12,000	455 827	45,000 36,000	200,160 8.094	202 161	4	5,625		
resser-Rand resser-Rand		HHE-VB	1	:	·	x		- +			+	+	-	OF/O			12,000	827	60,000	13,489	269	4			
resser-Rand		HHE-VE	-13	+-	+	x	-				+-	+		OF/O	<u> </u>		12,000	827	72,000	16,187	323	4		4.045	
resser-Rand		HHE-VG	-13	-	1	- Č		1	-	+	+			OF/0			12,000	827		28,103	560		10,630		
resser-Rand		HHE-VK	1	. -		x		1	.	+ -	-+	+	-	OF/0			12,000	827		31,475	627		10,390		
resser-Rand		HHE-VL	- 5	-+-		×		-+		_	-	-		OF/O			12,000	827		49,460	986		22,500		
resser-Rand		HOS	1		×	x		i †	1			-	_	OF/O			6.600	455			269		7,200		
resser-Rand		Super-HOS)	1	×	×					1		-1	OF/O		-	8,800	607	75,000	333,600	336		8,700		
resser-Rand		HSE	-		1	x				1	1			OF/O	· · · · · · · · · · · · · · · · · · ·		12,000	827		6,969	139	4		746	6
esser-Rand		PHE	,		L.,	х						i		OF/O			12,000	827	11,500	2,585	52	4	240		
resser-Rand				x	1	Ĺ.,			T	T		_i_							130,000		582			3,505	
resser-Rand				x	_	ļ -		_				.	1.		l		1		130,000	ļ. Ţ	582			4,177	
resser-Rand		TCVD-8		×	4 -	4	1	+		i	į.	1	. 						130,000		582	ļ		3,043	
resser-Rand		TCVD-10		X	+	 	\vdash	-+		_:_	<u>.</u>								130,000	 	582			3,804	
resser-Rand resser-Rand		TCVD-12 >		X	+			-+			-		1	į	l 				130,000		582 448	i		1,790	
resser-Rand resser-Rand		TLAD-6 TLAD-8		X	+	+	 -i	.	7.1			-	+	+					100,000	-	448			2,387	
resser-Rand				×	+-	<u> </u>	 	- +-			+		+	+					100,000		448			2,387	
resser-Rand					+ -	¥ :	1	+-	-+-	;	· •	1		OF/O			10,150	700	100,000	+ +	****	4	26,820		
resser-Rand		ε			† 1	×		. +	1	ł	:	1	1	OF/O			10,150	700		+	ł	5	26,820	****	÷
resser-Rand		Ď			+	×			· †	- +	4	+	_	OF/O			10,150	700		 	- +	5	15,421	####	á.

Data Courtesy COMPRESSORTechTwo magazine. Additional current data available at www.compressortech2.com or www.CTSSNet.net

		$\perp \perp$	1	Recipro	ocating	,				Rota	ry		1-0-	Inlet Flow Rai	nge- acfm(m3/min)	Working			Load		ower	Spe	ed Ra
Manufacturer	page Model Designation	Single Stage Multiple Stage	Integral Engine Driven	Separable	Balanced Opposed			Helical Lobe Screw	Single	Scroll	Trochoidal	Liquid Ring	OF = Oil Free/OI = Oil Injecte	min	N N N N N N N N N N N N N N N N N N N	Bisd	bar	Max Rod Load-lb	ewto	Compression Kato per stage	KW	min	
resser-Rand	A	x x			×		+	-	+	+-	+-	+-	OF/O			10,150	700		<u> </u>	-		93 3,50	
resser-Rand	M	x x	i		x				_			<u> </u>	OF/O			10,150	700	1.				113 1,80	
merson Process	SZO22C3A		-	\vdash	-	-	-	+	×	_	-	+	OI	, 13.5 27					-		16	2,40	
merson Process	SZO44C1A SZO44C1A								×		1	+ -	01	27		215 400					32	2.40	
merson Process merson Process	SZO56C1A	-	+	-	-	-	-	+	- X	_		+	OI	35					4		32	2.40	
aro Process	AM. ASM. AB			+ }		. +	- 1	Į	×		1	+	OF		2,931.00 (83.00)	500	14	-				500 50	
E Oil & Gas AC	From 85S15 to 250xxd.5		1	+ +			1			-+-		+	OF	600.00 (17.00)	40,000.00 (1,130.0		41		ł -	9 13,4		00,1,30	
BE Oil & Gas High Speed Reciprocating Compressors	A	xx	+	v	x	-	<u> </u>	-		_	-	+		30.00 (0.85)	5,650.00 (160.00)	6,000	414	14,500	64,520			300 90	
E Oil & Gas High Speed Reciprocating Compressors	DS	x x	1		ž I		- 1	- -				† :		45.00 (1.30)	14,840.00 (420.00)	6,600	455			4 2,4		300 70	
E Oil & Gas High Speed Reciprocating Compressors	ES	x x	+		x I	-+-			-		-			38.00 (1.10)	21,900.00 (620.00)	6,600	455			4 7,20	00 5.4	100 70	00 1
E Oil & Gas High Speed Reciprocating Compressors	FS	x x	1		×		-	\perp	-		-			38.00 (1.10)	21,900.00 (620.00)	6,600	455			4 7,2		100 70	
E Oil & Gas High Speed Reciprocating Compressors	н	x x			x				- 1				01 & 0	27.50 (0.78)	1,943.00 (55.00)	6,000	414	10,000	44,480	4 4	00 3	300 90	00 1
E Oil & Gas High Speed Reciprocating Compressors	M	x x	1		×				1			-	8 10	27.50 (0.78)	955.00 (27.00)	6,000	414	6,000	26,680			90 90	
E Oil & Gas Nuovo Pignone	AVTN	x x		x									OF/O	5.00 (0.14)	475.00 (13.00)	6,500	450					135 15	
E Oil & Gas Nuovo Pignone		x x	1	x				- I				J		10.00 (0.28)	1,840.00 (50.00)	6,500	450			9 1,0		300 15	
E Oil & Gas Nuovo Pignone		x x	1	x	x l	1	1.					l		39.00 (1.10)	15,500.00 (425.00)		450			6 2,8		120 35	
E Oil & Gas Nuovo Pignone	HB	x x	_		x		_							36.00 (1.00)	29,000.00 (800.00)	6,500	450			9 7,4		520 30	
E Oil & Gas Nuovo Pignone		x x	_		x	_	_				_	_		40.00 (1.10)	61,500.00 (1,700.0		750			9 13,9			
E Oil & Gas Nuovo Pignone	HE	X X			X							1		45.00 (1.20)	114,500.00 (3,100.		750				00 21,5		
Oil & Gas Nuovo Pignone	HE-S	x x			x							┿.		45.00 (1.20)	114,500.00 (3,100.		750				00 16,2		
E Oil & Gas Nuovo Pignone	HF	x x	-		X							┼-	OF/O	66.00 (1.80)	143,500.00 (3,900.	11,000	750				50 28,5 30 41,0		
E Oil & Gas Nuovo Pignone	HG HM	x x			x	-	\rightarrow					\vdash	OF/O	97.00 (2.70) 57.00 (1.60)	144,000.00 (3,900.16,500.00 (450.00)		750 450		1,550,000	6 4.8		300 28	
E Oil & Gas Nuovo Pignone E Oil & Gas Nuovo Pignone	OA OA	X X	+		x	+	-+-					-		20.00 (0.60)	3,150.00 (85.00)	6,500 6,500	450					135 30	
E Oil & Gas Nuovo Pignone	OC	X X	+	X	-			-	- i-	_	-			20.00 (0.60)	4,250.00 (115.00)	6,500	450					700 25	
E Oil & Gas Nuovo Pignone	5 PH	ı x	_	,	×	-	-	\pm	- :	_	-	+	OI	10.00 (0.28)	841.00 (23.00)	50,800	3,500			6 12.8		300 17	žā!
E Oil & Gas Nuovo Pignone	PK	×			x	_	-						OI	12.00 (0.33)	1,201.00 (33.00)	50,800	3,500			6 80.5			
E Qii & Gas Nuovo Pignone	SHM	x x	1		×	1					_		OF/O	42.00 (1.20)	33,500.00 (920.00)	6,500	450	80.565		6 11.10	8.2	200 25	50 1
E Oil & Gas Nuovo Pignone	SHMB	x x		x	x	- 7	- 1			\neg			OF/O	42.00 (1.20)	22,300.00 (610.00)	6,500	450	80,585	358,065	6 7,4	40 5,4	174 25	
reenField	CT	×		x		- (OI	71.00 (2.00)	424.00 (12.00)	6,550	450		32,000	4 2	30 1	170 57	
reenField	CU	x	1	x									OI	32.00 (0.90)	194.00 (5.50)	7,250	500	80,000	18,000			90 58	
reenField	CC	x		x									OI	11.00 (0.30)	67.00 (1.90)	5,000	350	40,000				45 60	
reenField	CN	x		x				_					OI	9.00 (0.25)	34.00 (0.96)	5,000	350					20 73	
reenField	DM	x			х		_						OF	7.00 (0.20)	37.00 (1.05)	4,500	310		10,000	4		36 1.45	
AUG Kompressoren AG		x x									1		OF	-0.1			150			-		90 70	
tachi, Ltd./Hitachi Plant Technologies, Ltd.	BMD	×	ļ						_	-	_	-		10.60 (0.30)	11,654.00 (330.00)		500		i	4 5,3		000 30	
tachi, Ltd./Hitachi Plant Technologies, Ltd.	BSD				X				\rightarrow	- : -	_	+		10.60 (0.30)	11,654.00 (330.00)	12,360	350		-	4 5,3		000 30	
tachi, Ltd./Hitachi Plant Technologies, Ltd.	BTD	1. 1		ŧ ŀ	×	- 4		- i	- 4	+		ļ		10.60 (0.30)	11,654.00 (330.00)	35,300	1,000			4 5,3		000 30 268 30	
tachi, Ltd./Hitachi Plant Technologies, Ltd. owden BC Compressors	HSD Burton Corblin a P series	×	ļ	! !						—i—	-	+ —	OF	3.50 (0.10)	1,060.00 (30.00)	35,300 3,600	250		220,000	4 3.4		500 20	
wden BC Compressors		x x	+-	-	~	-			+	+	+	•	OF	0.06 (0.00)	120.00 (3.50)	43,500	3,000					100 20	
owden BC Compressors	Burton Corblin a HPD series	^ ×	- -	+	× ;) - -	- 1	- }	- 1	1	+ -	ŧ	OF	35.00 (1.00)	412.00 (12.00)	6,500	450					700 20	
owden Process Compressor	xRV127/R1	: "	1	1 1	ľ	`	İ	- 1 -		_	1-	+	OI	00.00 (1.00)	207.00 (5.86)	300	20					150 3.00	
owden Process Compressor	xRV127/R3		7				x		_	-			Oi		280.00 (7.93)	300	20					150 1.80	
owden Process Compressor	xRV127/R5	: 1		1 1	- 1	1	×	ı				†	OI		345.00 (9.77)	300	20			10 2	00 1	150 1,80	00 :
owden Process Compressor	xRV163/165	1	·				x	-		-:-			QI.	T	420.00 (11.89)	300	20	1		10 3	50 2	260 1,80	00 :
wden Process Compressor	xRV163/193		i				×					1	OI		500,00 (14.16)	300	20					260 1,80	
wden Process Compressor	xRV204/110	i L					×	1		1			OI		573.00 (16.23)	300	20		1. 7			1,80	
wden Process Compressor	xRV204/145	1 -1	J	-			×			- 1		1	OI	ļ	756.00 (21.41)	300	20					150 1,80	
wden Process Compressor	xRV204/165	1 4	ļ			1.	1	ļ				-	01		860.00 (24.36)	300	20		. :			1,80	
owden Process Compressor	xRV204/193		-			-	-			-	+-	+-	OI	247.00.00.00	952.00 (26.96)	300	20				00 4	1,80	
owden Process Compressor	GTV 228	1 4	÷		- 1.	4-	X	. -	-			ļ., .	OI	217.00 (6.00)	682.00 (19.00)	870	60			3	70	1,25	
owden Process Compressor	WRV 163/145	1 1	1		1	- 1	×	-				<u></u>	OI		397.00 (11.24)	350	. 24					350 1,50	
wden Process Compressor	WRV163/1.80		-	-	-	+	X	+					01	<u> </u>	478.00 (13.54)	350	24		+ +	12 1,0	70 3	350 1,50	
owden Process Compressor owden Process Compressor	WRV204/1.10 WRV204/1.45		i -		\rightarrow	-	X	-+-		- 1 -	-	j -	10	<u> </u>	570.00 (16.14) 775.00 (21.95)	350 350	24 24			12 1,0	20 /	766 1,50 766 1,50	00
owden Process Compressor owden Process Compressor	WRV204/1.45		1			. }	×			+	1		OI	į	855.00 (24.21)	350	24			12 1,0	28 7	766 1,50	
owden Process Compressor	WRV204/1.93	1 .	1	i i			1	1	· ; -	-+-	+	+	OI.		962.00 (27.24)	350	24			12 1,0		766 1,50	
owden Process Compressor	WRVi 255/1.10	+	+-		-+		- î	+	- †	+		+	OI		1,114.00 (31.55)	350	24		- · · · · · · · · · · · · · · · · · · ·	12 1.5		150 1.50	
wden Process Compressor	WRVI 255/1.30	4	-	t					L	I		1	OI -		1,253.00 (35.48)	350	24					150 1.50	

Positive Displacement Compressor Specifications

				. !	Recip	orocati	ng				Ro	tary	,		Inlet Flow Ra	nge- acfm(m3/min)		Allowable Pressure		Allowable Load		Maximum Pow		Speed	Range
Manufacturer	page:	Model Designation	Single Stage	Multiple Stage Integral Engine Driven	Separable	Balanced Opposed	Diaphragm	Straight Lobe	Helical Lobe Screw	Single	Sliding Vane	Scroll	Trochoidal	Liquid King OF = Oil Free/OI = Oil Injected	min	a x x x	bisd	bar	Max Rod Load-lb	Max Rod Load Newtons	Compression Ratio per stage	웊	KW	Ē	тах
Howden Process Compressor		WRVi 255/1.45			+	†			x	-				OI		1,514.00 (42.88)	350	24			12	1,542		1,500	
Howden Process Compressor Howden Process Compressor		WRVi 255/1.85 WRVi 255/1.93	\vdash	- :	+				X			-		OI		1,670.00 (47,29)	350	24			12	1,542	1,150		3,600
Howden Process Compressor		WRV255/2.20	!	-	1	-	-		x	-	-			OI	 	1,879.00 (53.21) 2,227.00 (63.07)	350 200	24 24		1	12	1,542	1,150 1,150		3,600
Howden Process Compressor		WRVi 321/1.32				+			÷-			+	- 1	OI		2,673.00 (75.70)	350	24		:	12	2,741	2.044		3,600
Howden Process Compressor		WRVi 321/1.65				+			x	- :			_	OI		3,341.00 (94.62)	350	24		: 1	12	2,741	2.044		3,600
Howden Process Compressor		WRVi 321/1.93			Ť.				x		- 1	1		OI		3,758.00 (106.43)	350	24			12	2,741	2,044	1,500	3,600
Howden Process Compressor		WRV321/2.20			1 .				x					OI		4,510.00 (127.72)	200	24			8	2,741	2.044		3,600
Howden Process Compressor		WRVi 365/145			1	÷			х					OI		4,144.00 (117.36)	350	24		T	12	5,814	4,335		3,600
Howden Process Compressor		WRVi 365/165	_	\vdash	<u> </u>	-	-		x	i	[.	- 1		OI	4	4,716.00 (133.56)	350	. 24	ļ.		12	5,814	4,335		3,600
Howden Process Compressor		WRVI 365/193 WRVT510/1.32				1 -	÷		X	.	+	-	+	01	+	5,516.00 (156.21)	350	24			12	5,814			
Howden Process Compressor Howden Process Compressor		WRVT510/1.32 WRVT510/1.65	\vdash	-+-		+	-		X	\rightarrow	-			OI	-	6,022.00 (170.54) 7,528.00 (213.19)	350 350	24 24			12	6,700	5,000		
Howden Process Compressor		WRVT510/1.93		_	-	1	İ		x			- 1		OI		8,266.00 (234.09)	350	24			12	6,700	5,000		2,000
Howden Process Compressor		H127/165			-	_			x		\rightarrow	-	-	OF		794.00 (1,350.00)	130	10		1	4	286		7,500	
Howden Process Compressor		HP204/110	T)		1				X		- 1	- 1	. †-	OF		1,341.00 (2,273.00)	200	15			4	800		4,750	
Howden Process Compressor		H204/165			T		T - "		x					OF	T	2,012.00 (3,420.00)	130	10			4	800	600	4,750	9,500
Howden Process Compressor		HP255/110							X					OF		2,070.00 (3,519.00)	200	15			4	1,250		4,000	7,500
Howden Process Compressor		H255/165				_			×					OF	i	3,105.00 (5,279.00)	130	10		L	4	1,250		4,000	
Howden Process Compressor Howden Process Compressor		HP408/110 H408/165	\vdash		+-	+			X X					OF OF		5,308.00 (2,597.00) 7,961.00 (13,532.00	200 130	15 10		-	4	3,050	2,275	2,300	
Howden Process Compressor Howden Process Compressor		HP510/110				+			Č I	+	-		-	OF		8,266.00 (14,050.00	200	10		-	4	4,000			3,750
Howden Process Compressor		H510/165	-	_	+	+			Ŷ				-+-	OF		12,397.00 (21,074.0	130	10		ł -	4	4,000			
Hycomp, Inc.			x			+	1		^				-	OF	1.82		1,000		2,800		5	8	2,000	400	825
Hycomp, Inc.			x		1	T.				7	-			OF	2.84	5.86	1,000		2,800		5	8		400	825
Hycomp, Inc.			x			1	l							OF	2.84		1,000		2,800		5	8		400	
Hycomp, Inc.			х		-	-	_		_	-		-		OF	4.09		1,000		2,800		5	- 8		400	825
Hycomp, Inc.			X		+	+		Н	_	-+			<u>.</u> .	OF	0.45		1,500		2,800		- 5	8		400	825 825
Hycomp, Inc.			x		+	+ -			- 1				+	OF	8,18		200		2,800		5	8		400	
Hycomp, Inc.			x	· į	+					+			-	OF	4.36		750		3,700		5	11		400	
Hycomp, Inc.			x			T .		i .						OF	4.36		750		3,700		5	11		400	
Hycomp, Inc.			x		***************************************								- 41 .	OF	6.81		600		3,700		5	11		400	825
Hycomp, Inc.			×	1 1										OF	8.81		600		3,700		5	11		400	825
Hycomp, Inc.	- i		X .	!	-	-	<u> </u>	!					_	OF	17,44		200		3,700		5	11		400	
Hycomp, Inc.			x :		-	-	<u> </u>	-			- 1		-	OF OF	17,44		1.000		3,700 4,700		5	11		400	825
Hycomp, Inc.			×		ŀ	†					-:	-	+	OF	11.45		600		4,700	-	5	20	_	400	825 825
Hycomp, Inc.			x		· · · · · · · · · · · · · · · · · · ·	1		_		- 1		-	+	OF	15.58		600		4,700	tt	5	20		400	825
Hycomp, Inc.			×		:					1	1	1	1	OF	29.44		200		4,700	† · · · · · · · · · · · · · · · · · · ·	5	20		400	825
Hycomp. Inc.	7	AN14E	X :									-		OF	9.09	18.74	800		6,300	I	5	40		400	825
Hycomp, Inc.			x		1	1		. 7					\perp	OF	9.09		800		6,300		5	40		400	
Hycomp, Inc.			x	\perp	-	-	-	<u>, , , , , , , , , , , , , , , , , , , </u>		_				OF	13.08		600		6,300		5	40		400	825
Hycomp, Inc.			×		+ -	ī					+	+	+	OF	13.08		600		6,300		5	40		400	825
Hycomp, Inc.			x	_	+-	+			\rightarrow	-				OF	17.81		600		6,300	ļ	5	40	- }	400	825 825
Hycomp, Inc. Hycomp, Inc.			×					1		-+		+	+	OF	23.26		600		6,300		5.	40	_	400	825
Hycomp, Inc.			x	-	 		_	\vdash		-+			1	OF	29.44		600		6,300	+	- 5	40		400	825
Hycomp, Inc.			×	1		1	1	1 1			- 1	+	1	OF	48.06		600		6,300	I I	5.	40		400	825
Hycomp, Inc.			×	1	T	Ι.								OF	48.06		600		6,300	1	5	40		400	825
Hycomp, Inc.		NN90	x		ļ	_								OF	60.08		600		6,300	1 1.	5	40		400	825
Hycomp, Inc.			X.	. !	+	i					i	+	1	OF	19.19		700		11,700	\vdash	5	66		400	700
Hycomp, Inc.		N28F	×		+	+		\vdash	+	-+			-+-	OF OF	19.19		700 650		11,700	ļ l	5	66	+	400	700
Hycomp, Inc.			X Y		+	+	-		·	- 4			İ	OF	29.07		650		11,700		5	66	+	400	700
Hycomp, Inc.			x		ļ			\vdash $+$	\dashv	-				OF	36.8		500		11,700	+ + +	5	66		400	700
Hycomp, Inc.		MN75F	x		+			\vdash			:	- 1	1	OF	50.08		400		11,700	: 1	5	66		400	700
Hycomp, Inc.		MN98	x			L	<u> </u>	11	1					OF	60.08		300		11,700		5	66		400	700
Hycomp, Inc.			x			1							4	OF	102.21		250		11,700	: 1	5	66	. 1	400	700
Hycomp, inc.		AD4A AN6B	. I	×				. 1		- 7		1	<u>ــا</u> ـــ	OF	2.84		1,000		2,800		5	8		400	825 825
Hycomp, Inc.														OF	4.09										

Data Courtesy COMPRESSORTechTwo magazine. Additional current data available at www.compressortech2.com or www.CTSSNet.net

			!		Reci	procati	ng				Ro	tary				Inlet Flow Ran	ge- acfm(m3/min)		m Allowable g Pressure		n Allowable		Maximum		Speed	Ra
Manufacturer F	page	Model Designation	Single Stage	Multiple Stage		Balanced Opposed	Diaphragm	Straight Lobe	Helical Lobe Screw	Single	Sliding Vane	Scroll	Trochoidal	Liquid Ring	F = Oil Free/Oi = Oil Injected	min	тах	Bysd	bar	Max Rod Load-ib	Max Rod Load Newtons	Compression Ratio per stage	£	KW	min	200
ycomp, Inc.		2AN8	٠					<u> </u>					+		ь of	5.56	11,48	50		2,800		5	8		400	
ycomp, Inc.		2AN3C			1	· i									OF.	2.18	4.5	1,50	0	3,700		5	11		400	
ycomp. Inc.		2AN5C 2AN10C	- 2			+	-	\vdash				\rightarrow			OF OF	3.41	7.03			3,700		5	11		400	
ycomp, Inc. ycomp, Inc.		2WN10C	,				+	+		\rightarrow	i		- 1		OF	5.76 6.68	11.88 13.77	500		3,700		5	11 11		400 400	
ycomp, Inc.		2AN17	١,		-	+	+	+		-	- 1				OF OF	11.04	22.77	. 501		3,700		5	11		400	-
ycomp, Inc.		2AN10D	,										- 1		OF .	6.72	13.86	751	0	4,700		5	23		400	
ycomp, Inc.		2AN15D	,		i	1	1		1	ì	1	-			OF	10.18	20.99			4,700		5	23		400	_
ycomp, Inc.		2AN26	. ,												OF.	17.53	36.15			4,700	of	5	23		400	H
ycomp, Inc.		2AN35		(1								OF	22.9	47.22			4,700		5	23		400	
ycomp, Inc.		2WN35	,		<u> </u>	-				!			-		OF	22.9	47.22			4,700			23		400	
ycomp, Inc.		2AN40	2			+	1 -			- 1	٠,		+		OF OF	26.17	53.97			4,700		5	23		400	H
ycomp, Inc.		2WN40 2WN13E	٠,		+	+	+-	-	\vdash	-			-		OF OF	26.17 8.9	53.97 18.36	1,000		4,700 6,300		5	23 43		400	
ycomp, Inc.		2AN17E	1			+	t-	+					- 1		OF.	11.63	23.99	1,00		6,300		5	43		400	
ycomp, Inc.		2WN17E				+	1	+-	\vdash		\rightarrow				OF	11.63	23.99	1.00		6,300		5	43		400	_
ycomp, Inc.		2AN22E		(1	1	1			\neg				OF	14.72	30,36	750		6,300		5	43		400	
ycomp, Inc.		2WN22E)	<			1	1							OF	14.72	30.36	750	0	6,300	j	5	43		400	
ycomp, Inc.		2AN61		(!						- T.		OF.	40.89	84.33	350		6,300		5	43		400	
ycomp, Inc.		2WN61				1276	4								OF	40.89	84.33	350		6,300		5	43		400	
ycomp, Inc.		2AN76	-			4	1	-		;			_		OF.	51.11	105.41	350		6,300		5	43		400	
ycomp, Inc.		2WN76			_	-	1	1		- 1	\rightarrow				OF.	51.11	105.41	350		6,300		. 5	43		400	
ycomp, Inc.		2AN22F	-0			į	ļ	1				-			OF .	14.54	25.44	1,000		11,700		5	72		400	
ycomp, Inc.		2WN22F 2WN28F				+	+-	1 . :	1				-		OF OF	14.54 18.4	25.44 32.2	1,500		11,700		5	72 72		400	
ycomp, Inc.		2AN28F	-,		+	+				-	_		-	- 6)F	18.4	32.2	750		11,700		5	72		400	
ycomp, Inc.		2WN38F	,	-	1		+-	1 1				+			OF OF	25.04	43.82	750		11,700		5	72		400	
ycomp, Inc.		2WN49F	,		"		+	1 -	- 1	***			\neg		OF.	32.71	57.24	750		11,700		5	72		400	
ycomp, Inc.		2AN58F	,			1 -									OF	38.39	67.18	750		11,700		5	72		400	
ycomp, Inc.	- 1	2AN137	>	(İ									OF	90.86	159	200	0	11,700		5	72		400	
ycomp, Inc.		2WN150L	-							. 1					DF	101.32	177.31	400		11,700		5	72		400	
ycomp, inc.		2VVN150H	>					i							⊋F'	101.32	177.31	500		11,700		5	72		400	
ycomp, Inc.		3AN44)					1				-			OF.	29,44	60.71	500		4,700		5	23		400	
P. Sauer & Sohn		WP156L)		_		-		\vdash)I		100.00 (2.80)	600				3	50	37		
P. Sauer & Sohn		WP276L)		+	+	-	-		-			- 1		OI .		150.00 (3.00)	_ 600				. 3	75	55		
P. Sauer & Sohn P. Sauer & Sohn		WP316L WP3215	2		ļ		+	1		-+	+		- 1		OI OI		200.00 (5.50)	600			+	3	100	75		
P. Sauer & Sohn		WP4325	1			+	+	1		\rightarrow		+	-		DI DI		10.00 (0.30)	5,000				4	17	13		
P. Sauer & Sohn		WP4331	- 13			1		+					+ -		οi.		30.00 (0.90)	6,000			1 :	- 7	35	26		
P. Sauer & Sohn		WP4341	1		. +	1		1		. 1	1				OI		55.00 (1.60)	6,000			 	4	47	35		
P. Sauer & Sohn		WP4351	>			-					_		\neg)i		75.00 (2.10)	5,000				4	70	52		
P. Sauer & Sohn	1	WP4205	x	\neg		T	T -				-	1	- 1		oi i		765.00 (21.70)	750				4	215	160		
P. Sauer & Sohn		WP4320											- T	. (DI		470.00 (13,30)	3,500				4	215	160		
P. Sauer & Sohn		WP4440	, ,										- 1			70.00 (2.00)	115.00 (3.30)	6,000				4	215	160		
P. Sauer & Sohn		WP6205	2	-		+	1	\perp		- 1	_				<u> 10</u>	320.00 (9.00)	880.00 (25.00)	750			1	4	335	250		
P. Sauer & Sohn		WP6310	, ×			1		1—				1) IC		350.00 (10.00)	1,500			1 . !	. 4	270	200		
P. Sauer & Sohn P. Sauer & Sohn		WP6440 WP6550	× ×		+		\vdash	\vdash	\rightarrow	\rightarrow)ł Di		350.00 (10.00) 210.00 (6.00)	6,000 7,250			+	4	300 175	230 132		
pbe Steel (Kobelco)			x x		-+	i,		+			+	+			OF / C		2 10.00 (0.00)	10,150			980,000	4	27,000	20,000	970	- 1
obe Steel (Kobelco)			2 - 2		+	<u> </u>	+-	1 1	× 1	- +			÷		OF / C		65,000.00	650			300,000	10	13,500	10,000	1.500	
bbe Steel (Kobelco)			X X		+	+-	\vdash		x :	×	\rightarrow	\neg			SI IC		12,000.00	1,500			1 1	15	10,000		1,000	
eobersdorfer Maschinenfabrik AG (LMF)			x x		.1.	×						. +			DF/OI			8,700			1	3	8,000			- 1
obersdorfer Maschinenfabrik AG (LMF)	9 E	EcoPET	×		1			1		. 1					OF :			580	0] 1	3	778			
obersdorfer Maschinenfabrik AG (LMF)		Compound			ì	х			x	1					OI .			6,500			1	4	1,743			_
obersdorfer Maschinenfabrik AG (LMF)		CNG	Х		<u> </u>	х	L		į	[OI :			5,075		1		4	800			1
obersdorfer Maschinenfabrik AG (LMF)		Air & Water Cooled Heavy Duty		1		×	į	, ,				.,	1		DF/OI			7,250		+	1	4	800			1
ROI-RCT		HG10000	X	+		+		. ;	×			+))			350	24	H			90		2,650	- 5
ROI-RCT ROI-RCT		101.10000	X	-	+	+	ļ		X	-			-+-		DI I			350	24	H.	1	- 1	90		1,770	
ROI-RCT			×		+	+ +	÷		X	\rightarrow		i i	- 1		ol I			350		H	1	I	125		1,500	
ROI-RCT		HGF12000	x		4	1	1	. 1	x	4.					51 -			350					125		750	

Positive Displacement Compressor Specifications

					Recip	rocatin	g			Ro	lary			Inlet Flow R	ange- acfm(m3/min)		n Allowable Pressure		n Allowable Load		Maximur Pow		Spee	ad R
Manufacturer	page	Model Designation	Single Stage	iple Sta	Integral Engine Driven Separable	Balanced Opposed	Diaphragm	Straight Lobe Helical Lobe Screw	Single	Sliding Vane	Scroll	Trocholdal	Liquid Ring	min	шах	Bysd	bar	Max Rod Load-lb	Max Rod Load Newtons	Compression Ratio per stage	Ŧ	KW	i E	
eROI-RCT		HG17xxx	×		1		- 1	×			- 1		OI			300					175	130		
eROI-RCT		HGS17xxx	х					×		i. I	1.		OI			350					175	130		
eROI-RCT	4	HGSF17000	×		1	4 -4		×	ļ.,,				OI			350					175		1,100	
ROI-RCT		HG24xxx	x		_	1		×	1			- ;	OI			250					350		500	
ROI-RCT		LG30xxx	×				j.	×	ļ				OI	-		200					600			
ROI-RCT		LGL30xxx	x		1		_i	x					OI			150			1		800			
ROI-RCT		HGT17		x		L		×		iL			OI			500					400			
ROI-RCT		HGT24	!	x	1	1. 1	l.	x					OI			500			i		600	447	500	
AN TURBO AG (Oberhausen)		CP	1					x	1				OF	120.00 (3.00)		725			: 7		4,000			
AN TURBO AG (Oberhausen)		Skuel		1.	1	4 I		x	\perp		_ (OF	2,000.00 (56.0	0.007(1,700.00)				:		8,700			
hrer Kompressoren GMBH & Co.		TE,	×										OF			580				i.	72			
ehrer Kompressoren GMBH & Co.		TZ	j	x			£		! -		[OF	L	1	300					100	75		
hrer Kompressoren GMBH & Co.		TVB 700	x			1		1 .	1				OF			854						90		
hrer Kompressoren GMBH & Co.		TVB 900	X			\perp						- :	OF			854					270			
hrer Kompressoren GMBH & Co.		TVE 700	x			4 I				L[OF			100				i		90	600	
hrer Kompressoren GMBH & Co.		TVE 900	X			11			-				OF			100			1		270		400	
hrer Kompressoren GMBH & Co.		TVZ 700		x			_		1		- :		OF			363			i			90	600	
hrer Kompressoren GMBH & Co.		TVZ 900		x .									OF			363					270		400	
hrer Kompressoren GMBH & Co.		TVD 700		X		!					i_		OF			854						90		
hrer Kompressoren GMBH & Co.		TVD 900		X		. ,				LI.			OF			854			1	. 1	270			
hrer Kompressoren GMBH & Co.		BST (air)				1	×		!	LI			OF	18	1,765.00						480	355	####	#
hrer Kompressoren GMBH & Co.		TRZ		x		L		. 1 .					OF			363		ii.						┙
ehrer Kompressoren GMBH & Co.		TRE	x			1							OF			102			l l					Ţ
ehrer Kompressoren GMBH & Co.		TRB	х						_	Li	- 1-		OF			580			L I	. l.				\perp
sui Engineering & Shipbuilding	1	C Series	X	x		×							OF.		14,125.00 (400.00)				1	7 ₁	24,138			1
sui Engineering & Shipbuilding		MB Series	X	X_		×		-:-		<u> </u>			OF.		14,125.00 (400.00)				1	7	134	1,000		4
COM CANADA LTD.		V series	х		<u> </u>	1		X					OI	150.00 (4.00)	8,100.00 (230.00)	350			L I	20	2,500			
COM CANADA LTD.		C series		X		I i		×			- 1.		QI.	250.00 (7.00)		350				30	2,000			
COM CANADA LTD.		GR series	x	_				×	ļ		_		01	250.00 (7.00)	600.00 (17.00)	260				20	300		1,890	
COM CANADA LTD.		GH series	X	-		\longrightarrow	_	×	-		- 1-		OI	250.00 (7.00)	2,300.00 (65.00)	750				20	2,700			
COM CANADA LTD.		VR series	x					×					OI	200.00 (6.00)	2,100.00 (80.00)	300				20	1,500			
COM CANADA LTD.		UD/G series	x	-4	. 4.			x					OI	150.00 (4.00)		350				20	2,500			
COM CANADA LTD.		FM series	X		ļ	1_1		x					OI	100.00 (3.00)	400.00 (12.00)	300			L	20	300		1,500	٥
COM CANADA LTD.		WA series		x	X				Ь.		- 1		01	40.00 (1.00)	220.00 (6.00)	300			l	20	100		600	3
COM CANADA LTD.		WB series	×	x	×				1				QI	220.00 (6.00)	670.00 (19.00)	300				20	300		600	3
COM CANADA LTD.		M series	X		×	\sqcup	_						OI	200.00 (6.00)	700.00 (20.00)	400	27			15	300	225	900	٥
COM CANADA LTD.		K series	х	_	x	1	_		1				OI	50.00 (1.00)	350.00 (11.00)	300				15	75			
COM CANADA LTD.		C series		х	×	I. I		1	ļ				01	30.00 (1.00)	90.00 (3.00)	300				15	20		1,000	
tural Gas Services Group / SCS		PHT2		×	×	X.		\perp					Oi	5.00 (0.14)	585.00 (16.60)	3,050				4	400			
ural Gas Services Group / SCS		PHT4	×	× L	×	x			<u>.</u>	ļ. ļ	- 1	1	01	10.00 (0.28)	1,170.00 (33.20)	3,050				4	400			
tural Gas Services Group / SCS		PVT2		×	×	x		ļ	-	-		-÷-		/ C 3.00 (0.08)	270.00 (7.65)	2,000				4	100			
tural Gas Services Group / SCS		PVT4		X :	×	x	-	i	-	L	- 1			/ C 6.00 (0.16)	540.00 (15.30)	2,000				4	150	112		
tural Gas Services Group / SCS		PxT2		X	×	x			ļ		- 1		OI	5.00 (0.14)	585.00 (16.60)	3,050				4	250			
ural Gas Services Group / SCS		PxT4	×		×	x	1						OI	10.00 (0.28)	1,170.00 (33.20)	3,050				4	250			
UMAN & ESSER Deutschland GmbH			5 x						_	L	:	1.	OF		105.00 (3.00)	710			25,000	4	135			
UMAN & ESSER Deutschland GmbH	1		0 ×	×		1. 1							OF		840.00 (24.00)	4,540			80,000	4	540			
JMAN & ESSER Deutschland GmbH	+		3 x			X	— i-	_	-			- i	OF		3,500.00 (100.00)	9,940			150,000	4	1,340			
JMAN & ESSER Deutschland GmbH	i_		0 x		+	х .			1 4		_		OF		7,700.00 (220.00)	9,800			250,000	4	1,600			
JMAN & ESSER Deutschland GmbH				×	.i	X			+	-	+	\rightarrow	OF		13,000.00 (370.00)	9,800			380,000	4	3,400			
UMAN & ESSER Deutschland GmbH UMAN & ESSER Deutschland GmbH				x		×	-				- ;	1	OF		22.400.00 (640.00)	9,800			560,000	4	6,700			
UMAN & ESSER Deutschland GmbH UMAN & ESSER Deutschland GmbH		320 hs		×	4	× -			+	- ;	-	-	OF.		37,800.00 (1,080.00				800,000		6,700			
UMAN & ESSER Deutschland GmbH UMAN & ESSER Deutschland GmbH	-			X		×	-	+	+ +	÷			OF		7,900.00 (226.00)	9,800			470,000		9,800			
UMAN & ESSER Deutschland GmbH		BV35		X		×	- }			-	-	-	OF		150,000.00 (4,500.0				1,500,000	4	40,000			
UMAN & ESSER Deutschland GmbH		V1	X.	X.	1	+ +		+	+	\rightarrow		+-			315.00 (9.00)	710			38,000	- 11	135			
			x	x	+	++		-	+		į.		OF		1,120.00 (32.00)	3,550			110,000	. 4	335			4
dro Gil S.A.		RTN OR 25 (2 to 25 HD)	-		+	1 +	×		+ +		-4		OF	1.00 (0.03)	170,00 (48,00)	29	2				422	315	ļ	+
incy Compressor		QR-25 (3 to 25 HP)	×	x x	-	I +	\rightarrow		-		-+-			+	+	 	+							1
incy Compressor		QT (3 to 15HP)	X	X X	+	 +	-	+	+			- 1-						-						+
		QTS (1 to 5 HP)	×	×	i	1 1		1	1 1	1		- 1		1	1		1	1	1 1					- 1
ncy Compressor		QRDS (5 to 30HP)	x	+-	-		- 1	1	+ · ·	- +-														-+

Data Courtesy COMPRESSORTechTwo magazine. Additional current data available at www.compressortech2.com or www.CTSSNet.net

				$oxed{oxed}$	Red	ciproca	ating				F	Rotary				Inlet Flow Ra	nge- acfm(m3/min)		Allowable Pressure		m Allowable d Load		Maximur Pow		Speed	Ran
Manufacturer	page	Model Designation	Single Stage	Multiple Stage	Integral Engine Driven	Raiancad Opposed	Disobrace	Straight Lobe	Helical Lobe Screw	Single	Sliding Vane	Scroll	Trochoidal	Liquid Ring	OF = Oil Free/OI = Oil Injected	uju	тах	gisd	bar	Max Rod Load-lb	Max Rod Load Newtons	Compression Ratio per stage	Ġ.	KW	u E	max
Quincy Compressor		6 (5 to 15 HP)							x	1_					01	0	0				1	11	15		1,500	
Quincy Compressor Quincy Compressor		3 (7.5 to 60 HP) (50 to 200 HP)		-+-		-	+		X	+	<u> </u>				01	27.00 (0.77) 238.00 (6.74)	284.00 (8.04) 998.00 (28.27)	150 150			-	11	60 200			6,5
Quincy Compressor		(50 to 300 HP)		_		1	1	1	×	+					OI.	245.00 (6.94)	1,500.00 (42.49)	210				15			1,800	1,8
Quincy Compressor		(400 to 500 HP)	ТŤ		-		$^{-}$		×						OI.		2,670.00 (75.63)	125		3	1	10			1,200	2.0
RO-FLO COMPRESSORS	4CC		X	- 1			. [1	x					OI	10.00 (0.25)	80.00 (2.30)	80		5	1	4		11	865	2.2
RO-FLO COMPRESSORS	5CC		X	+	1	\perp			4	x					01	24.00 (0.68)	110.00 (3.16)	80		5		4	15	11		2,2
RO-FLO COMPRESSORS	7D 8D		X	+	+	-+-		-	1 -	Х	1 .		_		01	53.00 (1.50)	198.00 (5.61)	80			-	4		25		1,4
RO-FLO COMPRESSORS	8DE		×			+ + -	1	+-	+-	X	+	\vdash			01	87.00 (2.46) 107.00 (3.03)	343.00 (9.71) 446.00 (12.63)	80		ļ	+	4	60	35 45		1,4
RO-FLO COMPRESSORS	10G		×	+	+	+-	+-	+	+	X	i				OI	126.00 (3.56)	674.00 (12.03)	80			+	4		77		
RO-FLO COMPRESSORS	118		x	1		1		ļ	Ĺ.	x	<u>i </u>				OI	204.00 (5.78)	862.00 (24.41)	80				4	162	121		1,
RO-FLO COMPRESSORS	11L		x	T	7					x					01	232.00 (6.56)	986.00 (27.93)	80				4	168	125	400	1,
RO-FLO COMPRESSORS	125		x :	+	+	-	1		-	X	ļ., i				01	252.00 (7.13)	1,024.00 (29.01)	80				4	213	159	380	
RO-FLO COMPRESSORS RO-FLO COMPRESSORS	12L 17S		× -		-		-			x	\vdash	H	_		01	280.00 (7.93)	1,159.00 (32.83)	80				4	222 345	166	380	_
RO-FLO COMPRESSORS	17L		x i	+	÷	+	+	+	+	x		\vdash			OI	325.00 (9.21)	1,378.00 (39.05) 1,594.00 (45.16)	80			1	4	400	257 298	310	
RO-FLO COMPRESSORS	198		x	\top	\neg		-		+	x	1				OI		1,895.00 (53.70)	80		5		4	410	306	275	
O-FLO COMPRESSORS	19L		x			- 1 -		-!-	+-	x	1				OI		2,165.00 (61.35)	80			T	4	390	291	275	
O-FLO COMPRESSORS	208E		X X							x					OI	15.00 (0.43)	79.00 (2.23)	150				6	96	72	600	1,
O-FLO COMPRESSORS	210	<u>, </u>	x x			_			1.	× _	-				OI	19.00 (0.53)	140.00 (3.96)	150				6		254	450	1
RO-FLO COMPRESSORS RO-FLO COMPRESSORS	2118 2128		X X	-				-+-	+	х	-	\vdash	_		01	48.00 (1,36)	245.00 (6.95)	150				. 6	450	336	400	1
RO-FLO COMPRESSORS	2171	<u>и</u>	XX			1:-	_	-	-	x					OI	58.00 (1,65) 88.00 (2,50)	276.00 (7.81) 383.00 (10.85)	150			+	6	450 474	336 353	380	-
RO-FLO COMPRESSORS	2198		x x			_			-	x	\vdash				OI	97.00 (2.75)	474.00 (13.43)	150				6	478	356	275	
SAFE S.R.L.		55-\$7-\$9	×		×				1				-		OI		-4		300		22,000	4		75	550	1,
SAFE S.R.L.	SW		×		_ X			_	1	ļ					OF/O	(-17.5		300		50,000	4		500	550	1,
SAFE, S.R.L. Sertoo	ST 350		х	4	х	-	+	_	+	-	\vdash				OF		-7.5		250		35,000	4		110	550	1,
Sertco	134		X	+	+	×	+	+	+		-				OF	50.00 (1.40) 50.00 (1.40)	900.00 (25.50)	150 350	24		+	6		90	900	2
Sertoo	100		^ x	-				-	+-		\vdash	\rightarrow			OF	50.00 (1.40)	900.00 (25.50)	500			+	6	120	90	900	2
SIAD Macchine Impianti S.p.A.	HD f		x x		×	×	_								01/01	I and Times	35,316.00 (1,000.00		350		† ··		3,264	2,400	300	-,
SIAD Macchine Impianti S.p.A.	HDt		x x		×	x									OI/OI		17,658.00 (500.00)	5,000	350				1,632	1,200	300	
SIAD Macchine Impianti S.p.A.	HPx		x x		×	X	- i		1		1_				01/01		21,189.00 (600.00)		350				1,340	1,000	300	_
SIAD Macchine Impianti S.p.A.	HPx W se		x x	×		. X	+	+	+	-					01/01		10,595.00 (300.00)	5,000	350				804	600	300	_
SIAD Macchine Implanti S.p.A. SIAD Macchine Implanti S.p.A.	Tse		x x		×	+	-	+	+	$\dot{-}$	+ !	-			01/01		1,766.00 (50.00)	3,610 3,610	250 250				335 102	250 75	350	1
SIAD Macchine Implanti S.p.A.	M se		x x		×		i			+	i i	1.1			OI/OI		3,550.00 (100.00)	3,610	250				603	450	300	1,
SIAD Macchine Impianti S.p.A.	I sen		x x		×			1	4	_					OI/OI		530.00 (15.00)	2,900			!		14	10	400	1,
homassen Compression Systems B.V.	C-7		x x	1		х	1								OF/O			8,700	600)		5	1,090	800	300	
homassen Compression Systems B.V.	C-12		X X			X				÷	-	_			OF/O			8,700	600			. 5	3,130	2,300	300	
homassen Compression Systems B.V. homassen Compression Systems B.V.	12 C-25 C-35		X - X	-		×	+	÷	i	-	H	-+			OF/O			8,700 8,700	600		÷	5	7,620 14,000	5,600 10,300	300 250	
homassen Compression Systems B.V.	C-45		X X		+	×	+	+-	†·	1	+-+	.	- 1		OF/O		-	8,700	600			5	20,950	15,400	250	
homassen Compression Systems B.V.	C-85		x x		1	x	-	į.	+	1	\Box	-+			OF/O			8,700			 	. 5	33,460	24,600	190	
filter Manufacturing, LLC	VSG	301						4.		1		- 1			OI		310.00 (8.80)	515	35		1	20	400	298		4,
filter Manufacturing, LLC	VSG		L.T.				┷-	4	1	1	1				01		356.00 (10.10)	515	35		1 .	20	400	298		4.
filter Manufacturing, LLC	VSG		\vdash	+		+	+-	+	+	+-	\vdash				OI	ļ	408.00 (11.50)	515	35		1	20	400	298		4.
filter Manufacturing, LLC filter Manufacturing, LLC	VSG		1 +-	- 1	+		+	1.	1		11	\rightarrow			OI OI		495.00 (14.00) 590.00 (16.70)	515 515	35 35		+	20	600 600	448	- 1	4.
fiter Manufacturing, LLC	VSG		1 🕂	-+-	- +	+-		+-	+	+	H	+			OI .		680.00 (19.30)	515			1	20	600	448		4.
filter Manufacturing, LLC	VSS	G 291	1				-	- †		1	\vdash	. :			OI		291.00 (8.20)	950				20	600	448		4
ilter Manufacturing, LLC	VSS	G 341					i	-	1						OI		341.00 (9.70)	950	65	1	1	20	600	448		4,
filter Manufacturing, LLC		G 451		_	_ ļ		.1.	.	1		1	- T		1	OI		483.00 (13.70)	950	65			20	600	448		4
filter Manufacturing, LLC	VSS	G 601	\vdash	-				+			i_	- 1			OI_		568.00 (16.10)	950	65		-	20	600	448		4
filter Manufacturing, LLC filter Manufacturing, LLC	VSG		1 +			-		1	1	+	\vdash				01	ļ. —	789.00 (22.30) 892.00 (25.30)	485 485	33		}	20 20	865 865	645 645		4.
filter Manufacturing, LLC	VSG		٠	1				+	+-	+	+		!	+	OI .		1,085.00 (30.70)	725	49		1	20	865	645		3
filter Manufacturing, LLC	VSG					+	+	+	÷	+	† †	į	· į	İ	OI		1,210.00 (34.30)	725			T	20	865	645		3,
ilter Manufacturing, LLC	VSG	1551					1	İ	:	1.		1	†		OI		1,547.00 (43.80)	535	37		+	20	1,400	1,044		3.
ilter Manufacturing, LLC	VSG	1851	. 1	7	,	1	I	1	1	1 "			- 1		OI	1	1.815.00 (51.40)	535	37	·I	I .	20	1,400	1.044		3,

Positive Displacement Compressor Specifications

			R	ecipro	cating				- 1	Rotary				Inlet Flow Rai	nge- acfm(m3/min)	Maximum Working			n Allowable I Load		Maximui Pov		Spee	ed Range
Manufacturer	page Model Designation	Single Stage Multiple Stage	Integral Engine Driven	Sepa	Balanced Opposed	Diaphragm	Helical Lobe Screw	Single	Silding Vane	Scroll	Trochoidal	Liquid Ring	OF = Oil Free/OI = Oil Injected	min	тах	pisq	bar	Max Rod Load-lb	Max Rod Load Newtons	Compression Ratio per stage	뫄	ΚW	mim	max
Vitter Manufacturing, LLC	VSG 2101		\vdash	-			+	+		-		+-	OI		2.048.00 (58.00)	535	37			20	1,400	1.044	-	3,800
VPT Kompressoren GmbH	RS	×	\vdash	-	_	+		-1		+ -	1	1	loi		318.00 (9.00)	190	13		-	13	63			3,600
VPT Kompressoren GmbH	Wsv	·	h H	. +	-	- 1	1 .	+	+	+		+	oi		6,500.00 (110.00)	870	80		÷	30	4,020			
VPT Kompressoren GmbH	WST	A X		_	-		+	+	+	+		+	OF		28,250.00 (800.00)	1,160	55			30	6,700			3,600
VPT Kompressoren GmbH	- CO		\rightarrow		1		i	+		· i		-	OF		2,930.00 (83.00)	190	13		4	1 3	670	5000		3,600
VPT Kompressoren GmbH	SKPT	x		+		\rightarrow	-	+	+-	_		+	OF		4,730.00 (83.00)	160	13			4				
VPT Kompressoren GmbH	WSF	v ^	-		_	-					-	1	OI		2,120.00 (134.00)	380			-	26	1,350			3,600
York/Frick (JCI)	RxF-12	×	- 1		+-		+	f	+	-							26		4	26	1,350	1,000	1	3,600
York/Frick (JCI)	RxF-15			-	-	-	×	+-	+	+	ł	1	01 01		72.00 (122.00)	334	23		-	-			-	3,550
	RxF-19		-	-			X								89.00 (152.00)	334			-	L				5,772
York/Frick (JCI)	RxF-24				-	+	Χ	\leftarrow	-			+-	OI		111.00 (188.00)	334 334	23	i	in				_	4,661
York/Frick (JCI)	RxF-30	1 1		-	-	\rightarrow	X	-	-	4		1	OI		144.00 (245.00)	334	23			-			_	3,550
York/Frick (JCI)		+-		\rightarrow		-+-	×.		4				OI		180.00 (306.00)	334	23			ļ ļ			ļ	5,772
York/Frick (JCI)	RxF-39				. .		Χ	4-	+				OI		223.00 (378.00)	334	23	i						4,661
York/Frick (JCI)	RxF-50		1.		_	_	X	+-	-	ļ	1.	1	OI		292.00 (497.00)	334 334	23 23 23	.:						3,550
York/Frick (JCI)	RxF-58			_	_	_	x				;	i	OI		341.00 (579.00)	334							1 .	6,297
York/Frick (JCI)	RxF-68	\perp					x						OI		403.00 (685.00)	334	23						1	5,332
York/Frick (JCI)	RxF-85	1 1				\rightarrow	x	J					OI		499.00 (848.00)	334	23 23	L	L	l 1			<u> </u>	4,306
York/Frick (JCI)	13 RxF-101	J		_			x			1			OI		596.00 (1,013.00)	334	23	1	i				<u> </u>	3,600
York/Frick (JCI)	RWFII-100	1			I.		į×.		1		<u> </u>	Ш	OI		592.00 (1,005.00)	348							1	4,500
York/Frick (JCI)	RWFII-134			-			×		i.				OI		790.00 (1,342.00)	348	24		i					4,500
York/Frick (JCI)	RWFII-177					_ i	×			-		1	OI		1,042.00 (1,770.00)		24						1	4,500
York/Frick (JCI)	RWFII-222						×				1	T	OI		1,311.00 (2,228.00)	348	24	T						4,500
York/Frick (JCI)	RWFII-270						X		1			T	OI		1,589.00 (2,700.00)		24							4,500
York/Frick (JCI)	RWFIt-316					· - T	×	\top	7	1			Ol		1,865.00 (3,169.00)	348	24 24			1 1				3,600
York/Frick (JCI)	RWFII-399					- 1	×	T				1	OI		2,349.00 (3,992.00)	348	24	1		1 1			-	3,600
York/Frick (JCI)	RWFII-480				- 1		x	1		1			OI		2,824.00 (4,798.00)		24		1					3,600
York/Frick (JCI)	RWFII-496						×		1	-	T	*	OI		2,920.00 (4,961.00)		24						T	3,600
York/Frick (JCI)	RWFII-546						×	,	1	1			OI		3,216.00 (5,464.00)		24			1 1			1	3,600
York/Frick (JCI)	RWFII-676		i - i			- 1	×	1	1	1	-	1	OI		3,982.00 (6,765.00)		24			1				3,600
York/Frick (JCI)	RWFII-856						x				1	1	OI		5,068.00 (8,610.00)		24						1	3,600
York/Frick (JCI)	RWFII-1080		-		_	_	¥			-	 	+	OI		6,394.00 (10,863.0		24					_	+	3,600

 $Data\ Courtesy\ COMPRESSORTech Two\ magazine.\ Additional\ current\ data\ available\ at\ www.compressortech 2.com\ or\ www.CTSSNet.net$

Appendix A2

COMPARISON TABLE OF THE THREE TYPES OF COMPRESSORS*

This chart provides a brief comparison of three compressor types: Reciprocating, Screw and Centrifugal relative to pressure and flow rate. For specific details per manufacturer and models the reader is directed to Appendix A.

Compressor Types		Reciprocating		Screw		Centrifugal
Com	pressor Types	Lube	Non-Lube	Oil Flooded	Oil Free	
Pressure	Maximum Discharge Pressure	4500 psiG (300barG)	1500 psiG (100 barG)	1500 psiG (100 barG)	600 psiG (40 barG)	3000 psiG (200barG)
	Maximum Pressure Ratio by Single Stage	3:1	3:1	> 50:1	4:1 - 7:1	1.5:1 - 3:1
Flow Rate	Maximum Actual Inlet Volume	8800ACFM (15000 m3/h)	8800ACFM (15000 m3/h)	15000ACFM (25000 m3/h)		240000ACFM (400000 m3/h)
	Turndown Accomplished by:	Suction Valve Unloaders (step & stepless); Clearance Pockets; Bypass	Suction Valve Unloaders (step & stepless); Clearance Pockets; Bypass	Slide Valve 15 - 100% (step & stepless); Bypass	(None); Bypass	Inlet Guide Vane; Speed Control (70 - 100%); Bypass
	Polymer Gas	Difficult	Difficult	Difficult	Possible	Difficult
	Dirty Gas	Possible	Difficult	Possible	Possible	Difficult
	MW Change	Possible	Possible	Possible	Possible	Difficult

^{*}Process Gas Applications Where API 619 Screw Compressors Replaced Reciprocating And Centrifugal Compressors, Takao Ohama, Yoshinori Kurioka, Hironao Tanaka, Takao Koga; Proceedings of the Thirty-Fifth Turbomachinery Symposium—2006

Appendix B1

List of Symbols

Α	Area,	Ft ²

Btu British thermal unit

C Velocity of the air entering the compressor or air and combustion products leaving the turbine, *ft per sec*

CDP Compressor discharge pressure, psia

CDT Compressor discharge temperature, °R

c, Specific heat at constant pressure, Btu/lb°F

 c_n Specific heat at constant pressure, $Btu/lb^\circ F$

 c_v Specific heat at constant volume, $Btu/lb^\circ F$

°E Engler, degrees

g_c Acceleration due to gravity, ft/sec²

h₁ Enthalpy of the fluid entering, Btu/lb_m

 h_2 Enthalpy of the fluid leaving, Btu/lb_m

 h_i Enthalpy of the fluid entering, Btu/lb

 h_o Enthalpy of the fluid leaving, Btu/lb_m

HP Horsepower

Hr Hours

J Ratio of work unit to heat unit, 778.2 ft lb_f/Btu

k Ratio of specific heats, c_p/c_v

KE₁ kinetic energy of the fluid entering, Btu/lb_m

KE₂ Kinetic energy of the fluid leaving, Btu/lb_m

KJ Kilojoules

KW Kilowatts

Mo Mass of a given volume of oil

Mw Mass of a given volume of water

MW Power output (electric generator)

Appendices 235

- MW Molecular weight
 - $\rm N_1$ Single spool or low pressure compressor-turbine rotor speed, $\rm rpm$
 - $\,{
 m N}_2\,\,$ Dual spool high pressure compressor-turbine rotor speed, rpm
 - N₃ Power turbine rotor speed, rpm
- NO_x Oxides of nitrogen
 - P₂ Compressor inlet pressure, psia
 - P₃ Single spool compressor discharge pressure, single spool low pressure compressor discharge pressure, *psia*
 - P₄ Dual spool low pressure compressor discharge pressure, psia
 - P₅ Turbine inlet pressure, psia
- P_3/P_2 Single spool compressor pressure ratio, dual spool low pressure compressor pressure ratio
- P₄/P₂ Compressor pressure ratio
- P₄/P₃ Dual spool high pressure compressor pressure ratio
- P_{AMB} Atmospheric total pressure, psia
 - PE_1 Potential energy of the fluid entering, Btu/lb_m
 - PE₂ Potential energy of the fluid leaving, Btu/lb_m
 - P_i Inlet pressure, psia
 - P_o Discharge pressure, psia
 - cP Absolute or Dynamic Viscosity, Centipoises
 - P_{PT} Power input to the load device, Btu/sec
 - Ps₃ Low pressure compressor out pressure (static)
 - Ps₄ High pressure compressor out pressure (STATIC)
 - P_{t7} Exhaust total pressure, psia
 - Q Cubic feet per second (CFS)
 - $_1\mathrm{Q}_2$ Heat transferred to or from the system, $\mathit{Btu/lb}_{\mathrm{m}}$
 - Q_m Mechanical bearing losses of the driven equipment, Btu/sec
 - Q_m Mechanical bearing losses of the power turbine, Btu/sec
 - Q_r Radiation and convection heat loss, Btu/sec
 - R_c Compressor pressure ratio
- secs R.I. Redwood No 1 (UK), seconds

cST Kinematic viscosity = Absolute viscosity/density. centistokes

SUS Saybolt Universal (USA), seconds

T_{1DB} Dry bulb temperature upstream of the cooler, °R

T_{2DB} Dry bulb temperature downstream of the cooler, °R

T_{2WB} Wet bulb temperature downstream of the cooler, °R

T₂ Compressor inlet temperature, °R

 ${
m T_3}$ Single spool compressor discharge temperature, dual spool low pressure compressor discharge temperature, °R

 ${\rm T_4}$ Dual spool low pressure compressor discharge temperature, ${^\circ}R$

T_{amb} Ambient air temperature, °R

Ti Inlet temperature, °R

To Discharge temperature, °R

U Velocity, feet per sec

D Diameter, in², ft²

V Vibration

W Mass flow rate, lb_m/sec

W₂ Relative velocity

W_a Air flow entering the compressor, lb/sec

W_f Fuel flow, lbs/sec

W_f/CDP Gas turbine burner ratio units, lbs/hr-psia

W_o Turbine inlet gas flow, *lbs/sec*

 $_1W_2$ Work per unit mass on or by the system, ft- lb_f/lb_m

W₂/J Work, Btu/lb_m

Z_{avo} Average compressibility factor of air,

 β_2 Relative direction of air leaving the stator vanes

 $η_c$ Compressor efficiency

 η_t Gas generator efficiency

 η_{PT} Power extraction turbine efficiency

 θ_1 Direction of air leaving the stator vanes

Appendices 237

Appendix B2 Glossary of Terms

- **Absolute pressure**—The total pressure measured from absolute zero in units such as pounds per square in absolute (psia), Inches of Mercury Absolute (in. of HGA).
- **Absolute temperature**—The temperature of a body at absolute zero (Fahrenheit scale is minus 459.67°F/Celsius scale is minus 273.15°C).
- **Absolute viscosity** (*Dynamic*)—Is the tangential force per unit area necessary to move one layer with respect to the other at unit velocity when maintained a unit distance apart by the fluid. Units are pound force sec per foot squared (lbf sec/ft²) or kilogram/meter sec (kg/m sec)
- **Absolute zero**—The lower limit of temperature -459.69°F or -273.15°C
- **Acidity**—The quality, state or degree of being acid. A substance is considered acidic if its pH is less than 7. In oils, acidity denotes the presence of acid-type constituents whose concentration is usually defined in terms of a neutralization number.
- ACFM—Actual cubic feet per minute. The quantity of gas actually compressed and delivered at the temperature & pressure at that location.
- Activated alumina—An adsorption type desiccant.
- **Adiabatic compression**—Compression where no heat is transferred to or from the gas during the compression process.
- **Adiabatic efficiency**—The ratio of the actual work output to the work output that would be achieved if the process between the inlet state and the exit state was isentropic.
- **Adsorptive filtration**—The attraction to a filter medium by electrostatic forces, or by molecular attraction between the particles and the medium.

- **Aeration**—A process by which air is circulated through or dissolved in a liquid or substance.
- Aerosol—A suspension of fine solid or liquid particles in a gas.
- **Aftercooler**—Heat exchangers for cooling air or gas discharged, typically, from compressors.
- **Air actuator**—A device to convert pneumatic energy to mechanical energy.
- **Air bearing**—A fluid dynamic (hydrostatic) bearing using air to support the rotating shaft loads within the bearing.
- Air borne—Supported or transported by air.
- **Air cooled compressor**—A compressor cooled by atmospheric air circulated around the cylinders or casing usually incorporating cooling fins.
- Air flow—The movement of air from one point to another.
- **Air lock**—An interlocking device that permits passage of air (or gas) between regions of different pressures whole maintaining the pressure in each region.
- **Air nozzle**—A fitting incorporating an orifice whereby a liquid or gas passing through the orifice undergoes a change in pressure and velocity.
- **Air receiver**—A receptacle that stores compressed air for heavy demands in excess of compressor capacity.

ALT—Altitude

Altitude—The elevation above sea level.

- **Alternating current (AC)**—An electrical current that periodically reverses its direction. Standard in US and Canada is 60 cycles per second. Europe and other countries is 50 cycles per second.
- **Amagat's law**—States that the volume of a mixture of gases is equal to the sum of the partial volumes which the constituent gases would occupy if each existed alone at the total pressure of the mixture.
- **Ambient**—The temperature, pressure and humidity at specific site locations.

Ammonia—A colorless gas with a strong pungent odor made up of nitrogen and hydrogen (NH₃).

- **Amonton's law**—States that the pressure of a gas, at constant volume, varies directly with the absolute temperature.
- **Ampere (AMP)**—A unit of electrical current or rate of flow of electrons through a conductor. One volt across one ohm of resistance causes a current flow of one ampere.
- **Ancillary equipment**—Components in addition to the primary equipment (such as the compressor, generator or driver).
- **Anhydrous**—A substance containing no water.
- **Anion**—An ion with more electrons than protons, giving it a net negative charge..
- A.P.I.—American Petroleum Institute
- **Approach temperature**—The difference in temperature between that of the heated medium exiting from a heat exchanger and the inlet temperature of the cooling medium entering the heat exchanger.
- **ASHRAE**—The American Society of Heating, Refrigerating and Air-Conditioning Engineers, Inc. .
- A.S.M.E.—American Society of Mechanical Engineers
- **A.S.T.M.**—American Society For Testing and Materials.
- **Atmosphere** (ATM)—The layer of gas surrounding the earth that is retained by gravity.
- **Atmospheres absolute (ATA)**—It is the weight of the column of air existing above the earths surface at sea level. It is equivalent to 14.696 psia or 1.0333 kg/sq cm.
- **Atmospheric dew point**—The temperature at which water vapor begins to condense at atmospheric pressure.
- **Attenuation**—The gradual loss in intensity of sound waves due to distance or an blocking media (such as a wall).
- **Avogadro's Law**—States that equal volumes of ideal gases, at the same temperature and pressure, contain the same number of molecules.

- **Axial compressor**—A compressor belonging to the group of dynamic compressors. Characterized by having its flow in the axial direction.
- **Boyle's Law**—States that for a fixed amount of an ideal gas kept at a fixed temperature, pressure and volume are inversely proportional.
- **Bag house**—A dust-collection chamber containing numerous permeable fabric filters through which the gases pass.
- Bar—A unit of pressure equal to 0.986925 atmospheres or 14.5039 psi.
- **Barometric pressure**—Is the absolute atmospheric pressure existing at any given point in the atmosphere. It is the weight of a unit column of gas directly above the point of measurement. It varies with altitude, moisture and weather conditions.
- **Base plate**—A metallic structure on which a compressor, motor, driver or other machine units are mounted.
- **Bernoulli's principle**—States that for a fluid, with little or no viscosity, increases in the speed of the fluid flow occurs simultaneously with a decrease in pressure or a decrease in the fluids potential energy
- BHP—Break horse power
- Blower—A compressor designed to operate at lower pressure ratios.
- **Blow off control**—When the maximum pressure is reached, the delivered air is blown off to the atmosphere.
- **Body**—The stationary valve seating surface
- **Bonnet**—The portion of a valve that surrounds the spring.
- **Booster compressor**—Compressors used to increase the initial gas pressure, usually low or near atmospheric pressure, to a higher pressure.
- **Boyle's law**—States that the volume of a gas, at constant temperature, varies inversely with the pressure.
- **Breather**—A filtering unit for vented enclosures installed to prevent dirt and foreign matter from entering the enclosure.
- British thermal unit—Btu. The amount of heat required to raise the tem-

- perature of one pound of water one degree Fahrenheit under set conditions of temperature and pressure.
- **Buna** N—A synthetic rubber frequently used for vessel and liquid filter element gasket.
- **Burst pressure**—Maximum pressure a vessel will withstand without bursting.
- **By pass**—Condition that exists when the air, gas, or fluid normally passing through an element is being shunted around the element.
- **Capacity**—Capacity of a compressor is the full rated volume of flow of gas compressed and delivered at certain set conditions.
- **Capacity gauge**—A gauge that measures air flow as a percentage of capacity, used in rotary screw compressors as an estimator during modulation controls.
- **Carbon dioxide**—A heavy colorless gas that does not support combustion but is formed by the combustion and decomposition of organic substances.
- **Carbon monoxide**—A colorless odorless very poisonous gas formed by the incomplete burning of carbon.
- **Casing**—The pressure containing stationary element that encloses the rotor and associated internal components of the compressor.
- Cation—An ion with more protons than electrons.
- **Celsius**—The international temperature scale where water freezes at 0 (degrees) and boils at 100 (degrees). Also known as the centigrade scale.
- **Centrifugal compressor**—A dynamic compressor where air or gas is compressed by the mechanical action of rotating impellers and stationary diaphragms imparting velocity and pressure to the air or gas.
- CFM—Cubic feet per minute. An airflow measurement of volume.
- **Charles Law**—States that the volume of a gas is directly proportional to its temperature.
- **Chatter**—Abnormal, rapid reciprocating movement of the disc on the seat of a pressure relief valve.

- **Check valve**—A valve that permits flow in one direction only.
- **Choke**—This term is used for turbo compressors and represents the maximum flow condition. It is sometimes also referred to as stonewalling.
- **Clean pressure drop**—The pressure loss across the filter element determined under steady state flow conditions using a clean test fluid across a clean filter element.
- Clearance—The maximum cylinder volume on a working side of the piston, minus the piston displacement volume per stroke. It is usually expressed as a percentage of the displaced volume.
- Clearance pocket—An adjustable volume that may be opened or closed to the clearance space for increasing or decreasing the clearance, usually temporarily or seasonally, to reduce the volumetric efficiency and flow of the compressor.
- **Collapse pressure**—The minimum differential pressure that an element is designed to withstand without permanent deformation.
- CNG—Compressed natural gas.
- Coalescing filter—A filter unit that combines three principles to filter out oil aerosols: 1) *Direct interception*—A sieving action, 2) *Inertial impaction*—Collision with filter media fibers, 3) *Diffusion -*Particles travel in a spiral motion, presenting an effective frontal area thus capturing particles within the filter medium.
- **Cogeneration**—The use of exhaust heat flow as the source of heat to generate steam, hot water, hot oil, etc. to be used in another process.
- **Cold start**—Starting a compressor from a state of total shutdown. Usually done with "local" control at the compressor.
- **Compressed air**—Air under pressure greater than that of the atmosphere.
- **Compressibility**—A measure of the relative volume change of a gas as a response to a pressure change.
- **Compressibility factor Z**—Is the ratio of the actual volume of the gas to the volume determined according to the ideal gas law.
- Compression efficiency—Is the ratio of the theoretical work requirement

to the actual work required to be performed on the gas for compression and delivery.

- **Compression ratio**—The ratio of the absolute discharge pressure to the absolute inlet pressure.
- **Condensate**—The liquid phase that separates from a vapor during condensation.
- Condenser—A heat exchanger used to change a vapor into a liquid.
- **Conduction**—The transfer of thermal energy between neighboring molecules in a substance due to a temperature gradient
- **Constant speed control**—A control method whereby load is varied either by use of recycle valves, suction valve unloaders or variable volume pockets and energy input at constant driver speed.
- **Contaminant**—Foreign matter carried in the air, gas or fluid to be filtered out. Includes air borne dirt, metallic particles produced by wear of moving parts of the air compressor, rust from metal pipelines.
- **Contaminant capacity**—An indicator of relative service life of a filter.
- **Control valve**—Any valve that controls flow.
- **Convection**—A means of transferring heat through mass flow. Also the transfer of heat within a fluid by movements of particles within the fluid.
- Coolant—Fluid cooling agent.
- **Cooling tower**—A cooling water supply system. There are two different types—Open and closed loop systems.
- **Coriolis force**—A force acting in a direction perpendicular to the rotation axis and to the velocity of the body in the rotating frame and is proportional to the objects speed in the rotating frame.
- **CPM**—Cycles per minute—a unit of measure of the frequency of any vibration.
- **Cracking**—To subject petroleum oil to heat in order to break it down into lighter products.
- **Critical pressure**—The pressure required at the critical temperature to cause the gas to change state. It is the highest vapor pressure

- that the liquid can exert.
- **Critical speed**—Rotative speeds at which rotating machinery passes through its the natural frequency.
- **Critical temperature**—That temperature above which a gas will not liquefy regardless of any increase in pressure.
- **Crosshead assembly**—The assembly connecting the crankcase and connecting rod to the cylinder head and piston rod for translating circular to linear motion.

Crosshead loading

The tensile or compressive loading on the crosshead assembly with compressive piston rod loading on the outward stroke and tensile piston rod loading on the inward stroke.

CSA—Canadian Standards Association

Cubic feet per minute (CFM)—An airflow measurement of volume.

Cycle time—Amount of time for a compressor to complete one cycle.

Cylinder—The piston chamber in a compressor or actuator.

- **Cyclone**—A type of separator for removal of larger particles from a gas stream. Gas laden with particulates enters the cyclone and is directed to flow in a spiral causing the entrained particulates to fall out and collect at the bottom. The gas exits near the top of the cyclone.
- **Cyclone separator**—A means of purifying an gas stream by using both gravitational and centrifugal forces.
- **Dalton's law**—States that the total pressure exerted by a gaseous mixture is equal to the sum of the partial pressures of each individual component in the gas mixture.
- **Degrees Celsius (°C)**—An absolute temperature scale. ((°F 32) x 5/9).
- **Degrees Fahrenheit (°F)**—An absolute temperature scale. ((°C x 9/5) + 32).
- **Degrees Kelvin (°K)**—An absolute temperature scale. The kelvin unit of thermodynamic temperature, is the fraction 1/273,16 of the thermodynamic temperature of the triple point of water. The triple point of water is the equilibrium temperature (0.01 °C

- or 273,16 K) between pure ice, air free water and water vapor.
- **Degree Rankine** (°R)—An absolute temperature scale. (°F + 459,67).
- **Degree of saturation**—The ratio of humidity ratio of moist air to humidity ratio of saturated moist air.
- **Deliquescent**—Melting or dissolving and becoming a liquid by absorbing moisture.
- **Delta P**—Describes the pressure drop through a component and is the difference in pressure between two points.
- **Delta** T—Describes the temperature difference between two points.
- **Demand**—Flow of a gas under specific conditions required at a particular point.
- **Demulsibility**—The resistance of a hydraulic fluid to emulsification.
- **Density**—The weight of a given volume of gas, usually expressed in lb/cu ft at standard pressure and temperature conditions.
- **Desiccant**—An adsorption type material used in compressed air dryers. Industry standards are activated alumina, silica gel and molecular sieves.
- **Design pressure**—The maximum continuous operating pressure as designed by the manufacturer.
- Desorption—Opposite of absorption or adsorption.
- **Dew point**—Of a gas is the temperature at which the vapor in a space (at a given pressure) will start to condense (form dew). Dew point of a gas mixture is the temperature at which the highest boiling point constituent will start to condense.
- **Diaphragm**—A stationary element between rotating stages of a multistage centrifugal compressor.
- **Diaphragm compressor**—Is a positive displacement reciprocating compressor using a flexible membrane or diaphragm in place of a piston.
- **Diaphragm cooling**—A method of removing heat from the flowing medium by circulation of a coolant in passages built into the diaphragm. Also known as diaphragm routing.
- Differential pressure—The difference in pressure between any two

- points of a system or component.
- **Differential pressure indicator**—An indicator, or differential pressure gage, which signals the difference in pressure between any two points of a system or a component.
- **Diffuser**—A stationary passage surrounding an impeller, in which velocity pressure imparted to the flow medium by the impeller is converted into static pressure.
- **Digital controller**—Control device whose operation may be reduced to binary operation such as ON = 0, OFF = 1 or OPEN and CLOSED. Also known as Logic controls
- **Diluent**—An inert substance added so as to reduce the activity of a substance.
- **Direct current**—DC. A continuous, one directional flow of electricity.
- **Directional control valve**—A valve to control the flow of a gas in a certain direction.
- **Dirt holding capacity**—The quantity of contaminant a filter element can trap and hold before the maximum allowable back pressure or delta P level is reached.
- Disc—The movable seating surface in a valve.
- **Discharge piping**—The piping between the compressor and the after-cooler, the aftercooler separator and the downstream element.
- **Discharge pressure**—The total gas pressure (static plus velocity) at the discharge port of the compressor. Velocity pressure is considered only with dynamic compressors.
- **Discharge temperature**—The temperature existing at the discharge port of the compressor.
- **Displacement compressor**—A machine where a static pressure rise is obtained by allowing successive volumes of gas to be aspirated into and exhausted out of a closed space by means of the displacement of a moving member.
- **Displacement of a compressor**—The volume displaced by the compressing element of the first stage per unit of time.
- **Disposable filter**—A filter element intended to be discarded and replaced after one service cycle.

- **DOE**—The U.S. Department of Energy.
- **Double acting compressor**—A positive displacement compressor where the pistons compress gas on both the head-end and crank-end strokes.
- **Downstream**—The portion of the flow stream which has already passed through the system or the portion of the system located after a filter or separator/filter.
- **Drag**—Occurs when a valve does not close completely after popping and remains partly open until the pressure is further reduced.
- **Drain valve**—A valve designed to remove surplus liquid from the compressed gas system (scrubbers, pulsation bottles, etc.).
- **Dripleg**—A pipe extending downward from the bottom of the vessel to collect any condensation flow.
- **Dry bulb temperature**—The ambient gas temperature as indicated by a standard thermometer.
- **Dry gas**—Any gas or gas mixture that contains no water vapor and/or in which all of the constituents are substantially above their respective saturated vapor pressures at the existing temperature.
- **Dry unit (oil free)**—Is one in which there is no liquid injection and/or liquid circulation for evaporative cooling or sealing.
- **Dynamic losses**—Friction against duct walls, internal friction in the ga mass and direction variations will cause a speed reduction and are therefore called dynamic losses.
- **Dynamic type compressors**—Machines in which air or gas is compressed by the mechanical action of rotating vanes or impellers imparting velocity and pressure to the flowing medium.
- **Dynamic viscosity** (*Dynamic*)—The tangential force per unit area necessary to move one layer with respect to the other at unit velocity when maintained a unit distance apart by the fluid. Units are pound force sec per foot squared (lbf sec/ft²) or kilogram/meter sec (kg/m sec)
- **Durometer**—This term refers to the hardness or softness of gaskets.
- **Dust cake**—A layer of dust built up on an air filter.

- **Dust holding capacity**—The amount of atmospheric dust which a filter will capture.
- **Effective area**—The area (in sq inches) of the filter element that is exposed to the flow of air or fluid for effective filtering.
- **Efficiency**—filter—Ability of a filter to remove particle matter from an air stream. Measured by comparing concentrate of material upstream and downstream of the filter. Typical particulate sizes range from .3 micron to 50 micron.
- **Efficiency- compression**—Is the ratio of the theoretical work requirement to the actual work required to be performed on the gas for compression and delivery.
- **Efficiency- isothermal**—The ratio of the theoretical work calculated on an isothermal basis to the actual work transferred to the gas during compression.
- **Efficiency mechanical**—The ratio of the thermodynamic work requirement in the cylinder to actual brake horsepower requirement.
- **Efficiency—polytropic**—The ratio of the polytropic compression energy transferred to the gas to the actual energy transferred to the gas.
- **Efficiency—volumetric—**The ratio of actual capacity to piston displacement, stated as a percentage.
- **Element**—The medium or material that does the actual filtering or separating. May be paper, wire mesh, special cellulose, inorganic plastic, or a combination.
- **Emulsibility**—The ability of a non-water-soluble fluid to form an emulsion with water.
- **Emulsifier**—Additive that promotes the formation of a stable mixture, or emulsion, of oil and water. Common emulsifiers are: metallic soaps, certain animal and vegetable oils, and various polar compounds.
- **Emulsion**—Intimate mixture of oil and water, generally of a milky or cloudy appearance. Emulsions may be of two types: oil-in water (where water is the continuous phase) and water-in-oil (where water is the discontinuous phase).

Energy audit—A survey that shows how much energy you use in your compressed air generation.

- **Energy conservation**—Practices and measures that increase energy efficiency.
- **Energy kinetic**—The energy a substance possesses by virtue of its motion or velocity.
- **Energy storage**—The ability to convert energy into other forms, such as heat or chemical reaction, so that it can be retrieved for later use. Also the development, design, construction and operation of devices for storing energy until needed. Technology includes devices such as compressed gas.
- **Enthalpy**—The sum of the internal and external energies.
- Entropy—A measure of the unavailability of energy in a substance.
- **Environmental contaminant**—All material and energy present in and around an operating system, such as dust, air moisture, chemicals, and thermal energy.
- **Evaporation**—The escape of water molecules from a liquid to the gas phase at the surface of a body of water.
- **Exothermic**—A term used to describe a chemical process in which heat is released.
- **Expanders**—Turbines or engines in which gas expands, does work, and undergoes a drop in temperature.
- **Ferrography**—An analytical method of assessing machine health by quantifying and examining ferrous wear particles suspended in the lubricant or hydraulic fluid.
- **Filter**—A device that removes solid contaminants, such as dirt or metal particles, from a liquid or gas, or that separates one liquid from another, or a liquid from a gas.
- Filter breather—A filtering unit for vented enclosures installed to prevent dirt and foreign matter from entering the enclosure. Also prevents oil loss by retaining oil droplets and draining the oil back to the sump.
- **Filter efficiency**—Ability of a filter to remove particle matter from an air stream. Measured by comparing concentrate of material

- upstream and downstream of the filter. Typical particulate sizes range from .3 micron to 50 micron.
- **Filter element**—The porous device which perform the actual process of filtration.
- **Filter housing**—Something that covers or protects the filter assembly.
- **Filter separator**—Filtering unit that separates solids and liquid droplets from gas (air). Widely used in removing oil from a gas or air.
- **Filtration**—The physical or mechanical process of separating insoluble particulate matter from a fluid, such as air or liquid, by passing the fluid through a filter medium that will not allow the particulate to pass through it.
- **First law of thermodynamics**—The amount of work done on or by a system is equal to the amount of energy transferred to or from the system.
- Flange—A bolted rim used for attachment to another object.
- Flash point—The lowest temperature to which oil must be heated under standardized test conditions to drive off sufficient inflammable vapor to flash when brought into contact with a flame. Flash points of petroleum based lubricants increase with increasing pressure.
- **Flexible mounting**—Vibration isolation mount. Provides reductions in vibration transmission.
- **Flow**—The volume of a substance passing a point per unit time (e.g., meters per second, gallons per hour, etc.).
- **Flow control valve**—A valve that controls the flow of air that passes through the valve.
- **Flow diagram**—A schematic flow sheet showing all controls involved with the system.
- **Flow meter**—An instrument for measuring the amount of gas flow of a compressor. Measured in CFM.
- **Flow rate**—The rate (in liters or gallons per minute, cubic meters or cubic feet per second, or other quantity per time unit)
- Flushing—A circulation process designed to remove contamination.

Forced draft fan—A fan that generates (by pushing) a flow of ambient air over the exterior of the finned pipes to dissipate the sensible heat.

- **Friction**—Surface resistance to relative motion, which slows down movement and causes heat.
- **Full load**—Achieved when the air compressor is running at full RPM with a fully opened inlet and discharge, delivering the maximum volume at the rated pressure.
- **Gay-Lussac's Law**—States that if the mass and pressure of a gas are held constant than gas volume is directly proportional to the gas's temperature.
- **Gag**—A device attached to a safety relief valve that prevents it from opening at the set pressure.
- **Galling**—A form of wear in which seizing or tearing of intermittent contacting surfaces occurs.
- Gas—One of three basic phases of matter (solid, liquid, gas).
- **Gas bypass**—All or a portion of gas that is redirected upstream or downstream of a component to compensate for process flow demands.
- Gas drying—The drying of compressed gases other than air. Equipment size, choice of materials and other specifications may be decidedly different for drying gases other than air because of the specific properties of the gases. Properties include specific gravity, specific heat, viscosity, thermal conductivity, explosive characteristics, toxicity, corrosion and others.
- Gas laws—The behavior of perfect gases, or mixtures thereof, follows a set of laws. Boyle' law, Charle's law, Amonton's law, Dalton's law, Amagat's law, Avogadro's law, Poisson's law.
- Gate valve—A type of valve in which the closing element (the gate) is a disc that moves across the stream in a groove or slot for support against pressure. A gate valve has relatively large full ports and a straight line flow pattern.
- Gage—An instrument for measuring, testing, or registering.

- **Gage pressure**—Is pressure as determined by most instruments and gages.
- **Glycol dehydration**—A method of drying natural gas.
- **Governor**—A engine or motor controller that regulates the fuel flow or amperage to the engine or motor to control the speed and power.
- **GPM**—Gallons per minute
- Guide—The portion of a valve used to guide the disc.
- **Guide vane**—A stationary element that may be adjustable and which directs the flow medium to the inlet of an impeller.
- **Head adiabatic**—The force (or pressure) that a adiabatic (No heat transferred to or from the fluid) compression process raises the gas from suction level to discharge level measured in inches of feet of water column.
- **Header**—A distribution pipe.
- **Head polytropic**—The force (or pressure) that a polytropic (heat transfer to/from the fluid can exists and the fluid may not behave as an ideal gas)compression process raises the gas from suction level to discharge level measured in inches of feet of water column.
- **Head pressure**—The force (or pressure) that the compression process raises the gas from suction level to discharge level measured in inches of feet of water column. This term is also referred to as **Head.**
- Heat capacity—The heat energy transferred from system A to system B.
- **Heat exchanger**—A device in which two fluids, separated by a heat conducting barrier, transfer heat energy from one fluid to the other.
- **Heat recovery**—Recovering and utilizing the heat content of a fluid.
- **Horsepower (HP)**—A unit of work equal to 33,000 foot pounds per minute, 550 foot pounds per second, or 746 Watts.
- **Horsepower brake (BHP)**—The horsepower output from the driver and input to the compressor shaft. Also referred to as Shaft Horsepower.
- Horsepower gas—The actual work required to compress and deliver a

- given gas quantity, including all thermodynamic, leakage and fluid friction losses.
- **Horsepower ideal**—The horsepower required to isothermally compress gas.
- **Horsepower indicated**—The horsepower calculated in positive displacement compressors using compressor-indicator diagrams.
- **Horsepower peak**—The maximum power available from a driver or required by a compressor.
- **Horsepower theoretical**—The horsepower required to adiabatically compress gas.
- Hot gas bypass valve—A valve which connects the compressor discharge to the compressor suction and adjusted so as to maintain a specific pressure on the suction side by controlled bypass or to regulate compressor throughput.
- **Humidity**—The moisture content of air.
- **Humidity specific**—The weight of water vapor in the air vapor mixture per pound of dry air.
- **Humidity relative**—The relative humidity of air vapor mixture is the ratio of the partial pressure of the vapor to the vapor saturation pressure at the dry bulb temperature of the mixture.
- **Hydrocarbons**—Chemicals containing carbon and hydrogen.
- **ICFM**—Gas flow in cubic feet per minute at the compressor inlet pressure & temperature conditions
- I.D.—Pipe or vessel inside diameter.
- Ideal gas—A gas that follows the perfect gas laws without deviation.
- IGV—Inlet guide-vane valve. Valve(s) installed at the compressors inlet.
- **Immiscible**—Fluids that are incapable of being mixed or blended together.
- **Impeller**—The rotating element(s) of a dynamic compressor that imparts energy to the flowing medium by means of centrifugal force.
- Inches of water—A pressure measurement for example 407.258 in of water (at $60~^{0}\text{F}$) = 1 Atmosphere = 14.696 psia.

- **Indicated power**—Power calculated from a compressor-indicator diagram.
- Indicator card—A pressure-volume diagram for a compressor or engine cylinder produced directly from measurements made using of a device called the engine/compressor indicator.
- Inducer—A curved inlet section on an impeller.
- **Inerting**—Process of purging a compressor or a compartment with a non-reactive such **Inert gas**—A gas that has little or no heating value.
- **Inertia forces**—Forces generated by the moving parts (such as pistons, rods, crossheads, connecting rods) with in the compressor and act on the compressor case and the support system.
- Influent—The fluid entering a component.
- **Inlet pressure**—The total pressure measured at the inlet flange of a compressor.
- **Inlet temperature**—The temperature measured at the inlet flange of the compressor.
- **Inlet throttle**—A compressor control device (valve) that controls the operation of the compressor.
- **Instrument air**—Compressed air (usually dry and free from contaminants) used specifically with pneumatic instruments and controls.
- **Intercooler**—Heat exchangers for removing the heat of compression between compressor stages.
- **Internal energy**—Energy which a substance possesses because of the motion and configuration of its atoms, molecules, and subatomic particles.
- International Organization for Standardization—ISO.
- **Irreversible process**—A process in which the system and/or surroundings cannot be returned to their original state.
- Isentropic compression—Compression at constant entropy
- Isentropic efficiency—The ratio of isentropic work to actual work
- ISO—International Organization for Standardization.

- Isobar—Constant pressure.
- Isochor—Constant volumn.
- **Isotherm**—Constant temperature.
- **Isothermal compression**—Compression where the temperature of a gas remains constant.
- **Isothermal efficiency**—The ratio of the isothermal power consumption to shaft power input.
- **Joule**—The amount of work done by a force of one newton moving an object through a distance of one meter. One joule is equal to one WATT—second or 0.737 foot pounds.
- **Joule effect**—The conversion of mechanical, electrical or magnetic energy into heat.
- Joule Thompson effect—The temperature change that occurs when a non-ideal gas suddenly expands from a high pressure to a low pressure. The ratio of the change in temperature divided by the change in pressure is known as the Joule-Thomson coefficient.
- **Journal**—That part of a shaft or axle that rotates in a stationary fixed or tilt-pad bearing.
- **Journal bearing**—A fixed two-piece or tilt-pad cylinder surrounding the shaft (journal) and supplied with a fluid lubricant. The fluid is the medium that supports the shaft preventing metal-to-metal contact.
- **Kelvin (K)**—Pertains to the absolute scale of temperature in which the degree intervals are equal to those of the Celsius scale and in which the triple point of water has the value 273.16 Kelvin.
- Kilowatt (kW)—A unit of power equal to 1,000 watts.
- **Kilowatt hour (kWh)**—A unit of work done in one hour at the rate of 1,000 watts.
- **Kinematic viscosity**—Is the ratio of the absolute or dynamic viscosity to density.
- **Kinetic energy**—The energy of a body or a system with respect to the motion or velocity of the body or system or of the particles in the system.

Knock out—A term used to describe the condensate flow rate. It can be expressed as gallons per minute (GPM) or pounds mass per minute (lb_m/min).

kPa—Kilopascal; a metric measure of pressure based on force per unit area. (1 kPa = 4.01 inches of water).

kW—Kilowatt—A unit of power equal to 1,000 watts.

kWh-Kilowatt hour-A unit of work being done in one hour.

Lift—The distance between valve plate and the seating surfaces when the valve goes full open.

Liquid ring rotary compressor—A liquid piston compressor is a rotary compressor in which a vaned rotor revolves in an elliptical casing, with the rotor spaces sealed by a ring of liquid rotating with it inside the casing.

LNG—Abbreviation for Liquefied Natural Gas.

Load Electrical—Electric power consumed.

Load Mechanical—Mechanical or shaft power consumed.

Load factor—Ratio of the design compressor load to the maximum rated load of the compressor.

Lobe—A rotating element of a blower.

Lubrication—A material (lubricant) used between moving parts of machinery to reduce friction and carry away heat.

Mach number—The ratio of the actual velocity or speed to the speed of sound in the surrounding medium.

Manifold—A common chamber with multiple inlets and

Man way—An inspection cover or port in a vessel or tank.

MAWP—Maximum allowable working pressure.

Maximum operating pressure—The highest operating pressure the system or component is designed to withstand.

Mechanical efficiency—The ratio of work or power input to work or power output1.

Mesh size—Mesh is the number of openings in a square inch of screen or sieve.

Micron—Micrometer or one millionth of a meter; micron is sometimes represented in filtration by the Greek letter μ (mu). A micron is 0.000039". Contaminant particles are measured by micron size and count.

- MMCFD—Millions of cubic feet per 24 hour.
- **Modulating control**—Controlling a compressor at various speeds, throughput, pressure or temperature.
- **Moisture separator**—A unit designed to separate condensate from the compressed air stream.
- **Moisture trap**—A device designed to enable accumulated liquids to be held for draining from a vessel.
- **Mole**—That mass of a substance which is numerically equal to its molecular weight
- MSDS—Materials Safety Data Sheets
- **Multistage axial compressor**—A machine having two or more impellers operating in series on a single shaft and in a single casing.
- **Multistage centrifugal compressor**—A machine having two or more impellers operating in series on a single shaft and in a single casing.
- **Natural frequency**—The natural frequency, or resonant frequency, is the frequency at which an element will vibrate when excited by a one time force.
- N.B.—National Board of Boiler and Pressure Vessel Inspectors.
- **NEC**—National Electrical Code
- **Negative pressure**—A pressure below that of the existing atmospheric pressure taken as a zero reference.
- **NEMA**—National Electrical Manufacturers Association.
- NFPA—National Fluid Power Association.
- No load—The air compressor continues to run, usually at full RPM, but no air is delivered because the inlet is either closed off or modified, not allowing inlet air to be trapped.
- Nominal efficiency—An arbitrary filter efficiency rating.
- Noncondensables—Are those constituents in the suction gas that cannot

- be condensed to a liquid ,, and removed from the gas stream, with the cooling medium available.
- Noncooled compressor cylinders—Reciprocating type compressor cylinders, with low compression ratios, used mainly in oil and gas field applications.
- **Noncorrosive gas**—Is one that does not attack normal materials of construction.
- **Nonlubricated compressor**—A compressor designed to compress air or gas without contaminating the flow with lubricating oil.
- **Nozzle**—A mechanical device designed to control the characteristics of a fluid as it exits (or enters) an enclosed chamber or pipe.
- **NPT**—National Pipe Thread standard. A description of a specific pipe thread
- **NPTT**—National Pipe Thread tapered. A description of a specific pipe thread
- NTP—Normal Temperature and Pressure. This is based upon a temperature of 32 deg F (0 deg C) and a pressure of 1 bara.
- O.D.—A measurement. Outside diameter.
- **OEM**—Original equipment manufacturer.
- Oil aerosol—A suspension of fine solid or liquid particles in a gas.
- **Oil free**—The term generally applies to the condition of the air or gas either when it leaves the compressor, or after filtration.
- Oil system—A arrangement of components such as pump, sump, separator, cooler and filter.
- **Operating pressure**—The pressure at which a combination of components is maintained in normal operation.
- **Orifice**—A restriction placed in a pipe line to provide a means of controlling or measuring flow.
- OSHA—Occupational Safety and Health Administration.
- **Overhung type centrifugal compressor**—A axial inlet compressor with the impeller or impellers mounted on an extended shaft.
- **Particulate type filter**—A device designed to remove solids, such as dirt, scale, rust and other contaminants from the gas.

Pedestal type centrifugal compressor—A single or dual inlet compressor with the impeller or impellers mounted on a shaft between two bearings.

- **Performance curve**—A plot of expected operating characteristics (e.g.., discharge pressure versus inlet capacity, shaft horsepower versus inlet capacity, efficiency).
- **pH**—Measure of alkalinity or acidity in water and water containing fluids.
- **Pinion**—The smaller of two mating or meshing gears; can be either the driving or the driven gear.
- **Piston displacement**—Net volume actually displaced by the compressor piston when traveling from crank end to head end.
- **Pitot tube**—A sensing device used to measure total pressures in a fluid stream.
- **Pleated filter**—A filter element whose medium consists of a series of uniform folds.
- Pneumatic power—The power of compressed air.
- **Pneumatic tools**—Tools that operate by air pressure.
- **Positive displacement compressors**—Compressors in which successive volumes of air or gas are confined within a closed space, and compressed.
- **Potential energy**—The energy a substance possesses because of its relative elevation.
- **Pounds per square inch**—PSI—Pounds per square inch.
- **Pour point**—The temperature at which oil begins to flow under prescribed conditions.
- **PPB**—A measurement. Parts Per Billion
- **PPBV**—A measurement. Parts Per Billion by Volume.
- PPM—A measurement. Parts per million
- **Precooler**—A heat exchanger located immediately upstream of the compressor inlet.
- **Pressure**—Force per unit area, usually expressed in pounds per square inch (PSI) or BAR.

- **Pressure absolute**—The total pressure measured from absolute zero (i.e., from an absolute vacuum).
- **Pressure cracking**—The pressure at which a pressure operated valve begins to open.
- **Pressure critical**—The saturation pressure at the critical temperature.
- **Pressure dew point**—The temperature at which moisture begins to condense in a compressed air system.
- **Pressure discharge**—The total gas pressure (static plus velocity) at the discharge port of the compressor.
- **Pressure drop**—Resistance to flow. Defined as the difference in pressure upstream and downstream.
- **Pressure rated**—The qualified operating pressure which is recommended for a component or a system by the manufacturer.
- **Pressure regulating valve**—A valve which enables pressure to be reduced, or kept constant at a desired level.
- **Pressure relief device**—A device actuated by inlet static pressure and designed to open during an abnormal condition to prevent a rise of internal pressure in excess of a specified value.
- **Pressure total**—The pressure that would be produced by stopping a moving stream of liquid or gas.
- **Preventive maintenance**—Also known as PM, maintenance performed according to a fixed schedule involving the routine repair and replacement of machine parts and components.
- **Pseudo critical pressure**—The saturation pressure at the critical temperature. It is the highest vapor pressure that the liquid can exert.
- PSI-Pounds per square inch.
- **PSIA**—Pounds per square inch, absolute.
- **PSID**—Pounds per square inch, differential.
- **PSIG**—Pounds per square inch, gauge. Pressure indicated by a pressure gauge.
- **Psychrometry**—The relationship of the properties of air and water vapor mixtures in the atmosphere.

Pulsation bottle or damper—A receiver fitted on the inlet or discharge of a reciprocating compressor. The device is designed to remove resonances from the compressor piping thereby reducing noise and stresses.

- **Purging**—Process of expelling an unwanted gas or liquid from a system through the introduction of a different gas until the last remnants of unwanted gas have been removed.
- **Receivers**—Tanks used for the storage of air discharged from compressors.
- **Reciprocating compressors**—Machines in which the compressing element is a piston having a reciprocating motion in a cylinder.
- **Reduced pressure**—The ratio of the absolute pressure of a gas to its critical pressure.
- **Reduced temperature**—The ratio of the absolute temperature of a gas to its critical temperature.
- **Regulator**—An automatic or manual device designed to control pressure, flow or temperature.
- **Relative clearance volume**—The ratio of clearance volume to the volume swept by the compressing element.
- **Relative humidity**—The ratio of the actual water-vapor partial pressure to its saturation pressure at the same temperature. (considered only with atmospheric air).
- **Relative vapor pressure**—The ratio of the vapor pressure to the saturated vapor pressure at the temperature considered.
- **Relief valve**—A spring loaded pressure relief valve actuated by the static pressure upstream of the valve.
- Reversible process—An ideal process, which once having taken place, can be reversed and in so doing leave no change in either system or surroundings
- **Reynold's number**—The numerical value of a dimensionless combination of four variables (pipe diameter, density and viscosity of the flowing fluid and the velocity of flow) may be considered to be the ratio of the dynamic forces of mass flow to the shear stress due to viscosity.

- **Rings**—Circular metallic elements that ride in the grooves of a compressor piston and provide sealing.
- **Rolling element**—A type of anti-friction bearing in lightweight compressors.
- **Rotary blowers**—A compressor belonging to the group of positive displacement rotary compressors.
- **Rotor**—The rotating element of a compressor composed of the impeller(s), shaft, seals and may include shaft sleeves and a thrust balance piston.
- SAE—Society of Automotive Engineers.
- **Safety valve**—A device that limits fluid (liquid and gaseous) pressures beyond a preset level.
- **Safety relief valve**—An automatic pressure relieving valve actuated by the static pressure of the system, which opens in proportion to the increase in pressure over the opening pressure.
- **Saturated vapor pressure**—The pressure existing at the saturation temperature in a closed vessel containing a liquid and the vapor.
- **Saturation**—Occurs when the vapor is at the dew point or saturation temperature corresponding to its partial pressure.
- SCFM—Standard cubic feet per minute.
- **Screw compressor**—A positive displacement rotary compressor.
- **Sea level**—This is the designation for the average ISO pressure = 14.69 psia.
- **Seals**—Devices used between rotating and stationary parts to eliminate or minimized leakage between areas of unequal pressures.
- **Second law of thermodynamics**—A process can only proceed in a certain direction but not in the opposite direction (heat cannot pass from a colder body to a hotter body).
- **Set pressure**—The gauge pressure at which a safety valve visibly and audibly opens or a setting at which a relief valve opens.
- **Shaft**—The part of the rotating element on which the rotating parts are mounted and by means of which energy is transmitted from the prime mover.

- **Shaft input**—The power required at the compressor drive shaft.
- **SI**—Systeme International. The international system of unit measurement.
- **Silencer**—A device fitted at a valves outlet to reduce or dampen the noise produced when the valve vents or opens.
- Single acting—When a piston compresses gas only in one direction.
- **Single stage compressors**—Compressors in which gas is compressed in each cylinder from initial intake pressure to final discharge pressure.
- **Single stage centrifugal compressors**—Compressors having only one impeller.
- **Sleeve**—A type of hydrodynamic journal bearing.
- Slip—The internal leakage within a rotary compressor representing the partially compressed gas that is not delivered.
- **Sole plate**—A metallic pad, usually embedded in concrete, on which the compressor feet are mounted.
- **Sonic flow**—The point (speed of sound) at which air flow through an orifice can not increase regardless of pressure drop.
- **SPC**—Specific Power Consumption.
- **Specific energy requirement**—The shaft input per unit of compressor capacity.
- **Specific gravity**—The ratio of the density of the material to the density of water at a specified temperature.
- **Specific heat**—The quantity of heat required to raise the temperature of a unit weight of a substance by one degree.
- **Specific humidity**—The weight of water vapor in an air-vapor mixture per pound of dry air.
- **Specific power**—A measure of compressor efficiency, usually in the form of bhp/100 acfm or acfm/bhp
- Specific volume—Is the volume of a given gas divided by its weight.
- Specific weight—The weight of a gas per unit volume
- **Speed**—The number of revolutions per minute of the compressor shaft.

- **Speed of sound**—The rate at which sound waves travel.
- **Stages**—Steps in the compression of a gas, In reciprocating compressors, each stage usually requires a separate cylinder, in dynamic compressors, each requires a separate rotor disc.
- **Stem**—The rod connecting the disc to the lever on a valve.
- **Suction pressure**—This is the pressure found on the suction side of a compressor.
- **Surge**—The reversal of flow within a dynamic compressor resulting from insufficient head and flow
- **Surge limit**—In a dynamic compressor, surge limit is the capacity below which the compressor operation becomes unstable.
- **Synthetic lubricant**—A lubricating oil made from synthetic based materials.
- **Temperature**—The physical property of a body that lies behind the common notion of hot and cold.
- **Temperature absolute**—The temperature of a body relative to the absolute zero temperature, at which point the volume of an ideal gas theoretically becomes zero. (Fahrenheit scale is minus 459.67°F/Celsius scale is minus 273.15°C).
- **Temperature discharge**—The temperature of the medium at the discharge flange of the compressor.
- **Temperature inlet**—The temperature of the medium at the inlet flange of the compressor.
- **Temperature static**—The temperature at a stagnation (speed of the fluid is zero) point in the fluid flow. Also known as the stagnation temperature.
- **Thermodynamics first law of**—The amount of work done on or by a system is equal to the amount of energy transferred to or from the system.
- **Thermodynamics second law of**—Heat cannot, of itself, pass from a colder to a hotter body.
- **Thrust balancing piston**—The part of a rotating element that counteracts the thrust developed by the impellers.

Tilting pad—A type of hydrodynamic journal bearing in a compressor.

- **Total package input power**—The total electrical power input to a electric motor driven compressor, including drive motor, cooling fan, auxiliary motors, controls, etc.
- **Torque**—Torsional moment or couple. It usually refers to the driving couple of a machine or motor.
- **Two stage compressor**—Compressors in which gas is compressed from an initial pressure to an intermediate pressure in one stage and than compressed from the intermediate stage to the final stage.
- **Two step control**—Load/unload control system that tries to maximizes compressor efficiency by matching delivery to demand. Basically the compressor is operated at full load or idle.
- **UL**—Underwriters Lab.
- **Ultrasonic leak detector**—An instrument designed to detect the ultrasonic emissions and convert them to audible signal.
- UNC—Thread—Unified national coarse.
- **UNF**—Thread—Unified national fine.
- **Unload**—A condition where the compressor runs at full RPM but no gas is delivered because the inlet is closed off.
- **Unloaded horsepower**—The power that is consumed to overcome the frictional losses when operating in an unloaded condition.
- **Vacuum pumps**—Compressors that operate with an intake pressure below atmospheric and discharge pressure usually atmospheric or slightly higher.
- **Valves**—Devices with passages for directing flow into alternate paths or restricting flow along a given path.
- **Vane compressor**—A single shaft, positive displacement rotary compressor.
- **Vapor**—Fine separated particles floating in the air and clouding it. A substance in the gaseous state.
- Vaporization—The process of changing from a liquid to a gaseous state
- **Vapor pressure**—The pressure exerted by a vapor confined within a given space.

- V belt drive—A drive arrangement for power transmission to compressors.
- **Venturi**—A reduction in fluid pressure that results when a fluid flows through a constricted section of pipe.
- **Viscosity**—A measure of the resistance of a fluid which is being deformed by either shear stress or external stress.
- **Viscosity index (VI)**—A measure of the rate of change of viscosity with temperature.
- **Volumetric efficiency**—The ratio and percent of the actual delivered capacity (measured at inlet temperature, pressure and gas composition) to the piston displacement.
- **Volute**—A stationary, spirally shaped passage that converts velocity head to pressure.
- **Water cooled compressors**—Compressors cooled by water/glycol circulated through jackets surrounding the cylinders or casings.
- **Water solubility**—The ability or tendency of a substance to blend uniformly with water.
- Wet bulb temperature—The temperature recorded by a thermometer whose bulb has been covered with a wetted wick and whirled on a sling psychrometer. Taken with the dry bulb, it permits determination of relative humidity of the atmosphere.
- **Wet gas**—A gas or gas mixture in which one or more of the constituents is at its saturated vapor pressure. The constituent at saturation pressure may or may not be water vapor.
- **Wicking**—The vertical absorption of a liquid into a porous material by capillary forces.
- WMW—Welded Minimum Wall tubing
- WOG—WOG—A pressure rating in psi for valves. W. Water, O. Oil, G. Gas
- **Work**—Energy in transition and is defined in units of Force times Distance. Work cannot be done unless there is movement.
- **Yoke**—The portion of a safety/relief valve that surrounds the spring. The spring housing.

Appendix B3

Conversion Factors

TO OBTAIN	MULTIPLY	BY		
bars	atmospheres	1.0133		
cm Hg @ 32°F (0°C)	atmospheres	76.00		
ft of water @ 40°F (4°C)	atmospheres	33.90		
in. Hg @ 32°F (0°C)	atmospheres	29.92		
in. Hg @ 60°F (15°C)	atmospheres	30.00		
lb/sq ft.	atmospheres	2,116		
lb/sq. in.	atmospheres	14.696		
cm Hg @ 32°F (0°C)	bars	75.01		
in. Hg @ 32°F (0°C)	bars	29.53		
lb/sq ft.	bars	2,088		
lb/sq in.	bars	14.50		
ft-lb	Btu	778.26		
Horsepower-hr	Btu	3.930×10^{-4}		
joules	Btu	1055		
kilogram calories	Btu	2.520×10^{-1}		
kilowatt-hr	Btu	2.930×10^{-4}		
grams	carats	2.0×10^{-1}		
ounces	carats	7.055×10^{-3}		
ft.	centimeters	3.281×10^{-2}		
in.	centimeters	3.937×10^{-1}		
kilogram/hr m	centipoise	3.60		
lb/sec ft	centipoise	6.72×10^{-4}		
Poise	centipoise	1×10^{-2}		
ft of water @ 40°F (4°C)	cm Hg	4.460×10^{-1}		
in. H ₂ O @ 40°F (4°C)	cm Hg	5.354		
kilogram/sq m.	cm Hg	135.95		
lb/sq. in.	cm Hg	1.934 x 10 ⁻¹		
lb/sq./ft.	cm Hg	27.85		
ft/sec	cm/sec	3.281×10^{-2}		
mph	cm/sec	2.237×10^{-2}		

cu in.	cu cm (dry)	6.102×10^{-2}
gal U.S.	cu cm (liquid)	2.642×10^{-4}
liters	cu cm (liquid)	1×10^{-3}
cu cm	cu ft (dry)	2.832×10^4
cu in.	cu ft (dry)	1,728
liters	cu ft (liquid)	28.32
lb	cu ft H ₂ O	62.428
gal U.S.	cu ft liquid)	7.481
cu m/min	cu ft/min	2.832×10^{-2}
gallons/hr	cu ft/min	4.488×10^2
liters/sec	cu ft/min	4.719 x 10 ⁻¹
cu cm	cu in.	16.39
gal U.S.	cu in.	4.329×10^{-3}
liters	cu in.	1.639 x 10 ⁻²
quarts	cu in.	1.732×10^{-2}
cu ft.	cu meters	35.31
cu in.	cu meters	61,023
gas U.S.	cu meters	264.17
liters	cu meters	1.0×10^3
meters	ft	3.048×10^{-1}
cm/sec	ft/min	5.080×10^{-1}
km/hr	ft/min	1.829×10^{-2}
mph	ft/min	1.136 x 10 ⁻²
cm/sec	ft/sec	30.48
gravity	ft/sec	32.1816
km/hr	ft/sec	1.097
knots	ft/sec	5.925×10^{-1}
mph	ft/sec	6.818 x 10 ⁻¹
Btu	gram-calories	3.969×10^{-2}
joules	gram-calories	4.184
kg/m	gram/cm	1 x 10 ⁻¹
lb/ft	gram/cm	6.721×10^{-2}
lb/in.	gram/cm	5.601×10^{-3}
kg/cu m	grams/cu cm	1000
lb/cu ft	grams/cu cm	62.43
slugs	grams/cu cm	1.940
Btu/hr	horsepower	2,546
Btu/sec	horsepower	7.073×10^{-1}
ft-lb/min	horsepower	33,000

C. 11. /	1	
ft-lb/sec	horsepower	550
kilowatts	horsepower	7.457×10^{-1}
m-kg/sec	horsepower	76.04
metric hp	horsepower	1.014
Btu-sec	horsepower, metric	6.975×10^{-1}
horsepower	horsepower, metric	9.863 x 10 ⁻¹
kilowatts	horsepower, metric	7.355×10^{-1}
m-kg/sec	horsepower, metric	75.0
Btu	horsepower-hours	2.545×10^3
ft-lb	horsepower-hours	1.98×10^6
kilowatt-hours	horsepower-hours	7.457×10^{-1}
m-kg	horsepower-hours	2.737×10^5
cm Hg @ 32°F (0°C)	in H ₂ O @ 40°F (4°C)	1.868×10^{-1}
in Hg @ 32°F (0°C)	in H ₂ O @ 40°F (4°C)	7.355×10^{-2}
kg/sq m	in H ₂ O @ 40°F (4°C)	25.40
lb/sq ft.	in H ₂ O @ 40°F (4°C)	5.202
lb/sq in.	in H ₂ O @ 40°F (4°C)	3.613 x 10 ⁻²
atmospheres	in H ₂ O @ 60°F (15°C)	2.455×10^{-3}
in Hg @ 32°F (0°C)	in H_2^2O @ 60°F (15°C)	7.349×10^{-2}
atmospheres	in Hg @ 32°F (0°C)	3.342×10^{-2}
ft H ₂ O 40°F (4°C)	in Hg @ 32°F (0°C)	1.133
in. H ₂ O @ 40°F (4°C)	in Hg @ 32°F (0°C)	13.60
kg/sq m	in Hg @ 32°F (0°C)	3.453×10^2
lb/sq ft.	in Hg @ 32°F (0°C)	70.73
lb/sq in.	in Hg @ 32°F (0°C)	4.912 x 10 ⁻¹
cm	in.	2.54
Btu	Joules	9.483 x 10 ⁻⁴
ft-lb	Joules	7.376 x 10 ⁻¹
hp-hr	Joules	3.725 x 10 ⁻⁷
kg calories	Joules	2.389×10^{-4}
kg m	Joules	1.020×10^{-1}
watt-hr	Joules	2.778×10^{-4}
grams/cu cm	kg/cu m	1×10^{-3}
lb/cu ft	kg/cu m	62.43×10^{-3}
in H ₂ O @ 40°F (4°C)	kg/sq cm	3.28 x 10 ⁻⁷
in Hg @ 32°F (0°C)	kg/sq cm	28.96
lb/sq ft.	kg/sq cm	2.048×10^3
lb/sq in.	kg/sq cm	14.22
Btu	kilogram-calories	3.9680
	U	

4 lb	Irilaaruam calarias	2007
ft-lb	kilogram-calories	3087 4.269×10^2
m-kg	kilogram-calories	1×10^3
grams	kilograms	2.205
lb	kilograms	
OZ	kilograms	35.27 1 x 10 ⁵
cm	kilometers	
ft	kilometers	3.281×10^3
miles	kilometers	6.214 x 10 ⁻¹
nautical miles	kilometers	5.400 x 10 ⁻¹
Btu/sec	kilowatts	9.485×10^{-1}
ft-lb/sec	kilowatts	7.376×10^2
horsepower	kilowatts	1.341
kg calories/sec	kilowatts	2.389×10^{-1}
ft/sec, fps	km/hr	9.113 x 10 ⁻¹
knots	km/hr	5.396 x 10 ⁻¹
m/sec	km/hr	2.778×10^{-1}
mph	km/hr	6.214×10^{-1}
ft/sec, fps	knots	1.688
km/hr	knots	1.853
m/sec	knots	5.148×10^{-1}
mph	knots	1.151
grains	lb, avdp	7000
grams	lb, avdp	453.6
ounces	lb, avdp	16.0
poundals	lb, avdp	32.174
slugs	lb, avdp	3.108×10^{-2}
kg/cu m	lb/cu ft	16.02
grams/cu cm	lb/cu in.	27.68
lb/cu ft	lb/cu in.	1728
atmospheres	lb/sq in.	6.805×10^{-2}
ft H ₂ O @ 4°C	lb/sq in.	2.307
in Hg @ 0°C	lb/sq in.	2.036
kg/sq m	lb/sq in.	7.031×10^2
cu cm	liters	1×10^{3}
cu ft	liters	3.532 x 10 ⁻²
cu in	liters	61.03
gal Imperial	liters	2.200 x 10 ⁻¹
gal U.S.	liters	2.642×10^{-1}
quarts	liters	1.057
1		

ft-lb	meter-kilogram	7.233
joules	meter-kilogram	9.807
ft/sec, fps	meter/sec	3.281
km/hr	meter/sec	3.600
miles/hr	meter/sec	2.237
ft	meters	3.281
in.	meters	39.37
miles	meters	6.214 x 10 ⁻⁴
in.	microns	3.937×10^{-5}
ft	miles	5280
kilometers	miles	1.609
nautical mile	miles	8.690 x 10 ⁻¹
in Hg @ 0°C	milibars	2.953×10^{-2}
ft/sec, fps	mph	1.467
km/hr	mph	1.609
knots	mph	8.690 x 10 ⁻¹
m/sec	mph	4.470×10^{-1}
ft	nautical mile	6076.1
m	nautical mile	1852
miles	nautical mile	1.151
grains	ounces, avdp	4.375×10^2
grams	ounces, avdp	28.35
lb, avdp	ounces, avdp	6.250×10^{-2}
cu cm	ounces. fluid	29.57
cu in.	ounces. fluid	1.805
degree (arc)	radians	57.30
degrees/sec	radians/sec	57.30
rev/min, rpm	radians/sec	9.549
rev/sec	radians/sec	15.92×10^{-2}
radians/sec	rev/min. rpm	1.047×10^{-1}
radians	revolutions	6.283
lb	slug	32.174
sq ft	sq cm	1.076×10^{-3}
sq in.	sq cm	1.550×10^{-1}
sq cm	sq ft	929.0
sq in.	sq ft	144.0
sq cm	sq in.	6.452
Btu/sec	watts	9.485×10^{-4}

Appendix C

Gas Properties and Behavior

This information is reprinted from the Gas Processors Suppliers Association Engineering Data Book Courtesy of The Gas Processors Suppliers Association.

The Physical Constants of Hydrocarbons, Compressibility Charts and Pressure-Enthalpy Diagrams have been reprinted in both English and SI Units.

Physical Constants of Hydrocarbons—English units Compressibility Factors of Gases—English Units

Physical Constants of Hydrocarbons—SI units Compressibility Factors of Gases—SI Units

Pressure-Enthalpy Diagrams

SI Units English Units Carbon Dioxide Enthalpy—Pure Components Carbon Dioxide Methane Methane Propane Ethane Propane Ethane Ethylene Ethylene Propylene Propylene Nitrogen Nitrogen Iso-Pentane Iso-Pentane n-Butane n-Pentane Iso-Butane

Water

Physical Constants of Hydrocarbons¹


No.	To ormula o Combonud o Georgian weight						Critical constants		
		Boiling point ^o F., 14.696 psio	Vapor pressure, 100°F., psia	Freezing point, °F., 14.696 psio	Pressure, psio	Temperature, °F.	Volume, cu ft/lb		
1 2 3	Methane Ethane Propane	CH ₄ C ₂ H ₆ C ₃ H ₈	16.043 30.070 44.097	-258.69 -127.48 -43.67	(5000) (800) 190.	-296.46 ^d -297.89 ^d -305.84 ^d	667.8 707.8 616.3	-116.63 90.09 206.01	0.0991 0.0788 0.0737
4 5	n-Butane Isobutane	C4H10 C4H10	58.124 58.124	31.10 10.90	51.6 72.2	-217.05 -255.29	550.7 529.1	305.65 274.98	0.0702
6 7 8	n-Pentane Isopentane Neopentane	C ₅ H ₁₂ C ₅ H ₁₂ C ₅ H ₁₂	72.151 72.151 72.151	96.92 82.12 49.10	15.570 20.44 35.9	-201.51 -255.83 2.17	488.6 490.4 464.0	385.7 369.10 321.13	0.0675 0.0679 0.0674
9 10 11 12 13	n-Hexane 2-Methylpentane 3-Methylpentane Neohexane 2,3-Dimethylbutane	C ₆ H ₁₄ C ₆ H ₁₄ C ₆ H ₁₄ C ₆ H ₁₄ C ₆ H ₁₄	86.178 86.178 86.178 86.178 86.178	155.72 140.47 145.89 121.52 136.36	4.956 6.767 6.098 9.856 7.404	-139.58 -244.63 -147.72 -199.38	436.9 436.6 453.1 446.8 453.5	453.7 435.83 448.3 420.13 440.29	0.0688 0.0681 0.0681 0.0667 0.0665
14 15 16 17 18 19 20 21	n-Heptone 2-Methylhexane 3-Methylhexane 3-Ethylpentane 2,2-Dimethylpentane 2,4-Dimethylpentane 3,3-Dimethylpentane Triptane	C7H16 C7H16 C7H16 C7H16 C7H16 C7H16 C7H16 C7H16	100.205 100.205 100.205 100.205 100.205 100.205 100.205 100.205	209.17 194.09 197.32 200.25 174.54 176.89 186.91 177.58	1.620 2.271 2.130 2.012 3.492 3.292 2.773 3.374	-131.05 -180.89 -181.48 -190.86 -182.63 -210.01 -12.82	396.8 396.5 408.1 419.3 402.2 396.9 427.2 428.4	512.8 495.00 503.78 513.48 477.23 475.95 505.85 496.44	0.0691 0.0673 0.0646 0.0665 0.0665 0.0668 0.0662 0.0636
22 23 24	n-Octane Disobutyl Ispoctane	C ₈ H ₁₈ C ₈ H ₁₈ C ₈ H ₁₈	114.232 114.232 114.232	258.22 228.39 210.63	0.537 1.101 1.708	-70.18 -132.07 -161.27	360.6 360.6 372.4	564.22 530.44 519.46	0.0690 0.0676 0.0656
25 26	n-Nonane n-Decane	C ₁₀ H ₂₀ C ₁₀ H ₂₂	128.259 142.286	303.47 345.48	0.179 0.0597	-64.28 -21.36	332. 304.	610.68 652.1	0.0684
27 28 29	Cyclopentane Methylcyclopentane Cyclohexane	C ₆ H ₁₀ C ₆ H ₁₂ C ₆ H ₁₂	70.135 84.162 84.162	120.65 161.25 177.29	9.914 4.503 3.264	-136.91 -224.44 43.77	653.8 548.9 591.	461.5 499.35 536.7	0.059 0.0607 0.0586
30	Methylcyclohexane Ethylene	C2H4	98.189 28.054	213.68 -154.62	1.609	-195.87 -272.45 ^d	503.5 729.8	570.27 48.58	0.0600
32 33 34 35 36	Propene 1-Butene Cis-2-Butene Trans-2-Butene Isobutene	C ₃ H ₆ C ₄ H ₈ C ₄ H ₈ C ₄ H ₈	42.081 56.108 56.108 56.108 56.108	-53.90 20.75 38.69 33.58 19.59	226.4 63.05 45.54 49.80 63.40	-301.45 ^d -301.63 ^d -218.06 -157.96 -220.61	669. 583. 610. 595. 580.	196.9 295.6 324.37 311.86 292.55	0.0689 0.0685 0.0668 0.0680 0.0682
37 38 39 40	1.—Pentene 1.2.—Butadiene 1.3.—Butadiene Isoprene	C ₅ H ₁₀ C ₄ H ₆ C ₄ H ₆ C ₅ H ₈	70.135 54.092 54.092 68.119	85.93 51.53 24.06 93.30	19.115 (20.) (60.) 16-672	-265.39 -213.16 -164.02 -230.74	590. (653.) 628. (558.4)	376.93 (339.) 306. (412.)	0.0697 (0.0649) 0.0654 (0.0650)
41 42 43	Acetylene Benzene Toluene	C ₂ H ₂ C ₆ H ₆ C ₇ H ₈	26.038 78.114 92.141	-119° 176.17 231.13 277.16	3.224 1.032 0.371	-114,d 41,96 -138,94 -138,91	890.4 710.4 595.9 523.5	95.31 552.22 605.55 651.24	0.0695 0.0531 0.0549 0.0564
44 45 46 47	Ethylbenzene a-Xylene m-Xylene p-Xylene	CaH10 CaH10 CaH10 CaH10	106.168 106.168 106.168 106.168	291.97 282.41 281.05 293.29	0.264 0.326 0.342 (0.24)	-138.91 -13.30 -54.12 55.86 -23.10	541.4 513.6 509.2 580.	675.0 651.02 649.6 706.0	0.0557 0.0567 0.0572 0.0541
48	Styrene Isopropylbenzene	C _p H _s C _p H ₁₂	104.152 120.195 32.042	306.34 148.1(2)	0.188 4.63(22)	-140.82 -143.82(22)	465.4 1174.2(21)	676.4 462.97(21)	0.0570
50 51 52 53 54 55	Methyl Alcohol Ethyl Alcohol Carbon Monoxide Carbon Dioxide Hydrogen Sulfide Sulfur Dioxide	CH40 C2H60 CO CO2 H2S SO2	46.069 28.010 44.010 34.076 64.059	148.1(2) 172.92(22) -313.6(2) -109.3(2) -76.6(24) 14.0(7)	2.3(7) — 394.0(6) 88.(7)	-143.82(22) -173.4(22) -340.6(2) -117.2(7) -103.9(7)	925.3(21) 507.(17) 1071.(17) 1306.(17) 1145.(24)	469.58(21) -220.(17) 87.9(23) 212.7(17) 315.5(17)	0.0589(21) 0.0580(21) 0.0532(17) 0.0342(23) 0.0459(24) 0.0306(24)
56 57 58 59 60	Ammonid Air Hydrogen Oxygen Nitrogen	NH ₃ N ₂ O ₂ H ₂ O ₂ N ₂	17.031 28.964 2.016 31.999 28.013	-28.2(24) -317.6(2) -423.0(24) -297.4(2) -320.4(2)	212.(7)	-107.9(2) -434.8(24) -361.8(24) -346.0(24)	1636.(17) 547.(2) 188.1(17) 736.9(24) 493.0(24)	270.3(24) -221.3(2) -399.8(17) -181.1(17) -232.4(24)	0.0681(17) 0.0517(3) 0.5167(24) 0.0382(24) 0.0514(17)
61 62 63	Chlorine Water Helium	CI ₂ H ₂ O He	70.906 18.015 4.003	-29.3(24) 212.0	158.(7) 0.9492(12)	-149.8(24) 32.0	1118.4(24) 3208.(17)	291.(17) 705.6(17)	0.0281(17) 0.0500(17)
64	Hydrogen Chloride	HCI	36.461	-121(16)	925.(7)	-173.6(16)	1198.(17)	124.5(17)	0.0208(17


Physical Constants of Hydrocarbons¹


Density of liquid; 60°F., 14.696 psia				factor (18)	factor Je F.		aensity, 6 14.696 psi Ideal gas	a	Specific 60° F 14,696	11		
Specific gravity 60°F./60°F.a.b	b/gal+a (W+ in vacuum)	b/gol * 0,c (Wt in air)	/lb Mole*	Temperature Coefficient of density ^{‡9}	tzer acentric fac	pressibility real gas, Z .696 psia, 60	Specific gravity Air = 1*	fr gas/lb*	liquid"	Cp Btu/lb Ideal		No
Spe 60%	3€	18/g	Gol/Ib	10°5	ğ.	Com 14	Spec	3	3-	gas	Enquia	
0.3 ¹ 0.3564 ^h 0.5077 ^h	2.5 ¹ 2.971 ^h 4.233 ^h	2.5 ¹ 2.962 ^h 4.223 ^h	6.4 ¹ 10.12 ^h 10.42 ^h	0.00152h	0.0104 0.0986 0.1524	0.9981 0.9916 0.9820	0.5539 1.0382 1.5225	23.65 12.62 8.606	59.1 37.5h 36.43h	0.5266 0.4097 0.3881	0.9256 0.5920	1
0.5844 ^h 0.5631 ^h	4.872h 4.695h	4.865 ^h 4.686 ^h	11.93 ^h 12.38 ^h	0.00117h 0.00119h	0.2010	0.9667	2.0068 2.0068	6.529	31.81h 30.65h	0.3867 0.3872	0.5636	
0.6310 0.6247 0.5967h	5,261 5,208 4,975 ^h	5.251 5.199 4.965 ^h	13.71 13.85 14.50 ^h	0.00087 0.00090 0.00104 ^h	0.2539 0.2223 0.1969	0.9549 0.9544 0.9510	2.4911 2.4911 2.4911	5.260 5.260 5.260	27.67 27.39 26.17 ^h	0.3883 0.3827 (0.3866)	0.5441 0.5353 0.554	
0.6640 0.6579 0.6689 0.6540 0.6664	5.536 5.485 5.577 5.453 5.556	5.526 5.475 5.568 5.443 5.546	15.57 15.71 15.45 15.81 15.51	0.00075 0.00078 0.00075 0.00078 0.00075	0.3007 0.2825 0.2741 0.2369 0.2495		2.9753 2.9753 2.9753 2.9753 2.9753	4.404 4.404 4.404 4.404 4.404	24.38 24.15 24.56 24.01 24.47	0.3864 0.3872 0.3815 0.3809 0.378	0.5332 0.5264 0.507 0.5165 0.5127	1 1 1 1
0.6882 0.6830 0.6917 0.7028 0.6782 0.6773 0.6976 0.6946	5.738 5.694 5.767 5.859 5.654 5.647 5.816 5.791	5.728 5.685 5.757 5.850 5.645 5.637 5.807 5.782	17.46 17.60 17.38 17.10 17.72 17.75 17.23 17.30	0.00069 0.00068 0.00069 0.00070 0.00072 0.00072 0.00065 0.00069	0.3498 0.3336 0.3257 0.3095 0.2998 0.3048 0.2840 0.2568		3.4596 3.4596 3.4596 3.4596 3.4596 3.4596 3.4596 3.4596	3,787 3,787 3,787 3,787 3,787 3,787 3,787 3,787	21.73 21.57 21.84 22.19 21.41 21.39 22.03 21.93	0.3875 (0.390) (0.390) (0.390) (0.395) 0.3906 (0.395) 0.3812	0.5283 0.5223 0.511 0.5145 0.5171 0.5247 0.502 0.4995	1 1 1 1 1 2
0.7068 0.6979 0.6962	5.893 5.819 5.804	5.883 5.810 5.795	19.39 19.63 19.68	0.00062 0.00065 0.00065	0.4018 0.3596 0.3041		3.9439 3.9439 3.9439	3.322 3.322 3.322	19.58 19.33 19.28	(0.3876) (0.373) 0.3758	0.5239 0.5114 0.4892	2 2 2 2
0.7217	6.017	6.008	21.32	0.00063	0.4455	QT	4.4282 4.9125	2,959 2,667	17.80 16.33	0.3840 0.3835	0.5228	2 2
0.7504 0.7536	6.256	6.247	11.21 13.40	0.00070	0.1955 0.2306	0.9657	2.4215 2.9057	5.411 4.509	33.85 28.33	0.2712 0.3010	0.4216	2
0.7834	6.531	6.522	12.89 15.22	0.00068	0.2133	_	2.9057 3.3900	4.509 3.865	29.45 24.94	0.2900 0.3170	0.4332	3
0.5220h 0.6013h 0.6271h 0.6100h 0.6004h 0.6457 0.658h 0.6272h 0.6272h	4.352h 5.013h 5.228h 5.086h 5.006h 5.383 5.486h 5.229h 5.720	4.343h 5.004h 5.219h 5.076h 4.996h 5.374 5.470h 5.220h 5.711	9.67h 11.19h 10.73h 11.03h 11.21h 13.03 9.86h 10.34h 11.91	0.00189h 0.00116h 0.00098h 0.00107h 0.00120h 0.00089 0.00098h 0.00113h 0.00086	0.0868 0.1405 0.1906 0.1953 0.2220 0.1951 0.2925 0.2485 0.1955 0.2323	0.9938 0.9844 0.9704 0.9661 0.9662 0.9689 0.9550 (0.965) (0.965) (0.962)	0.9686 1.4529 1.9372 1.9372 1.9372 1.9372 2.4215 1.8676 1.8676 2.3519	13.53 9.018 6.764 6.764 6.764 6.764 5.411 7.016 7.016 5.571	39.25h 33.91h 35.36h 34.40h 33.86h 29.13 38.49h 36.69h 31.87	0.3622 0.3541 0.3548 0.3269 0.3654 0.3701 0.3635 0.3458 0.3412 0.357	0.585 0.535 0.5271 0.5351 0.549 0.5196 0.5408 0.5079 0.5192	Action to the taken to take
0.615 ^k 0.8844 0.8718 0.8718	7.373 7.268 7.268	7.365 7.260 7.259	10.59 12.68 14.61	0.00066 0.00060 0.00054	0.1803 0.2125 0.2596 0.3169	0.9925 0.929(15) 0.903(21)	0.8990 2.6969 3.1812 3.6655	14.57 4.858 4.119 3.574	35.82 29.94 25.98	0.3966 0.2429 0.2598 0.2795	0.4098 0.4012 0.4114	
0.8687 0.8687 0.8657 0.9110 0.8663	7.377 7.243 7.218 7.595 7.223	7,367 7,234 7,209 7,586 7,214	14.39 14.66 14.71 13.71 16.64	0.00055 0.00054 0.00054 0.00057 0.00054	0.3023 0.3278 0.3138 0.2862		3.6655 3.6655 3.6655 3.5959 4.1498	3.574 3.574 3.574 3.644 3.157	26.37 25.89 25.80 27.67 22.80	0.2914 0.2782 0.2769 0.2711 0.2917	0.4418 0.4045 0.4083 0.4122 (0.414)	
0.796(3) 0.794(3) 0.801m(8) 0.827h(6) 0.79h(6)	6.64 6.62 6.68m 6.89h 6.59h	6.63 6.61 6.67m 6.88h 6.58h	4.83 6.96 4.19m 6.38h 5.17h	=	0.041 0.225 0.100	0.9995(15) 0.9943(15) 0.9903(15)	1.1063 1.5906 0.9671 1.5195 1.1765	11.84 8.237 13.55 8.623 11.14	78.6 54.5 59.5h 73.3h	0.3231 v(24) 0.3323 v(24) 0.2484(13) 0.1991(13) 0.238(4)	0.594(7) 0.562(7)	
1.397 ^h (14) 0.6173(11) 0.856 ^m (8)	11.65 ^h 5.15 7.14 ^m	11,64 ^h 5.14 7.13 ^m	5.50 ^h 3.31 4.06 ^m		0.246	0.9996(15)	2.2117 0.5880 1.0000	5,924 22-28 13.10	69.0 ^h	0.145(7) 0.5002(10) 0.2400(9)	0.325 ^h (7) 1.114 ^h (7)	
0.07m(3) 1,140(25) 0.810(26) 1.414(14)	9.50 ^m 6.75 ^m 11.79	9.49 ^m 6.74 ^m 11.78	3.37 ^m 4.15 ^m 6.01		0.000 0.0213 0.040	1.0006(15) 0.9997(15)	0.0696 1.1048 0.9672 2.4481	188.2 11.86 13.55 5.352	63.1	3.408(13) 0.2188(13) 0.2482(13) 0.119(7)	Ξ	
0.8558(14)	7.135	7.126	5.11	0.00335*	0.348		1.2588	10.41	74.3	0.4446(13)	1.0009(7)	6

Physical Constants of Hydrocarbons¹


		Ca	lorific valu	e, 60° F			*0	ě,	Flammability limits, val		ASTM		
		Net		Gross		0	gr, a	ired stion	%	in	0	ctane	
No.	Compound	Btu/cu ft, ideal gas, 14.696 psia (20)*	Stu/cu ft, ideal gas, 14,696 psia (20)*	b id in vacuum)	log.	of vaporization, 196 psia at bailing nt, 8tv/lb	Refractive indexa, nD	Air required for for combustion ideal gas*	air mi		nethod 7	20.02.50	
		Btu/cu Ideal g psia (2	Btu/cu f Ideal go psia (20	Bru/lb liquid (w) in	Btv/gal liquid*	Hear of 14.696 point,	68° F	cu ft/	Lower	Higher	Motor r D-35	Research method D_908	
1 2	Methane Ethane	909.1 1617.8	1009.7 1768.8	-		219.22 210.41		9.54 16.70	5.0	15.0	- Lorf		
3	Propane	2316.1	2517.5	21513	91065	183.05		23.86	2.9	13.0	+.05 ^f 97.1	+1.61,f +1.81,f	
4 5	n-Butane Isobutane	3010.4 3001.1	3262.1 3252.7	21139 21091	102989 99022	165.65 157.53	1.3326h	31.02 31.02	1.8	8.4	89.6 ¹ 97.6	93.8 ¹ +.10 ¹	
6	n-Pentane	3707.5	4009.6	20928	110102	153.59	1.35748	38.18	1.4	8.3	62.61	61.71	
7 8	Isopentane Neopentane	3698.3 3682.6	4000.3 3984.6	20889	108790 103599	147.13 135.58	1.35373 1.342h	38.18	1.4	(8.3)	90.3 80.2	92.3 85.5	
9	n-Hexane	4403.7	4756.2	20784	115060	143.95	1.37486	45.34	1.2	7.7	26.0	24.8	
10	2-Methylpentane 3-Methylpentane	4395.8 4398.7	4748.1 4751.0	20757	113852 115823	138.67	1.37145	45.34 45.34	1.2	(7.7)	73.5 74.3	73.4 74.5	
12	Neohexane	4382.6	4735.0	20710	112932	131.24	1.36876	45.34	1.2	(7.7)	93.4	91.8	
14	2,3-Dimethylbutane	4391.7 5100.2	4744.0 5502.8	20742	115243	136.08	1.37495	45.34 52.50	1.0	7.0	94.3	+0.3f	
15	2-Methylhexane	5092.1	5494.8	20658	117627	131.59	1.38485	52.50	(1.0)	(7.0)	46.4	42.4	
16	3—Methylhexane 3—Ethylpentane	5095.2 5098.2	5497.8 5500.9	20668 20679	119192 121158	132.11 132.83	1.38864	52.50 52.50	(1.0)	(7.0) (7.0)	55.8	52.0 65.0	
18	2,2-Dimethylpentane	5079.4	5482.1	20620	116585	125.13	1.38215	52.50	(1.0)	(7.0)	95.6	92.8	
19	2,4-Dimethylpentane 3,3-Dimethylpentane	5084.3 5085.0	5487.0 5487.6	20636	116531	126.58 127.21	1.38145	52.50	(1.0)	(7.0)	83.8	83.1	
21	Triptane	5081.0	5483.6	20638 20627	119451	124.21	1.39092	52.50 52.50	(1.0)	(7.0)	86.6 +0.1f	80.8 +1.8f	
22	n-Octane	5796.7	6249.7	20604	121419	129.53	1.39743	59.65	0.96				
23	Diisobutyl Isooctone	5781.3 5779.8	6234.3 6232.8	20564 20570	119662 119388	122.8	1.39246	59.65 59.65	(0.98)	-	55.7 100.	55.2	
25	n-Nonane	6493.3	6996.5	20544	123613	123.76	1.40542	66.81	0.875	2.9	100.	100.	
26	n-Decane	7188.6	7742.1	20494	125444	118.68	1.41189	73.97	0.785	2.6	_	-	
27	Cyclopentane	3512.0	3763.7	20188	126296	167.34	1.40645	35.79	(1.4)	-	84.9	+0.1f	
28 29	Methylcyclopentane Cyclohexane	4198.4	4500.4 4480.8	20130	126477	147.83	1.40970	42.95	(1.2)	8.35	80.0	91.3	
30	Methylcyclahexane	4862.8	5215.2	20035	129066	153.0 136.3	1.42623	42.95	1.3	7.8	77.2	83.0 74.8	
31	Ethylene	1499.0	1599.7	-	-	207.57	-	14.32	2.7	34.0	75.6	+.031	
32	Propene 1-Butene	2182.7	2333.7 3080.7	20678	103659	188.18		21.48 28.63	2.0 1.6	9.3	84.9	+0.2 [‡] 97.4	
34	Cis-2-Butene	2871.7	3073.1	20611	107754	178.91		28.63	(1.6)	-	83.5	100.	
35 36	Trans-2-Butene	2866.8 2860.4	3068.2 3061.8	20584 20548	104690	174.39		28.63	(1.6)				
37	1-Pentene	3575.2	3826.9	20548	110610	154.46	1.37148	35.79	1.4	8.7	77.1	90.9	
38	1,2-Butadiena 1,3-Butadiena	2789.0 2730.0	2940.0 2881.0	20447	112172 104826	(181.)	-	26.25	(2.0)	(12.)	-	_	
40	Isoprene	3410.8	3612.1	19964	114194	(153.)	1.42194	26.25 33.41	(1.5)	11.5	81.0	99.1	
41	Acetylene	1422.4	1472.8		1200	_	_	11.93	2.5	80.	-	700	
42	Benzene Toluene	3590.7 4273.3	3741.7 4474.7	17992 18252	132655 132656	169.31 154.84	1.50112	35.79 42.95	1.39	7.99 7.19	+2.8f +0.3f	+5.8f	
44	Ethylbenzene	4970.0	5221.7	18494	134414	144.0	1.49588	50.11	0.999	6.79	97.9	10.81	
45	o_Xylene	4958.3	5210.0	18445	136069	149.1	1.50545	50.11	1.19	6.49	100.	-	
46 47	m-Xylene p-Xylene	4956.8 4956.9	5208.5 5208.5	18441 18445	133568	147.2	1.49722	50.11	1.19	6.49	+2.8f +1.2f	+4.0f +3.4f	
48	Styrene	4826.7	5030.0	18150	137849	(151.)	1.54682	47.72	1.1	6.1	+0.2f	N42 1	
49	Isopropylbenzene	5661-4	5963.4	18665	134817	134.3	1.49145	57.27	0.889	6,59	99.3	12.1f	
50	Methyl Alcahol Ethyl Alcahol			9760 12780	64771 84600	473.(2) 367.(2)	1.3288(8)	7.16	6.72(5)	36.50 18.95	_		
52	Carbon Monoxide	-	321.(13)			92.7(14)		2.39	12-50(5)	74.20	_		
53 54	Carbon Dioxide Hydrogen Sulfide	588.(16)	637.(16)	\equiv		238-2n(14) 235.6(7)		7.16	4.30(5)	45.50	-		
55	Sulfur Dioxide			-		166.7(14)		-	Carrier .		-		
56 57	Ammonia Air	359.(16)	434.(16)			587.2(14) 92.(3)		3.58	15.50(5)	27,00		-	
58	Hydrogen	274.(13)	324.(13)		200	193.9(14)	_	2.39	4.00(5)	74.20			
59	Oxygen Nitrogen				-	91.6(14) 87.8(14)						3.00	
61	Chlorine	7==1	_	-		123.8(14)		-			-	-	
62	Water Helium					970.3(12)	1.3330(8)			-			
64	Hydrogen Chloride	();		_	-	185.5(14)		200		1			










Compressibility of low-molecular-mass natural gases







Compressibility of low-molecular-mass natural gases









PHYSICAL CONSTANTS OF HYDROCARBONS(27)


	See Note No. →		1.	2.		3.						
1					8		Critical constants					
No.	Compound	Compound spin-		Boiling point, °C 101,3250 kPa (abs)	Vapor pressure, kPa (abs) 40 °C	Freezing point, °C 101.3250 kPa (abs)	Pressure, kPa (abs)	Temperature, K	Volume, m ³ /kg			
1 2 3 4 5	Methane Ethane Propane n-Butane Isobutane	CH ₄ C ₂ H ₆ C ₃ H ₈ C ₄ H ₁₀ C ₄ H ₁₀	16.043 30.070 44.097 58.124 58.124	-161.52(28) -88.58 -42.07 -0.49 -11.81	(35 000.) (6 000.) 1 341. 377. 528.	-182.47 ^d -182.80 ^d -187.68 ^d -138.36 -159.60	4 604. 4 880. 4 249. 3 797. 3 648.	190.55 305.43 369.82 425.16 408.13	0.006 17 0.004 92 0.004 60 0.004 39 0.004 52			
6 7 8	n-Pentane Isopentane Neopentane	C ₅ H ₁₂ C ₅ H ₁₂ C ₅ H ₁₂	72.151 72.151 72.151	36.06 27.84 9.50	115.66 151.3 269.	-129.73 -159.90 -16.55	3 369. 3 381. 3 199.	469.6 460.39 433.75	0.004 21 0.004 24 0.004 20			
9 10 11 12 13	n-Hexane 2-Methylpentane 3-Methylpentane Neohexane 2,3-Dimethylbutane	C ₆ H ₁₄ C ₆ H ₁₄ C ₆ H ₁₄ C ₆ H ₁₄ C ₆ H ₁₄	86.178 86.178 86.178 86.178 86.178	68.74 60.26 63.27 49.73 57.98	37.28 50.68 45.73 73.41 55.34	-95.32 -153.66 -99.870 -128.54	3 012, 3 010, 3 124, 3 081, 3 127,	507.4 497.45 504.4 488.73 499.93	0.004 29 0.004 26 0.004 26 0.004 17 0.004 15			
14 15 16 17 18 19 20 21	n-Heptane 2-Methylhexane 3-Methylhexane 3-Ethylpentane 2,2-Dimethylpentane 2,4-Dimethylpentane 3,3-Dimethylpentane Triptane	C7H16 C7H16 C7H16 C7H16 C7H16 C7H16 C7H16 C7H16	100.205 100.205 100.205 100.205 100.205 100.205 100.205 100.205	98.42 90.05 91.85 93.48 79.19 80.49 86.06 80.88	12.34 17.22 16.16 15.27 26.32 24.84 20.93 25.40	-90.582 -118.27 -118.60 -123.81 -119.24 -134.46 -24.91	2 736. 2 734. 2 814. 2 891. 2 773. 2 737. 2 945. 2 964.	540.2 530.31 535.19 540.57 520.44 519.73 536.34 531.11	0.004 31 0.004 20 0.004 03 0.004 15 0.004 15 0.004 17 0.004 13 0.003 97			
22 23 24 25 26 27 28 29 30	n-Octane Disobutyl Isooctane n-Nonane n-Decane Cyclopentane Methylcyclopentane Cyclohexane Methylcyclohexane	C8H18 C8H18 C8H18 C9H20 C10H22 C5H10 C6H12 C6H12 C7H14	114.232 114.232 114.232 128.259 142.286 70.135 84.162 98.189	125.67 109.11 99.24 150.82 174.16 49.25 71.81 80.73 100.93	4.143 8.417 12.96 1.40 0.4732 73.97 33.85 24.63 12.213	-56.76 -91.200 -107.38 -53.49 -29.64 -93.866 -142.46 6.554 -126.59	2 486. 2 486. 2 568. 2 288. 2 099. 4 502. 3 785. 4 074. 3 472.	568.76 549.99 543.89 594.56 617.4 511.6 532.73 553.5 572.12	0.004 31 0.004 22 0.004 10 0.004 27 0.004 24 0.003 71 0.003 79 0.003 68 0.003 75			
31 32 33 34 35 36 37 38 39 40	Ethene (Ethylene) Propene (Propylene) 1-Butene (Butylene) cis-2-Butene trans-2-Butene 1-Pentene 1,2-Butadiene 1,3-Butadiene	C1H4 C3H6 C4H8 C4H8 C4H8 C5H16 C4H6 C4H6	28.054 42.081 56.108 56.108 56.108 56.108 70.135 54.092 54.092 68.119	-103.77(29) -47.72 -6.23 3.72 0.88 -6.91 29.96 10.85 -4.41 34.07	1596. 451.9 337.6 365.8 452.3 141.65 269. 434. 123.77	-169.15 ^d -185.25 ^d -185.35 ^d -138.91 -105.55 -140.35 -165.22 -136.19 -108.91 -145.95	5 041. 4 600. 4 023. 4 220. 4 047. 3 999. 3 529. (4 502.) 4 330. (3 850.)	282.35 364.85 419.53 435.58 428.63 417.90 464.78 (444.) 425. (484.)	0.004 67 0.004 30 0.004 28 0.004 17 0.004 24 0.004 26 0.004 22 (0.004 05) 0.004 09 (0.004 06)			
41 42 43 44 45 46 47 48 49	Acetylene Benzene Toluene Ethylbenzene o-Xylene m-Xylene p-Xylene Styrene	C ₂ H ₂ C ₆ H ₆ C ₇ H ₈ C ₈ H ₁₀ C 038 78.114 92.141 106.168 106.168 106.168 106.168 104.152 120.195	-84.88 ^e 80.09 110.63 136.20 144.43 139.12 138.36 145.14 152.41	24.38 7.895 2.87 2.05 2.53 2.65 1.85 1.47	-80.8 ^d 5.533 -94.991 -94.975 -25.18 -47.87 13.26 -30.61 -96.035	6 139. 4 898. 4 106. 3 609. 3 734. 3 536. 3 511. 3 999. 3 209.	308.33 562.16 591.80 617.20 630.33 617.05 616.23 647.6 631.1	0.004 34 0.003 28 0.003 43 0.003 53 0.003 54 0.003 54 0.003 56 0.003 38 0.003 57				
50 51 52 53 54 58	Methyl alcohol Ethyl alcohol Carbon monoxide Carbon dioxide Hydrogen sulfide	CH ₄ O C ₂ H ₆ O CO CO ₂ H ₂ S SO ₂	32.042 46.069 28.010 44.010 34.076 64.069	64.54 78.29 -191.49 -78.51 ^e -60.31 -10.02	35.43 17.70 — 2.881. 630.8	-97.68 -114.1 -205.0 ^d -56.57 ^d -85.53 ^d -75.48 ^d	8 096. 6 383. 3 499.(33) 7 382.(33) 9 005. 7 894.	512.64 513.92 132.92(33) 304.19(33) 373.5 430.8	0.003 68 0.003 62 0.003 32(33) 0.002 14(33) 0.002 87 0.001 90			
56 57 58 59 60 61 62 63	Ammonia Air Hydrogen Oxygen Nitrogen Chlorine Water Helium	NH ₃ N ₂ +O ₂ H ₂ O ₂ N ₂ Cl ₂ H ₂ O He	17.031 28.964 2.016 31.999 28.013 70.906 18.015 4.003 36.461	-33.33(30) -194.2(2) -252.87 ^b -182.962 ^b -195.80(31) -34.03 100.00 ^b -268.93(32) -85.00	1513. ————————————————————————————————————	-77.74 ^d -259.2 ^d -218.8 ^d -210.0 ^d -101.0 ^d 0.00 -114.18 ^d	11 280, 3 771.(2) 1 297, 5 081, 3 399, 7 711, 22 118, 227.5(32) 8 309,	405.6 132.4(2) 33.2 154.7(33) 126.1 417. 647.3 5.2(32) 324.7	0.004 25 0.003 23(3) 0.032 24 0.002 29 0.003 22 0.001 75 0.003 18 0.014 36(32) 0.002 22			


PHYSICAL CONSTANTS OF HYDROCARBONS(27)

	4.	en defini		5.	6.	7.		8.		- 1	9.	
10	Density of I 01.3250 kPa (at	iquid s), 15 °C		int of	ā	or of , 15°C	101.325	deal gas * O kPa (abs), 15°C	101 3350	at capacity kPa (abs),	
Relative density 15 °C/15 °C a.0	gym3 •.a (mass in vacuum) gym3 •.a.e (Apparent mass in air)		Temperature coefficient density, at 15 °C *.a -1/°C	acentric factor,	Compressibility factor real gas, Z 101,3250 kPa (abs), 1	ve density 1	ic volume	Volume ratio gas/(liquid in vacuum)	15 °C C kJ/(kg • °C		No.	
Relath	kg/m ³ •	kg/m ³ * (Appare in air)	m ³ /kmol	Tempe densit	Pitzer	Compi rest gr 101,3	Relative Air = 1	Specific v m ³ /kg	Volume gas/(liqu	Ideal gas	Liquid	
(0.3) ¹ 0.3581 ^h 0.5083 ^h 0.5847 ^h 0.5637 ^h	(300.) ⁱ 357.8 ^{h,x} 507.8 ^{h,x} 584.2 ^h 563.2 ^h	(300.) ¹ 356.6 ^h 506.7 ^h 583.1 ^h 562.1 ^h	(0.05) ¹ 0.084 04 ^h 0.086 84 ^h 0.099 49 ^h 0.103 2 ^h	0.002 74 ^h 0.002 11 ^h 0.002 14 ^h	0.0126 0.0978 0.1541 0.2015 0.1840	0.9981 0.9915 0.9810 0.9641 0.9665	0.5539 1.0382 1.5225 2.0068 2.0068	1.474 0.7863 0.5362 0.4068 0.4068	(442.)i 281.3h 272.3h 237.6h 229.1h	2.204 1.706 1.625 1.652 1.616	3.807 2.476 2,366(41) 2,366(41)	1 2 3 4 5
0.6316 0.6250 0.5972 ^h	631.0 624.4 596.7 ^h	629.9 623.3 595.6 ^h	0.114 3 0.115 6 0.120 9 ^h	0.001 57 0.001 62 0.001 87 ^h	0.2524 0.2286 0.1967	0.942† 0.948† 0.9538	2.4911 2.4911 2.4911	0.3277 0.3277 0.3277	206.8 204.6 195.5 ^h	1.622 1.600 1.624	2.292(41) 2.239 2.317	7 8
0.6644 0.6583 0.6694 0.6545 0.6668	663.8 657.7 668.8 653.9 666.2	662.7 656.6 667.7 652.8 665.1	0.129 8 0.131 0 0.128 9 0.131 8 0.129 4	0.001 35 0.001 40 0.001 35 0.001 40 0.001 35	0.2998 0.2784 0.2741 0.2333 0.2475	0.910†	2.9753 2.9753 2.9753 2.9753 2.9753 2.9753	0.2744 0.2744 0.2744 0.2744 0.2744	182.1 180.5 183.5 179.4 182.8	1.613 1.602 1.578 1.593 1.566	2.231 2.205 2.170 2.148 2.146	10 11 12 13
0.6886 0.6835 0.6921 0.7032 0.6787 0.6777 0.6980 0.6950	688.0 682.8 691.5 702.6 678.0 677.1 697.4 694.4	686.9 681.7 690.4 701.5 676.9 676.0 696.3 693.3	0.145 6 0.146 8 0.144 9 0.142 6 0.147 8 0.148 0 0.143 7 0.144 3	0.001 24 0.001 22 0.001 24 0.001 26 0.001 30 0.001 30 0.001 17 0.001 24	0.3494 0.3303 0.3239 0.3107 0.2876 0.3031 0.2681 0.2509	0.852†	3.4596 3.4596 3.4596 3.4596 3.4596 3.4596 3.4596 3.4596	0.2360 0.2360 0.2360 0.2360 0.2360 0.2360 0.2360 0.2360	162.4 161.1 163.2 165.8 160.0 159.8 164.6 163.9	1,606 1,595 1,584 1,613 1,613 1,651 1,603 1,578	2.209 2.183 2.137 2.150 2.161 2.193 2.099 2.088	14 15 16 17 18 19 20 21
0.7073 0.6984 0.6966 0.7224 0.7346 0.7508 0.7541 0.7838 0.7744	706.7 697.7 696.0 721.7 733.9 750.2 753.4 783.1 773.7	705.6 696.6 694.9 720.6 732.8 749.1 752.3 782.0 772.6	0.161 6 0.163 7 0.164 1 0.177 7 0.193 9 0.093 49 0.111 7 0.107 5 0.126 9	0.001 12 0.001 17 0.001 17 0.001 13 0.000 99 0.001 26 0.001 28 0.001 22 0.001 13	0.3981 0.3564 0.3041 0.4452 0.4904 0.1945 0.2308 0.2098 0.2364	0.783†	3.9439 3.9439 3.9439 4.4282 4.9126 2.4215 2.9057 2.9057 3.3900	0.2070 0.2070 0.2070 0.1843 0.1662 0.3371 0.2809 0.2809 0.2408	146.3 144.4 144.1 133.0 122.0 252.9 211.7 220.0 186.3	1.601 1.573 1.599 1.598 1.595 1.133 1.258 1.211 1.324	2.191 2.138 2.049 2.184 2.179 1.763 1.843 1.811 1.839	22 23 25 25 26 27 26 27 28 28 28 28 28
0.5231 ^h 0.6019 ^h 0.6277 ^h 0.6105 ^h 0.6010 ^h 0.6462 0.6576 ^h 0.6280 ^h 0.6866	522.6 ^{h,x} 601.4 ^h 627.1 ^h 610.0 ^h 600.5 ^h 645.6 657.4 ^h 627.4 ^h 686.0	521.5 ^h 600.3 ^h 626.0 ^h 608.9 ^h 599.4 ^h 644.5 656. ^h 626.3 ^h 684.9	0.080 69 ^h 0.093 30 ^h 0.089 47 ^h 0.091 98 ^h 0.093 44 ^h 0.108 6 0.082 33 ^h 0.086 22 ^h	0.003 40 ^h 0.002 09 ^h 0.001 76 ^h 0.001 93 ^h 0.002 16 ^h 0.001 60 0.001 76 ^h 0.002 03 ^h	0.0869 0.1443 0.1949 0.2033 0.2126 0.2026 0.2334 (0.2540) 0.1971 (0.1567)	0.9938 0.9844 0.9703 0.9660 0.9661 0.9688 0.948† (0.969) (0.965) 0.949†	0.9686 1,4529 1,9372 1,9372 1,9372 1,9372 2,4215 1,8676 1,8676 2,3519	0.8428 0.5619 0.4214 0.4214 0.4214 0.4214 0.3371 0.4371 0.4371	293.6 ^h 253.4 ^h 264.3 ^h 257.1 ^h 253.1 ^h 217.7 287.2 ^h 274.2 ^h 238.1	1.483 1.366 1.528 1.547 1.519	2.443 2.237 2.241(42) 2.238 2.296 2.241(43) 2.262 2.124 2.171	3
0.615 ^h 0.8850 0.8723 0.8721 0.8850 0.8691 0.8661 0.9115 0.8667	884.2 871.6 871.3 884.2 868.3 865.3 910.6 866.0	883.1 870.5 870.5 883.1 867.2 864.2 909.5 864.9	0.088 34 0.105 7 0.121 9 0.120 1 0.122 3 0.122 7 0.114 4 0.139 0	0.001 19 0.001 08 0.000 97 0.000 97 0.000 97 0.000 97 0.001 03 0.000 97	0.1893 0.2095 0.2633 0.3031 0.3113 0.3257 0.3214 0.1997 0.3260	0.9925 0.929† 0.903†	0.8990 2.6969 3.1812 3.6655 3.6655 3.6655 3.5959 4.1498	0.9081 0.3027 0.2566 0.2227 0.2227 0.2227 0.2227 0.2270 0.1967	267.6 223.7 194.0 196.9 193.4 192.7 206.7 170.4	1.659 1.014 1.085 1.168 1.218 1.163 1.157 1.133 1.219	1,715 1,677 1,721 1,741 1,696 1,708 1,724 1,732	4 4 4 4 4 4 4
0.7967 0.7922 0.7893 ^m 0.8226 ^h 0.7897 ^h 1.397 ^h	796.0 791.5 788.6m(34) 821.9h(35) 789.0h,*(36) 1396.h,*(36)	794.9 790.4 820.8 ^h 787.9 ^h	0.040 25 0.058 20 0.035 52m 0.053 55 ^h 0.043 19 ^h 0.045 89 ^h	0.001 17 0.001 07	0.5648 0.6608 0.0442 0.2667 0.0920 0.2548	0.9995 0.9943 0.9903 0.9801†	1.1063 1.5906 0.9671 1.5195 1.1765 2.2117	0.7379 0.5132 0.8441 0.5373 0.6939 0.3691	587.4 406.2 441.6 547.5 515.3	1.352 1.389 1.040 0.8330 0.9960 0.6062	2.08(36)	3
0.6183 ^h 0.856 ^m (36) 0.07106 ^m 1.1420 ^m (25) 0.8093 ^m (26) 1.426 1.000 0.1251 ^m 0.8538	617.7 ^{h,x} (30) 855. ^m 71.00 ^m (37)	616.6 ^h	0.027 57h 0.033 9m 0.028 39m 0.028 04m 0.034 64m 0.049 78 0.018 03 0.032 02m 0.042 74	0,000 14 0.006 03	0,2576 -0,219 th 0,0200 0,0372 0,0737 0,3434 0 0,1232	0.9899(30) 0.9996 1,0006 0.9993(39) 0.9897 (0.9875) [†] (36) 1.000 5(40)	0.5880 1.0000 0.0696 1.1048 0.9672 2.4481 0.6220 0.1382 1.2588	1.388 0.8163 11.73 0.7389 0.8441 0.3335 1.312 5.907 0.6485	475.0 1311. 553.2	2.079 1.005 14.24 0.9166 1.040 0.4760 1.862 5.192 0.7991	-	556666666666666666666666666666666666666


PHYSICAL CONSTANTS OF HYDROCARBONS(27)


	See Note No>		10.			11.	12.	13.	Flamma	bility		
			eating valu					-83	limits, in air m		octane	
No.	Compound	MJ/m ³ Z Ideal gas, 101,3250 kPa (abs)	MJ/m ³ Ideal gas, 101.3250 kPa (abs)	MJ/kg Liquid (Mass in vacuum)	MJ/m ³ Liquid (Mass in vacuum)	Heat of vaporization, 101.3250 kPa (abs) at boiling point, kJ/kg	Refractive index ^a , n _D	Air required for combus tion ideal gas " m ³ (air)/m ³ (gas)	Lawer	Higher	Motor method D-357	Research and method D-908
1 2 3 4 5	Methane Ethane Propane n-Butane Isobutane	33.936 60.395 86.456 112.384 112.031	37.694 66.032 93.972 121.779 121.426	51.586 ^h 50.008 ^h 49.158 ^h 49.044 ^h	18 458h 25 394h 28 718h 27 621h	509.86 489.36 425.73 385.26 366.40	1.214 04 ^h 1.219 05 ^h 1.332 92 ^h	9.54 16.70 23.86 31.02 31.02	5.0 2.9 2.1 1.8 1.8	15.0 13.0 9.5 8.4 8.4	+,05 ^f 97.1 89.6 ^f 97.6	+1.6/if +1.8/i,f 93.8/ +0.10/i,f
6 7 8	n-Pentane Isopentane Neopentane	138.380 138.044 137.465	149,654 149,319 148,739	48.667 48.579 48.427 h	30 709 30 333 28 896 ^h	357.22 342.20 315.34	1,360 24 1,356 58 1,345	38.18 38.18 38.18	1.4 1.4 1.4	8.3 (8.3) (8.3)	62.6 ^j 90.3 80.2	61.7 ^j 92.3 85.5
9 10 11 12 13	n-Hexane 2-Methylpentane 3-Methylpentane Neohexane 2,3-Dimethylbutane	164.402 164.075 164.188 163.683 164.025	177.556 177.229 177.341 176.836 177.179	48.344 48.273 48.300 48.191 48.269	32 091 31 749 32 303 31 512 32 157	334.81 322.52 325.82 305.24 316.50	1.377 46 1.374 17 1.379 18 1.371 57 1.377 59	45.34 45.34 45.34 45.34 45.34	1.2 1.2 (1.2) 1.2 (1.2)	7.7 (7.7) (7.7) (7.7) (7.7)	26.0 73.5 74.3 93.4 94.3	24.8 73.4 74.5 91.8 +0.3
14 15 16 17 18 19 20 21	n-Heptane 2-Methylhexane 3-Methylhexane 3-Ethylpentane 2,2-Dimethylpentane 2,4-Dimethylpentane 3,3-Dimethylpentane Triptane	190.398 190.099 190.243 190.327 189.630 189.803 189.885 189.690	205.431 205.132 205.276 205.359 204.662 204.836 204.918 204.722	48.104 48.051 48.082 48.101 47.964 48.000 48.019 47.982	33 095 32 809 33 249 33 796 32 520 32 501 33 488 33 319	316,33 306,06 307,27 308,94 291,03 294,41 295,87 288,90	1,390 17 1,387 43 1,391 19 1,395 94 1,384 75 1,384 08 1,393 42 1,391 96	52.50 52.50 52.50 52.50 52.50 52.50 52.50 52.50	1.0 (1.0) (1.0) (1.0) (1.0) (1.0) (1.0) (1.0)	7.0 (7.0) (7.0) (7.0) (7.0) (7.0) (7.0) (7.0)	0.0 46.4 55.8 69.3 95.6 83.8 86.6 +0.1	0.0 42.4 52.0 65.0 92.8 83.1 80.8 +1.8
22 23 24 25 26 27 28 29 30	n-Octane Disobutyl Isooctane n-Nonane n-Decane Cyclopentane Methylcyclopentane Cyclohexane Methylcyclohexane	216.374 215.797 215.732 242.398 268.396 131.114 156.757 156.034 181.567	233 286 232 709 232 644 261 189 289 066 140 509 168 032 167 308 194 720	47.919 47.832 47.843 47.783 47.670 46.955 46.825 46.606 46.525	33 865 33 372 33 299 34 485 34 985 35 225 35 278 36 497 36 997	301.26 285.69 271.44 288.82 276.06 389.20 345.51 365.95 317.03	1.399 81 1.394 88 1.393 92 1.407 73 1.414 11 1.409 27 1.412 40 1.428 92 1.425 66	59.65 59.65 59.65 66.81 73.97 35.79 42.95 42.95 50.11	0.96 (0.98) 1.0 0.87* 0.78* (1.4) (1.2) 1.3 1.2	2.9 2.6 8.35 7.8	55.7 100. 84.9 80.0 77.2 71.1	55.2 100. +0.1 ^f 91.3 83.0 74.8
31 32 33 34 35 36 37 38 39 40	Ethene (Ethylene) Propene (Propylene) 1-8utene (Butylene) cis-2-Butene trans-2-Butene 1-Pentene 1-Pentene 1,2-Butadiene 1,3-Butadiene 1soprene	55.942 81.482 107.475 107.191 106.957 106.755 133.465 104.118 101.917 127.330	59,700 87,119 114,991 114,707 114,473 114,271 142,860 109,755 107,555 134,846	48.081h 47.927h 47.843h 47.769h 47.788 47.504h 46.608h 46.408	30 055h 29 184h 28 685h 30 852 31 210h	482,77 437,68 390,60 416,10 405,56 394,18 359,25 (449,6) (418,7) (385,2)	1,374 61	14.32 21.48 28.63 28.63 28.63 28.63 35.79 26.25 26.25 33.41	2.7 2.0 1.6 (1.6) (1.6) (1.6) (1.6) 1.4 (2.0) 2.0 (1.5)	34.0 10.0 9.3 8.7 (12.) 11.5	75.6 84.9 80.8 ² 83.5 77.1 81.0	+0.03/ +0.2/ 97.4 100. — 90.9 — 99.1
41 42 43 44 45 46 47 48 49	Ethylbenzene o-Xylene m-Xylene p-Xylene Styrene	53.098 134.055 159.534 185.555 185.092 185.020 185.050 180.290 211.328	54.978 139.692 167.050 194.950 194.487 194.415 187.806 222.603	41.843 42.450 43.014 42.900 42.891 42.901 42.213 43.410	36 998 37 000 37 478 37 935 37 245 37 122 38 439 37 591	393.32 360.14 334.98 346.80 342.47 338.92 (351.23) 312.25	1.504 32 1.499 73 1.498 56 1.507 95 1.499 80 1.498 39 1.549 69 1.494 00	11,93 35,79 42,95 50,11 50,11 50,11 47,72 57,27	2.5 1.3# 1.2# 0.99# 1.1# 1.1# 1.1# 1.1 0.88#	80. 7.9g 7.1g 6.7g 6.4g 6.4g 6.6g 6.1 6.5g	+2.8/ +0.3/ 97.9 100. +2.8/ +1.2/ +0.2/ 99.3	+5.8 ^f +0.8 ^f +4.0 ^f +3.4 ^f >+3.1 ^f +2.1 ^f
50 51 52 53 54 55	Methyl alcohol Ethyl alcohol Carbon monoxide Carbon dioxide Hydrogen sulfide	28.601 54.062 11.959 0 21.912	32.360 59.699 11,959 0 23,791	22.685 29.707 —	18 057 23 513	1075.97 840.54 215.70 573.27 ⁿ 548.01 387.74	1,330 28 1,363 45 1,000 36 1,000 49 1,000 61 1,000 62	7.16 14.32 2.39 7.16	6.72(5) 3.28(5) 12.50(5) 4.30(5)	36.50 18.95 74.20 45.50		
56 57 58 59 60 61 62 63	Air Hydrogen Oxygen Nitrogen Chlorine Water Helium	17,301 10.230 — 0	20.121 12.091 — — — — — — —	= 0 =		1366. 214. 450.4 213. 204. 288.0 2257. 431.5	1,000 36 1,000 13 1,000 27 1,000 28 1,387 8 ⁹ 1,333 47 1,000 03 1,000 42	3.58 2.39 —	15.50(5) 4.00(5)	27.00 74.20		







7 Z= 18 Ad










Appendices 289











10000 m















Compressor Handbook:


Principles

and


Practice





METHANE





299

















17-33




Benedict-Webb-Rubin-Starling

Equation of State (1979)







Appendix D

Classification of Hazardous Atmospheres

Area classifications are divided into CLASS, DIVISION, and GROUPS. As shown in the following table:

	CLASS	Ī	IVISION		GROUP
1	Gases,	1	Normally	A	Acetylene (581 °F)
	Vapors		Hazardous	В	Hydrogen (968 °F)
	1			C	Ethylene (842 °F)
				D	Fuels such as:
					Methane (999 °F)
	ļ				Propane (842 °F)
					Butane (550 °F)
					Gasoline (536-880 °F)
					Naphtha (550 °F)
1	Gases,		Not Normally	Α	Same as Div. 1
	Vapors	1	Hazardous	В	Same as Div. 1
	-			C	Same as Div. 1
				D	Same as Div. 1
II	Combustible	1	Normally	E	Combustible metal
	Dust		Hazardous		dust
	İ			F	Carbonaceous dust
1					Resistivity $> 10^2$ and
				_	<10 ⁸ ohm-centimeter
				G	Carbonaceous dust
					Resistivity $> 10^8$ ohm-
<u> </u>			37 37		centimeter
		2	Not Normally	F	Carbonaceous dust
			Hazardous		Resistivity > 105 ohm-
					centimeter
TIT	D!l-:			G	Same as Div. 1
III	Easily				
	Ignitable				
	Fibers and				
	Flyings				

The above information has been extracted from NFPA 70-1990, National Electric Code. National Electric Code and NEC are Registered Trademarks of the National Fire Protection Association, Inc. Quincy, MA.

Appendix E

Air/Oil Cooler Specifications Check List

1. Site Conditions	
A. Location	C. Ambient Temperature Range
B. Altitude	Max Min
2. Type	
A. Vertical Horizontal	C. Louvers: With Without
A. Vertical Horizontal B. Indoor Outdoor	Drives: Electric Hydraulic
3. Number of Cooling Sections	
4. Section Gas Generator	
A. Oil Flow gpm	E. Oil Outlet Temp <u>140 F (60 C)</u>
A. Oil Flowgpm B. Heat Loa dbtu/hr	Other
C. Design Temp 300 F (150 C)	F. Allowable ΔP 5 psig (oil Side)
Other	
D. Design Presspsig	G. Type Oils: Specific Gravity
5. Section Power Turbine	
A. Oil Flow gpm	E. Oil Outlet Temp 140 F (60 C)
B. Heat Load btu/hr	Other
C. Design Temp 300 F (150 C)	F. Allowable ΔP 5 psig (oil Side)
Other	G. Type Oils:
D. Design Presspsig	Specific Gravity
6. Codes	
A. Design to ASME	C. API Std 661
Stamp Yes No	D. Customer Spec
B. Section VIII Boiler Code for	
Location	
7. Electrical Requirements	
A. Codes UL CSA	C. Available Power
B. Hazardous Area Classification	AC, Ph, Hz
Class, Div Group	DC
	Other
8. Fan Requirements	
A. Non-SparkingYes No	B. Manually Adjustable Pitch Blades Yes No
9. Drive Requirements	
A. Hydraulic Drives	B. Electric Drive Connection
Direct Connected	Direct Indirect
	Indirect Electric Drivebeltgear
10. Vibration Switch - Remote Resetable	
SPDT (for hydraulic drives)	DPDT (for electric drives)

10. Vibration Switch - Remote Resetable SPDT(for hydraulic drives)	DPDT (for electric drives)
11. Special Conditions A. Physical Location Wall Mounted Floor B. Louvers Required Inside Outside C. Louver Actuators - When Required To Be Fail-safe, Closing Outside Louvers	D. Actuator Temperature Control Switches E. Outside Louvers To Be Weather Tight F. Air Actuators To Be Tubed To Coupling On Radiator
A. Per Customer Spec B. Per Manufacturer Spec 13. Electrical Conditions A. Actuators, temperature controls, vibratio boxes to met electrical codes. B. Electric motor drives (and motor heater) radiator enclosure.	C. Vendor Standard Strainless Steel n switches to be wired to external junction to include conduit wiring to external surface of
A. Noise A. Noise levels to meet customer spec for field requirement 15. Hinged Access Door To Inlet Side Of Radiator	Purchaser
Thinged Access Bool To linet Side Of Radiator 16. Provision for floor drain of radiator enclosure box	
17. Support Legs Yes No	
18. Tube Bundles To Be Cleanable Turbulators Removable Type Of Fin Construction: Rolled In Tension Wound Welded "L" Other	Material: Steel with Aluminum Fins, Other Fouling Factor 0.0005 Std/Customers Spec
19. Hydraulic Pressure Available psig Other psig	
20. Glycol/Water Heating Coil By Spec (if re	quired)
21. Insulation By Spec (if required)	
22. Packaging For Shipment Per Spec	
23. Spare Parts List Required Yes N	0
24. Commercial Considerations A. Delivery Committment B. Progress Reports Yes No	C. Warrantees Std Other D. Sourcing

25 Drawings
A. Proposal Outline
B. Schedule For Approval Drawings (from date of order)
C. Schedule For Final Certified Drawings (from date of order)
26 Quality and Inspection
A. Witness and Inspection Notice
B. Shipping Release
C. Material Certification
D. Radiographic Requirements
27. Installation and Maintenance Manuals
A. Number Required
B. Delivery Required


Appendix F

Cylinder Displacement Curves

The following charts are provided as a shortcut method of determining cylinder displacement as a function of piston stroke and cylinder diameter. Curves are provided in both SI units and English units.


The charts have been provided courtesy of Petroleum Learning Programs, 305 Wells Fargo Drive, Suite 4, Houston, Texas 77090. Phone: (281) 444-7632, Fax: (281) 586-9876. E-mail: PetroLearning@aol.com.

SMALL DIAMETER COMPRESSOR CYLINDER DISPLACEMENT - SI UNITS




COMPRESSOR CYLINDER DISPLACEMENT CURVES FOR SMALL DIAMFTER CYLINDERS - SI UNITS

LARGE DIAMETER COMPRESSOR CYLINDER DISPLACEMENT - SI UNITS




COMPRESSOR CYLINDER DISPLACEMENT CURVES FOR LARGE DIAMETER CYLINDERS - SI UNITS





COMPRESSOR CYLINDER DISPLACEMENT CURVES FOR SMALL DIAMETER CYLINDERS - ENGLISH UNITS

LARGE DIA. COMPRESSOR CYLINDER DISPLACEMENT - ENGLISH UNITS



COMPRESSOR CYLINDER DISPLACEMENT CURVES FOR LARGE DIAMETER CYLINDERS - ENGLISH UNITS

Appendix G


Compressor Cylinder Lubrication

The following charts are provided to determine cylinder lubricating oil flow as a function of piston stroke, cylinder diameter, speed and the number of oil injection ports. Curves are provided in both SI units and English units.

The charts have been provided courtesy of Petroleum Learning Programs, 305 Wells Fargo Drive, Suite 4, Houston, Texas 77090. Phone: (281) 444-7632, Fax: (281) 586-9876. E-mail: PetroLearning@aol.com.


LUBRICATION SYSTEM

COMPRESSOR CYLINDER LUBRICATION - ENGLISH UNITS



LUBRICATION SYSTEM

COMPRESSOR CYLINDER LUBRICATION - SI UNITS



Appendix H

Troubleshooting Chart Positive Displacement Compressors

The following is a list of symptoms or problems that most frequently occur. The possible causes associated with each problem are listed with the most likely cause or causes first.

Sympton or Problem	Compressor Type	Possible Cause
Compressor Driver	All	a) Control malfunction
Fails to Start		b) Low or no oil pressure
Compressor Fails To	Recip	a) Cylinder pressurized
Rotate	Recip	b) Seized components (crankshaft, piston, crosshead, bearings)
	All	c) Control malfunction
No Crankcase Oil	All	a) Oil filter clogged
Pressure		b) Oil system not primed
		c) No oil in crankcase
		d) Air leak in Pump inlet line
		e) Oil pump assembly defective
Low Crankcase Oil	All	a) Worn bearings
Pressure		b) Oil pressure relief valve spring has inadequate spring tension
		c) Oil pressure relief valve plugged
		d) Low crankcase oil level
		e) Plugged suction strainer
High Crankcase Oil	All	a) Oil pressure relief valve spring has excessive spring tension
Pressure		b) Plugged oil pressure line
High Crankcase Oil	Ail	a) Cooling inadequate
Temperature		b) Low oil level c) Oil contaminated
		c) Oil contaminated d) Improper oil
No Gas Throughput	All	a) Controls inoperative
No Gas Throughput	Recip	b) Missing or defective valves
	All	c) Restricted suction line
Reduced Gas	All	a) Restricted suction line
Throughput	Recip	b) Worn, loose or missing valves
	Recip	c) Piston rings worn
	All	d) Control not operating property
	Recip	Open or defective VVP or suction valve unloader
Cylinder Overheating		a) Cooling insufficient
		b) Contamination in cooling water jacket or valve assemblies
		c) Broken valves or valve springs
	Recip	d) Piston rod packing too tight
		e) Piston, liner or cylinder wall scored
		f) Discharge pressure too high
		g) Suction pressure too low
rr: 1 75' 1	4.11	h) Insufficient lubrication
High Discharge	All	a) Control setting improper
Pressure	All	b) Discharge line partially blocked a) Control system defective
Low Discharge Pressure	All Recip	a) Control system defective b) Worn, loose or missing valves
riessure	Recip	c) Worn piston rings
	All	d) Compressor capacity too low relative to system demand
	All	a) Compressor capacity too low relative to system demand

SYMPTOM	Compressor	POSSIBLE CAUSE
	Type	
High Discharge	Recip	a) Worn, loose or missing valves
Temperature	All	b) Cooling insufficient
	All	c) Suction temperature too high
Broken Valves &	Recip	a) Incorrect assembly
Valve Springs	Recip	b) Foreign material or liquids
	Recip	c) Insufficient lubrication
Scored Cylinder Liner	Recip	a) Foreign material in cylinder
& Piston	Recip	b) Broken valves & springs
	Recip	c) Cylinder out-of-round
	Recip	d) Cylinder temperature too high
	Recip	e) Inadequate lubrication
High Intercooler	Recip	a) Broken or missing 2 nd stage (or higher) inlet valves,
Pressure (where		discharge valves
applicable)	Recip	b) Valve cage misaligned
	Recip	c) Worn piston rings in successive stages
	Recip	d) Worn cylinder liner in successive stages
	Ali	e) Suction pressure too high
Low Intercooler	Recip	Broken or missing 1 st stage inlet valves, discharge valves
Pressure		b) Piping leak in intercooler or interconnecting pipe
	All	c) Intercooler drain malfunction
	All	d) Worn 1st stage piston rings
	All	e) Piston rod packing leak
	Recip	f) Suction pressure too low
	All	
Knocking	Recip	a) Loose & cage
	Recip	b) Worn crosshead or crosshead liner
	Recip	c) Worn connecting rod bearings
	Recip	d) Liquids or foreign material in cylinder
	Recip	e) Head clearance incorrect
	Recip	f) Piston loose on piston rod
	Recip	g) VVP plug loose
Compressor Vibration	All	a) Compressor out of balance
	All	b) Installation or alignment improper
	All	c) Worn bearings
	Recip	d) Loose valve assemblies
Compressor	All	a) Compressor fouling
Performance Decrease	All	b) Foreign object damage
	All	c) Worm seals
Compressor Vibration	All	Foreign object damage
Imbalance	All	Compressor fouling
Compressor Axial Vibration	All	a) Coupling Misalignment
TIVIALIVII	1	1

Appendix I

Starting, Operating and Maintenance Procedures

CONTENTS

- Preparation for Start-up
- Operation
- Maintenance

PREPARATION FOR START-UP

Compressor

On units shipped with the cylinders and piston assemblies installed, it is necessary to check piston end clearances, piston rod run out, crosshead shoe clearances, and piston pin through-bolt torque and correct if necessary. Record these readings on the frame setting record sheet for future reference.

Remove the suction valves from each end of the compressor cylinders to permit the unit to run at no load for break in purposes. Reinstall and tighten the valve covers.

Remove the compressor crankcase cover and cross head inspection doors on the compressor. Inspect the compressor crankcase to insure that it is free of all dirt, water and long-term preservatives. Inspect the compressor oil filter cases for dirt, rust, etc. Clean the filter cases if needed.

Fill all cooling systems with coolant and bleed all air from the system. Allow the unit to sit for 2-3 hours then check inside the compressor cylinders for coolant leaks.

If not already installed, install the compressor oil filter element and filter top using a gasket if needed. Consult the instruction manual for the correct type and weight of oil to be used in the compressor crankcase.

Install oil in the compressor crankcase to the proper level. Using the prelube hand pump, prelube the compressor frame. Bleed all air from the compressor oil filter. Continue to prelube the compressor until oil is delivered to all lubrication points of the compressor frame. A visual check will determine if oil is reaching the main bearing, rod bearings, and crosshead assemblies.

After it has been established that the frame is lubricated properly, reinstall the crankcase top covers and the crosshead inspection doors.

Inspect the compressor lubricator reservoir for water that may have entered during shipping and storage. Clean the reservoir if needed. Check the lubricator drive for proper alignment and ease of operation. This is done by moving the lubricator oil pump coupling back on the oil pump shaft and rotating the oil pump by hand. If binding is found to exist, loosen the lubricator mounting bolts and move the lubricator from side to side or up and down until unit turns freely. Tighten lubricator mounting bolts and connect the compressor oil pump drive coupling to the oil pump drive shaft.

If the lubricator is not fed from the compressor frame be sure it is connected to a supply with the proper type and weight of oil, as recommended in the instruction manual, for the break-in of the compressor cylinders and packings and for the type of operation under which the compressor will be run.

Using the hand primers on lubricator pump or a suitable hand primer gun, prime and bleed all lubricator lines until they are free of air. Continue to hand prime the system until there is oil in the cylinder bore and packing cases.

Motor Check

See the motor section of the instruction manual for the manufacturer's instructions for start-up.

Auxiliaries

Fill all systems that require oil such as the mist lubricator for the starter and air/gas prelube pump motors.

Grease the cooler fan shaft and idler bearings, if needed.

Control Panel

Make a preliminary inspection of the operation of the control panel. During the break in period of the unit it may be necessary to "lock out" certain parts of the control system in order to keep the unit running. This depends on the type of panel used on the unit. Do not, under any circumstances, lock out the low oil pressure shutdowns or completely disable the panel and run the unit. Should a malfunction occur on the compressor during the break-in run, serious damage could occur before the unit could be shutdown by the plant operator.

See the panel section of the instruction manual for complete details.

Instrumentation

A point-to-point continuity check must be made for all wiring. Conduit seal fittings (if applicable) must be filled prior to start-up. Any instrumentation which was removed for shipping should be re-installed at this time.

Start-up Procedure

Start the unit and run for 5 minutes. Do not exceed the maximum number of motor starts per hour. Remove the compressor crankcase covers and check for any overheating of the crankcase main bearings rod bearing and crosshead assemblies. Reinstall the crankcase covers if no heating is found.

Restart the unit and run for 30 minutes. Note the compressor oil pressures, oil temperatures and monitoring device for main bearing temperatures if provided. Stop the unit and repeat the check for overheating of the compressor bearings, (and motor bearings) and other items listed in step 1.

Remove the suction valve covers and inspect the cylinder bore for oil, scuffing, and debris. Check the packing glands for overheating.

If there is no indication of overheating of the crankshaft, cylinder bores or packing glands, restart the unit and run for a second thirty minute period. Note the oil pressures and oil & water temperatures.

At the end of the second thirty minute period, stop the unit. Make a final inspection of the compressor crankshaft, main bearings, rod bearings, motor bearings, crosshead assemblies, rod packings and cylinder bores for overheating and proper lubrication. Inspect the bores of all cylinders for a glazing effect. If everything is found to be satisfactory, the unit can now be loaded. Install the suction valves and valve covers, and the crankcase cover.

After all valve covers, piping, etc., have been installed, open the unit suction valve and allow pressure to flow through the unit out the

blow down valve until the unit is adequately purged. Once all air is expelled, allow the pressure to build to 50 psi or normal suction pressure whichever is less. It is suggested that air be purged from the unit using nitrogen gas. Once all the air is adequately purged, then the nitrogen may be purged from the unit using the process gas.

Lubrication & Cooling

The complete lubricating system of the compressor may be conveniently divided into three parts of equal importance. Complete protection of all frame running parts is provided by lube oil from the frame sump. A separate, independent, force feed lubricator and tubing system provides lubrication for cylinder walls and piston rod packing. A shell-and-tube cooler is provided for frame oil cooling.

Lubricating Oil Requirements

A good mineral oil which provides resistance to oxidation and corrosion is generally satisfactory for lubrication in a reciprocating compressor which has its crankcase sealed off from the cylinders. However, there is no objection to the use of a detergent type oil if this is more readily available. The best assurance of obtaining a suitable oil is to use only products of well known merit, produced by responsible concerns, and used in accordance with their recommendations. Do not permit your compressor to be used as an experimental unit for trying out new or questionable lubricants.

In some cases it may be convenient or practical to use the same type oil in the compressor as is used in the compressor drive engine. This is permissible as long as the engine oil is of proper viscosity.

If start-ups are to take place when ambient temperatures are below freezing, the **pour point** of the oil must be low enough to insure flow to the oil pump. Heavier oil should be heated before starting.

If a compounded oil is used, the non-corrosiveness of this oil must be looked into very carefully. The oil must not contain substances which might be injurious to tin or lead base babbitts and it is also highly desirable that it be non-corrosive to copper-lead alloys.

Mechanical Check List

- 1. Compressor jack screws are backed off after grout has set up
- 2. Compressor anchor bolts are properly torqued.
- 3. Check Coupling Alignment.
- 4. Motor anchor bolts are properly torqued.

- 5. Check tightness of adapter plate bolts to flywheel and sheave (if applicable).
- 6. After cylinder is mounted on compressor. Jam nuts are properly tightened.
- 7. Check packing gland for clearance. (Record Clearance)
- 8. Packing bolts are tight.
- 9. Torque crosshead pin bolts. Procedure to torque these bolts are:
 - a. Torque the bolts
 - b. Tap the bolt with a hammer
 - c. Re-torque the bolt.
- 10. Check and record cross head clearance.
- 11. Record piston end clearance.

OPERATION

Preparation for Initial Start-up

CAUTION

READ THIS PROCEDURE AND FAMILIARIZE YOURSELF WITH THE COMPRESSOR AND ITS AUXILIARY EQUIPMENT PLUS YOUR COMPANY SAFETY PROCEDURES BEFORE ATTEMPTING TO START THIS MACHINERY.

The following procedure is suggested before starting the unit for the first time, or after overhaul, or after a long period of idleness.

- Remove the top cover of the base and the covers for the crossheads and distance pieces on each crosshead guide. Check for cleanliness before adding lube oil to the base. Be sure that no dirt, cuttings, water, etc., are allowed to remain.
- Remove a valve from each end of each compressor cylinder. Rotate
 the compressor slowly and check for piston-to-head clearances.
 Make sure all parts move freely. Check that all valves are installed
 property.

CAUTION

BEFORE REMOVING ANY GAS CONTAINING PART OF THE COMPRESSOR OR ASSOCIATED PIPING SYSTEM, VENT THE COMPRESSOR AND SYSTEM TO ATMOSPHERE.

- 3. Add lubricating oil to the base and to the lube oil filter.
- 4. Check the force feed lubricator for cleanliness and fill to the proper level with oil.
- 5. Adjust all force feed lubricator pumps to full stroke for cylinder and packing break-in.
- 6. Disconnect ends of force feed lubricator lines as close as possible to cylinders and cross head guides. Hand pump the lubricators to fill lines and eliminate air.
- 7. Connect the force feed lubricator lines and operate pumps ten more strokes to force oil into cylinders and rod packing.

CAUTION

HIGH PRESSURE OIL STREAM MAY PUNCTURE SKIN. USE PROPER WRENCH AND KEEP HANDS AWAY FROM IMMEDIATE POINT WHERE CONNECTION IS PURGING AIR.

- 8. Prime the system with the lube oil priming pump.
- 9. Hand lubricate the piston rod next to the packing.
- 10. Replace all covers with their respective gaskets and tighten screws according to torque chart. Distance piece covers may be left off to check for packing leaks on start up if gas is not sour gas.
- 11. Check to see that all crosshead guides or distance pieces and packings are vented individually and with proper size vent lines.
- 12. Unload the compressor for start-up.
- 13. Check to be sure all guards are in place.

Initial Start-up

- 1. Open the valves supplying water to the compressor cooling system (when required).
- 2. Start up and operate the unit under no-load conditions at reduced speed where possible (i.e., engine driven units). Check the oil pressure. When the compressor is started, an oil pressure of 20 psi must be experienced within 5 seconds or the compressor must be immediately shut down. Do not restart until adequate oil pressure can be assured.
- 3. After running the unit 15 to 20 minutes, shut down and check all bearings and packings for high temperature.
- 4. Check piping for oil or water leaks.
- 5. Start up again and run for approximately 20 to 30 minutes. Add oil to the crankcase to bring the oil level (while running) up to the

- middle of the sight glass. Shut down and recheck as above.
- 6. Start the unit and bring it up to full rated speed. Apply the load.
- 7. During the initial period of operation, pay close attention to the machine for any unusual high temperature, pressure, or vibration. In the event of equipment malfunction where excessive vibration, noise, high temperature, or any other dangerous condition exists, the compressor should be stopped immediately.

WARNING

IF COMPRESSOR HAS BEEN STOPPED, DO NOT IMMEDIATELY REMOVE EQUIPMENT COVERS. ALLOW THE UNIT TO COOL DOWN TO PREVENT POSSIBLE EXPLOSION DUE TO IN RUSH OF AIR, AND TO PREVENT INJURY WHICH MAY BE CAUSED BY HOT SURFACE.

Normal Start-up

Not all of the instructions provided for initial start-ups are required for routine starting. The following notes comprise the normal starting procedure:

- 1. Unload the compressor.
- 2. Operate the force feed lubricator pumps, by hand, for ten strokes. (Be sure the lubricator tank is kept full).
- 3. Hand prime the frame lube oil system.
- 4. Turn on cooling water supply.
- 5. Start the unit. Check frame lube oil pressure.
- 6. Operate at low speed (where possible) and no load for several minutes. Check force feed lubricator sight glasses for feed. Check lube oil for proper level at sight gauge.
- 7. Bring up to rated speed and apply load.

Normal Shutdown

Before shutting the unit down, it is good practice to unload the compressor and reduce speed (where possible).

Emergency Shutdown

WARNING

IF COMPRESSOR HAS BEEN STOPPED, DO NOT IMMEDIATELY REMOVE EQUIPMENT COVERS. ALLOW THE UNIT TO COOL DOWN TO PREVENT POSSIBLE EXPLOSION DUE TO IN RUSH OF AIR, AND TO PREVENT INJURY WHICH MAY BE CAUSED BY HOT SURFACE.

Recommended Operating Conditions

For compressor operating speed ranges, refer to Compressor Performance Data Sheet.

WARNING

IMPROPER SETTING OF VARIABLE VOLUME POCKETS, FIXED VOLUME POCKETS, VALVE UNLOADERS OR OTHER UNLOADING DEVICES CAN RESULT IN DANGEROUS OPERATION AND POSSIBLE DAMAGE AND/OR INJURY TO EQUIPMENT OR PERSONNEL OPERATING THIS UNIT WITHOUT CLEARANCE AND LOADING INFORMATION CAN RESULT IN FAILURE DUE TO. OVERLOADING, EXCESSIVE ROD LOADS OR HIGH TEMPERATURE.

MAINTENANCE

General

The diligent observation of the inspection and maintenance procedure, given in this section, will go a long way toward insuring satisfactory operation of the compressor. Good preventative maintenance practice includes a periodic check of critical bolt torques, such as compressor main and connecting rod bolts and flywheel & sheave bolts. The recommended schedule should be followed:

- 1. One (1) month after the unit is placed into service.
- 2. Six (6) months after the unit is placed into service.
- 3. At least once every twelve (12) months thereafter.

This schedule should be repeated after each compressor overhaul. During the first 300 hours of operation, the compressor should be checked frequently. Check bearings and packings for excessively high temperatures, and look over the complete unit for oil or water leaks.

Constant care in maintaining the machine in clean condition will payoff in time, labor, and repair costs. Inspect and clean the unit at regular intervals.

When repair or inspection inside the covers of the frame or cylinders is required, use only clean, lint-free rags. Lint or loose threads may cause clogging of lubrication lines or filters and result in major troubles. All tools and work places should be kept free from grit, dust or dirt.

WARNING

WHEN WORK IS BEING DONE ON THE COMPRESSOR, THE ELECTRIC MOTOR MUST BE BLOCKED IN SUCH A WAY THAT THE COMPRESSOR CANNOT TURN OVER. VALVES MUST BE CLOSED ON THE SUCTION AND DISCHARGE LINES. AIR OR GAS MUST BE BLED OFF FROM THE CYLINDERS. PRECAUTION MUST BE TAKEN TO PREVENT THE OPENING OF ANY VALVE WHICH WOULD RELEASE PRESSURE AGAINST A PISTON, CAUSING IT TO ROTATE THE UNIT AT A CRITICAL MOMENT.

The following paragraphs contain information about the various assemblies that go to make up the complete compressor assembly. The conscientious operator will obtain valuable knowledge by a thorough reading of this material from time to time.

BASE (Crankcase)

The base is made of high strength iron and is heavily reinforced for maximum rigidity. Removable top and end covers provide access to all moving parts and the open top design allows easy crankshaft removal. Drilled lubrication passages in the base should be carefully cleaned at overhaul.

Crankshaft and Main Bearings

The complete crankshaft assembly includes the oil slinger. The crankshaft is rifle-drilled to carry lubrication from the main bearing to the connecting rod bearing. Plain and thrust main bearing shells are of the split, non-adjustable, precision type.

New upper and lower plain main bearing shells are interchangeable. However, after the compressor has been run, it is preferable that the shells be placed back in their original position after removal for any cause. Therefore, the bearing shells should be so marked.

NOTE

Use pencil markings only on the parting line faces of bearing shells or in the bearing grooves.

Carefully clean the crankshaft and bearing shells and saddles before attempting to replace the bearing shells. Under no circumstances should any filing, scraping, or other fitting be done on either bearing shells or saddles. The bearing cap nuts should be tightened uniformly (criss-cross method) to the proper torque.

Connecting Rods

The connecting rod is a steel forging, rifle-drilled to provide lubrication to the crosshead pin bushing. The cap and rod are match-marked, and a complete assembly must be ordered if replacement is necessary.

The upper end of the connecting rod carries a pressed-in bushing. This bushing has a large oil groove both inside and outside at its midpoint, with communicating holes to admit oil from the connecting rod to the crosshead pin. The inside diameter of the bushing has equally spaced, helical oil spreader grooves to insure adequate lubrication between bushing and crosshead pin. This bushing is precision bored after assembly in the rod to insure proper size and location. If these bushings are replaced in the field, extreme care should be used in maintaining the bore of the new bushings parallel to and properly spaced from the crankpin bore.

THE CAPS AND RODS ARE MATCH-MARKED. NUMBERED BY THROW AND HAVE THEIR RESPECTIVE WEIGHTS STAMPED ON. ALWAYS INSTALL RODS WITH THIS INFORMATION UP. The rod cap is removed and replaced while the crank throw is in the outer position and the rod itself can be eased into or out of position with the crank throw slightly below the inner position.

Crosshead Guides

The crosshead guides have lubrication holes with metering fittings for both top and bottom slides. BLOCKING OF THESE FITTINGS MAY CAUSE THE CROSSHEAD SHOES TO HEAT UP AND SEIZE.

The nuts and capscrews holding the guide to the base must be torqued evenly (criss-cross method) to prevent cocking of the guide relative to the base and crankshaft. Large side covers on the guide allow easy access to the crosshead, connecting rod, and rod packing. The crosshead can be removed through these openings without disturbing the cylinder mounting.

Crosshead—Removal and Installation

The crosshead is made of ductile iron and has removable top and bottom steel backed shoes with durable bearing material on the sliding surface. Flat head screws and locknuts hold the shoes firmly in place, and these must be torqued evenly. Like the main bearings maintenance, cleanliness is an important factor during the assembly of shoes to crosshead and crosshead to guide.

Cylinder Body

The cylinder body is provided with drilled water passages, top and bottom, which connect the water inlet and outlet with the cooling source. Whenever the water jacket covers on the cylinder sides are removed to clean out deposits, the drilled passages should also be cleaned out. If the pipe plugs in the crank end of the drilled passages are removed, they should be coated with good waterproof sealer and replaced. This will prevent water seepage into the atmospheric vent space.

Lube oil, from the force feed lubricator tubing system, passes through a check valve and into a fitting on the outside of the upper flange of the cylinder. From here, the flow is through the wall of the discharge flange, into a tube and fitting assembly which connects to a drilled passage near or at the top of the cylinder bore. Cylinders have two point lubrication, one in the upper flange and one in the lower flange. During general overhaul the oil hole for cylinder bore lubrication should be cleaned out and all steel tubing checked for soundness and tightness.

Cylinder Head

The gasket, which is used to seal the cylinder head to the cylinder body, may be re-used only if a new one is not available. However, if possible, a new gasket should be fitted if the head has been removed after a period of running. The water seal grommets should also be replaced at the same time.

Pistons, Piston Rings and Piston Rod

The piston to rod nut is torqued after locking two crosshead nuts on the crosshead end of the rod and clamping them in a large vise. (If the piston is unusually heavy, provide some kind of support during this operation.). <u>DO NOT</u> clamp onto the piston rod. The piston nut may also be torqued when rod and piston are in place and the rod is locked in the crosshead.

The piston end clearance is adjusted by mounting the head and measuring the clearance on both ends with a feeler gauge. Check these clearances with the crosshead nut snugged down. If adjustment is necessary, loosen crosshead nut, remove cylinder head and turn piston and rod assembly. Once again <u>DO NOT</u> use wrenches on rod shank; do all turning of piston rod through the piston to rod nut.

Piston rings are designed with proper end clearance. However, it

is a good idea to check this in the cylinder. Rings should be square in the bore when checking.

Piston Rod Packing

The purpose of piston rod packing is to prevent the loss of gases from the cylinder along the piston rod. During initial operation a packing may leak or tend to overheat. This is a temporary condition while the rings are properly mating to the rod and case. As a general guide, a temperature in excess of that which can be tolerated by resting the hand on the packing flange will indicate too fast a rate of wearing in. The nominal rate of lubrication for the piston rod packing is specified by the manufacturer. However, definite lubrication rates and time intervals for wearing-in of the packing are difficult to prescribe here. Experience has indicated that these factors may vary widely on different applications. If there is concern for proper lubrication rate contact the manufacturer's representative.

Rod packing must be removed and replaced as a complete unit. This is possible after first removing the cylinder head, unlocking the crosshead nut and screwing the piston rod out of the crosshead. Leave the crosshead in the guide and bar compressor over until crosshead moves to inner dead center position to allow removal of the packing. Pull rod (with split sleeve over threads) through the packing until it clears. Disconnect tube fittings and remove screws holding packing to cylinder.

When disassembling a packing, always carefully note and record the position of each packing cup and each ring, and the direction each ring faces. Ordinarily, packing cups and glands are not subject to severe wear. It is, therefore, possible to make repairs by ordering only a set of new rings. It is always good practice to keep complete spare sets of new rings for the packing assembly.

Before installing a new packing assembly, it is important that the piston rod be carefully checked. If the rod is worn, rough, pitted, or has a taper, it must be replaced. The packing cups and gland, and all parts that are not replaced by new parts, must be soaked and thoroughly cleaned in a non-acid solvent. They should then be blown dry and examined closely for unusual nicks or burrs which might interfere with the rings free floating or contact with the rod. Particular care must be taken with rings made of soft metals and it is very important that wiper rings be handled and installed carefully to prevent damage to the scraping edges.

The rings must be placed in the packing cups in the same position

(facing original direction) as the original set.

The stuffing-box bore for the rod packing must be cleaned and examined for burrs. If found, burrs should be carefully and completely removed. A new metallic gasket should be placed in the groove of the packing cup which seats in the stuffing box.

When installing a new or rebuilt packing assembly, the attaching screws must be tightened uniformly. The gasket must not cock or bind and the assembly must seat squarely in the bore.

NOTE

The packing case flange must not contact the cylinder body. Clearance must exist at this point to ensure pressure is applied to the seal ring when packing screws are tightened.

Before connecting the tubing to the packing flange, hand pump the force feed lubricator until oil runs from one of the disconnected tubes. Connect this tube to the respective hole in the packing flange and continue to pump lubricator 12 to 15 more strokes. Connect vent tubing. With split sleeve still on the rod threads, insert the piston rod (with piston still assembled thereon) back through the cylinder head opening and through the packing assembly. Remove the split sleeve, add the crosshead nut, and thread the piston rod back onto the crosshead.

Valve Installation

Suction and discharge valves must be installed in the proper direction. This can be determined by first inspecting the valve to see which direction the springs push the valve plates closed.

The gas will flow in the same direction that the valve plate moves when it compresses the spring toward the center of the cylinder. The discharge valves are installed with the springs away from the center of the cylinder.

Valve Replacement

WARNING

BEFORE REMOVING ANY GAS CONTAINING PART OF THE COMPRESSOR OR ASSOCIATED GAS PIPING SYSTEM, VENT COMPRESSOR AND SYSTEM TO ATMOSPHERIC PRESSURE.

Proceed with valve removal in the following manner:

1. Loosen bolts or nuts holding valve cap. DO NOT remove completely until cap is pulled out far enough to vent any pressure trapped under cap.

- 2. Remove valve cap. Inspect O-ring; replace if defective.
- 3. Loosen setscrew in valve retainer (bottom valves only); insert threaded puller into valve retainer and remove.
- 4. Using threaded valve puller, remove valve from seat in cylinder.
- 5. Remove gasket, inspect and replace as needed.
- 6. Clean the gasket surface on valve and in valve pocket. Use new or a good gasket.
- 7. Place valve in pocket, FACING PROPER DIRECTION.
- 8. Locate the retainer on top of the valve assembly and grease or oil the O-ring of the valve cap forcing the cap into place by torquing the nuts or screws evenly.

NOTE

The valve cap flange must not contact the cylinder body. Clearance must exist at this point to insure that pressure is applied to the valve and retainer gaskets when the valve cap bolts or nuts are tightened.

To <u>replace a valve into a bottom port</u> (this is a discharge port), proceed as follows:

- 9. Invert retainer. Place valve on top of retainer with valve guard facing out (away from cylinder). Slip gasket on valve assembly.
- 10. Lift the complete works up into the bottom port, making sure that the valve seat enters first.
- 11. Tighten the retainer setscrew just enough to hold everything in place.
- 12. Lubricate valve cap O-ring.

NOTE: At the completion of any maintenance, it is important to bar the compressor crankshaft over, at least one complete revolution, to check for adequate running clearances.

RECOMMENDED COMPRESSOR MAINTENANCE SCHEDULE

				Semi-	Annually or
Controls	Daily	Weekly	Monthly	Annually	As Needed
Perform safety shutdown checks				X	
Note and record panel gage					
readings	X				
Check calibration of all					
thermometers and pressure gages				X	

Lubrication System	Daily	Weekly	Monthly	Semi- Annually	Annually or As Needed
Check oil levels; oil level regulator, oil level sight gage	X	.,			
Check lubricator line connections for leakage	X				
Inspect frame, lubricator and packing cases for leakage		Х			
Clean and/or replace crankcase breather(s)				X	
Check compressor force feed lubricator pump(s) for proper quantity output				X	
Take compressor oil sample for analysis			X		
Change compressor oil and oil filters	after t change Extend analysi Change	he initial -out can b oil chan s company c lube oil f	400 hour be increased ges to lor y recomme	s run time d to 1000 h nger interva nds continu	Id be changed e. Thereafter, your intervals als if the oil ed use of oil. al pressure of
Replace O-rings					X

Mechanical/Operator System -				Semi-	Annually or
Cylinder	Daily	Weekly	Monthly	Annually	As Needed
Note and record inlet temperatures	X				
Check for loose cylinder mounts,					
piping connections, supports		X			
Note and record cylinder discharge					
temperatures	X				
Hand check suction valve covers					
for coolness	X				
Listen for unusual noises	X		L		

Mechanical/Operator System – Cylinder (continued)	Daily	Weekly	Monthly	Semi- Annually	Annually or As Needed
Check temperatures of coolant to and from cylinders and lube oil cooler, packings	X				
Check one compressor valve of each stage, inspect for broken plates or springs, trapped liquids or solids				X	
Remove the distance cover piece or crosshead guide cover to inspect packing on each piston rod				X	
Remove the first stage head-end piston to check cylinder bore, piston rings, piston, rod and rod bearing condition					X

Mechanical/Operator System -				Semi-	Annually or
Frame	Daily	Weekly	Monthly	Annually	As Needed
Check crosshead clearances					
Check crosshead guide for wear					
metals					
Check foundation bolt torques					
Check compressor coupling for					
proper alignment					
Visually inspect frame interior for					
bearing material in frame, gear					
tooth condition, crosshead shoe					
and guide condition					
Roll out compressor thrust lower					
main shell for inspection					
Check compressor accessory drive					
gear back-lash and condition					

Appendix J

Basic Motor Formulas And Calculations

The following formulas are provided courtesy of Baldor Electric Company to assist the reader in selecting the proper motor driver for his compressor application.

The Baldor Electric Company is located at 5711 R.S. Boreham, Jr. St., Fort Smith, AR 72901. Phone: (479) 646-4711 ext.5123. Fax (479) 648-5281. Web Site www.baldor.com

BASIC MOTOR FORMULAS AND CALCULATIONS

The formulas and calculations which appear below should be used for estimating purposes only. It is the responsibility of the customer to specify the required motor Hp, Torque, and accelerating time for his application. The salesman may wish to check the customers specified values with the formulas in this section, however, if there is serious doubt concerning the customers application or if the customer requires guaranteed motor/application performance, the Product Department Customer Service group should be contacted.

Rules of Thumb (Approximation)

At 1800 rpm, a motor develops a 3 lb.ft. per hp

At 1200 rpm, a motor develops a 4.5 lb.ft. per hp

At 575 volts, a 3-phase motor draws 1 amp per hp

At 460 volts, a 3-phase motor draws 1.25 amp per hp

At 230 volts a 3-phase motor draws 2.5 amp per hp

At 230 volts, a single-phase motor draws 5 amp per hp

At 115 volts, a single-phase motor draws 10 amp per hp

Mechanical Formulas

Torque in lb.ft. =
$$\frac{\text{HP x 5250}}{\text{Rpm}}$$
 HP = $\frac{\text{Torque x rpm}}{5250}$ rpm = $\frac{120 \text{ x Frequency}}{\text{No. of Poles}}$

Temperature Conversion

Deg C =
$$(Deg F - 32) \times 5/9$$

$$Deg F = (Deg C \times 9/5) + 32$$

High Inertia Loads

$$t = \frac{WK^2 \times rpm}{308 \times T \text{ av.}}$$

$$T = \frac{WK^2 \times rpm}{308 \times t}$$

$$WK^2 = \text{inertia in lb.ft.}^2$$

$$t = \text{accelerating time in sec.}$$

$$T = Av. \text{ accelerating torque lb.ft.}$$

inertia reflected to motor = Load Inertia $\left(\frac{\text{Load rpm}}{\text{Motor rpm}}\right)^2$

Synchronous Speed, Frequency and Number of Poles of AC Motors

$$\frac{n_s = 120 \times f}{P} \qquad \frac{f = P \times n_s}{120} \qquad \frac{P = 120 \times f}{n_s}$$

Relation between Horsepower, Torque, and Speed

$$HP = \frac{T \times n}{5250}$$
 $T = \frac{5250 \text{ HP}}{n}$ $n = \frac{5250 \text{ HP}}{T}$

Motor Slip

% Slip =
$$\frac{n_s - n}{n_s}$$
 x 100

Code	KVA/HP	Code	KVA/HP	Code	KVA/HP	Code	KVA/HP
A	0-3.14	F	5.0 -5.59	L	9.0-9.99	S	16.0-17.99
В	3.15-3.54	G	5.6 -6.29	M	10.0-11.19	T	18.0-19.99
C	3.55-3.99	Н	6.3 -7.09	N	11.2-12.49	U	20.0-22.39
D	4.0 -4.49	I	7.1 -7.99	P	12.5-13.99	V	22.4 & Up
E	4.5 -4.99	K	8.0 -8.99	R	14.0-15.99		

Symbols

I = current in amperes

E = voltage in volts

kW = power in kilowatts

kVA = apparent power in kilo-volt-amperes

HP = output power in horsepower

n = motor speed in revolutions per minute (RPM)

ns = synchronous speed in revolutions per minute (RPM)

P = number of poles

f = frequency in cycles per second (CPS)

T = torque in pound-feet EFF = efficiency as a decimal PF = power factor as a decimal

Equivalent Inertia

In mechanical systems, all rotating parts do not usually operate at the same speed. Thus, we need to determine the "equivalent inertia" of each moving part at a particular speed of the prime mover.

The total equivalent WK² for a system is the sum of the WK² of each part, referenced to prime mover speed.

The equation says:

$$WK_{EQ}^2 = WK_{part}^2 \qquad \left(\frac{N_{part}}{N_{prime\ mover}}\right)_2$$

This equation becomes a common denominator on which other calculations can be based. For variable-speed devices, inertia should be calculated first at low speed.

Let's look at a simple system which has a prime mover (PM), a reducer and a load.

$$WK^2 = 900 \text{ lb.ft.}^2$$

$$WK^2 = 100 \text{ lb.ft.}^2 \qquad \text{(as seen at output shaft)} \qquad WK^2 = 27,000 \text{ lb.ft.}^2$$

$$PRIME MOVER \qquad 3:1 \text{ GEAR REDUCER} \qquad LOAD$$

The formula states that the system WK^2 equivalent is equal to the sum of WK^2_{parts} at the prime mover's RPM, or in this case:

$$WK_{EQ}^2 = WK_{pm}^2 + WK_{Red.}^2 \left(\frac{\text{Red. RPM}}{P_M \text{ RPM}}\right)^2 2 + WK_{Load}^2 \left(\frac{\text{Load RPM}}{P_M \text{ RPM}}\right)^2$$

Note: reducer RPM = Load RPM

$$WK_{EQ}^2 = WK_{pm}^2 + WK_{Red.}^2 \left(\frac{1}{3} \right)^2 2 + WK_{Load}^2 \left(\frac{1}{3} \right)^2$$

The WK² equivalent is equal to the WK² of the prime mover, plus the WK² of the load. This is equal to the WK² of the prime mover, plus the WK² of the reducer times $(1/3)^2$, plus the WK² of the load times $(1/3)^2$.

This relationship of the reducer to the driven load is expressed by the formula given earlier:

$$WK_{EQ}^2 = WK_{part}^2 \left(\frac{N_{part}}{N_{prime\ mover}} \right) 2$$

In other words, when a part is rotating at a speed (N) different from the prime mover, the WK^2_{EQ} is equal to the WK^2 of the part's speed ratio squared.

In the example, the result can be obtained as follows:

The WK² equivalent is equal to:

$$WK_{EQ}^2 = 100 \text{ lb.ft.}^2 + 900 \text{ lb.ft.}^2 \left(\frac{1}{3}\right)^2 + 27,000 \text{ lb.ft.}^2 \left(\frac{1}{3}\right)^2$$

Finally:

$$WK^{2}_{EQ} = lb.ft.^{2}_{pm} + 100 lb.ft.^{2}_{Red} + 3,000 lb.ft^{2}_{Load}$$

 $WK^{2}_{EQ} = 3200 lb.ft.^{2}$

The total WK^2 equivalent is that WK^2 seen by the prime mover at its speed.

Electrical Formulas

To Find	Alternating Current	
	Single-Phase	Three-Phase
Amperes when horsepower is known	HP x 746	HP x 746
	Ex Effxpf	1.73 x E x Eff x pf
Amperes when kilowatts are known	Kw x 1000	Kw x 1000
	Expf	1.73 x E x pf
Amperes when kva are known	Kva x 1000	Kva x 1000
	Е	1.73 x E
Kilowatts	I x E x pf	1.73 x I x E x pf
	1000	1000
Kva	ΙxΕ	1.73 x I x E
	1000	1000
Horsepower = (Output)	I x E x Eff x pf	1.73 x I x E x Eff x pff
	746	746

I = Amperes; E = Volts; Eff = Efficiency; pf = Power Factor; KVA = Kilovoltamperes; kW = Kilowatts

Locked Rotor Current (I_I) From Nameplate Data

Three Phase:
$$I_L = \frac{577 \times HP \times KVA/HP}{E}$$

See: KVA/HP Chart

Single Phase:
$$I_L = \frac{1000 \times HP \times KVA/HP}{E}$$

EXAMPLE:

Motor nameplate indicates 10 HP, 3 Phase, 460 Volts, Code F.

$$I_{L} = \frac{577 \times 10 \times (5.6 \text{ or } 6.29)}{460}$$

 $I_L = 70.25$ or 78.9 Amperes (possible range)

Effect of Line Voltage on Locked Rotor Current (I1) (Approx.)

$$I_L @ E_{LINE} = I_L @ E_{N/P} x \frac{E_{LINE}}{E_{N/P}}$$

EXAMPLE:

Motor has a locked rotor current (inrush of 100 Amperes (I_L) at the rated nameplate voltage ($E_{N/P}$) of 230 volts.

What is I_L with 245 volts (E_{LINE}) applied to this motor?

$$I_L @ 245 V. = 100 \times 254V/230V$$

 I_L @ 245V. = 107 Amperes

Basic Horsepower Calculations

Horsepower is work done per unit of time. One HP equals 33,000 ft-lb of work per minute. When work is done by a source of torque (T) to produce (M) rotations about an axis, the work done is:

radius x 2
$$\pi$$
x rpm x lb. or 2 π TM

When rotation is at the rate N rpm, the HP delivered is:

HP =
$$\frac{\text{radius x 2 } \pi \text{x rpm x lb.}}{33,000} = \frac{\text{TN}}{5,250}$$

For vertical or hoisting motion:

$$HP = \frac{W \times S}{33,000 \times E}$$

Where:

W = total weight in lbs. to be raised by motor

S = hoisting speed in feet per minute

E = overall mechanical efficiency of hoist and gearing. For purposes of estimating

E = .65 for eff. of hoist and connected gear.

For fans and blowers:

$$HP = \frac{\text{Volume (cfm) x Head (inches of water)}}{6356 \text{ x Mechanical Efficiency of Fan}}$$

Or

HP =
$$\frac{\text{Volume (cfm) x Pressure (lb. Per sq. ft.)}}{3300 \text{ x Mechanical Efficiency of Fan}}$$

Or

$$HP = \frac{\text{Volume (cfm) x Pressure (lb. Per sq. in.)}}{229 \text{ x Mechanical Efficiency of Fan}}$$

For purpose of estimating, the eff. of a fan or blower may be assumed to be 0.65.

Note: Air Capacity (cfm) varies directly with fan speed. Developed Pressure varies with square of fan speed. Hp varies with cube of fan speed.

For pumps:

$$HP = \frac{GPM \times Pressure \text{ in lb. Per sq. in. x Specific Grav.}}{1713 \times Mechanical Efficiency of Pump}$$

Appendices 347

Or

$$HP = \frac{GPM \times Total Dynamic Head in Feet \times S.G.}{3960 \times Mechanical Efficiency of Pump}$$

where Total Dynamic Head = Static Head + Friction Head

For estimating, pump efficiency may be assumed at 0.70.

Accelerating Torque

The equivalent inertia of an adjustable speed drive indicates the energy required to keep the system running. However, starting or accelerating the system requires extra energy.

The torque required to accelerate a body is equal to the WK² of the body, times the change in RPM, divided by 308 times the interval (in seconds) in which this acceleration takes place:

ACCELERATING TORQUE =
$$\frac{WK^2N \text{ (in lb.ft.)}}{308t}$$

Where:

N = Change in RPM

W = Weight in Lbs.

K = Radius of gyration

t = Time of acceleration (secs.)

WK² = Equivalent Inertia

308 = Constant of proportionality

Or
$$T_{Acc} = \frac{WK^2N}{308t}$$

The constant (308) is derived by transferring linear motion to angular motion, and considering acceleration due to gravity. If, for example, we have simply a prime mover and a load with no speed adjustment:

Example 1

PRIME LOADER

LOAD

$$WK^2 = 200 \text{ lb.ft.}^2$$

$$WK^2 = 800 \text{ lb.ft.}^2$$

The WK_{EO}^2 is determined as before:

$$WK^{2}_{EQ} = WK^{2}_{pm} + WK^{2}_{Load}$$

$$WK^{2}_{EQ} = 200 + 800$$

$$WK^{2}_{EO} = 1000 \text{ ft.lb.}^{2}$$

If we want to accelerate this load to 1800 RPM in 1 minute, enough information is available to find the amount of torque necessary to accelerate the load.

The formula states:

$$T_{Acc} = -\frac{WK_{EQ}^2N}{308t}$$
 or $\frac{1000 \times 1800}{308 \times 60}$ or $\frac{1800000}{18480}$

$$T_{Acc} = 97.4 \text{ lb.ft.}$$

In other words, 97.4 lb.ft. of torque must be applied to get this load turning at 1800 RPM, in 60 seconds.

Note that T_{Acc} is an average value of accelerating torque during the speed change under consideration. If a more accurate calculation is desired, the following example may be helpful.

Example 2

The time that it takes to accelerate an induction motor from one speed to another may be found from the following equation:

$$t = \frac{WR^2 \text{ x change in rpm}}{308 \text{ x T}}$$

Where:

T = Average value of accelerating torque during the speed change under consideration.

Appendices 349

t = Time the motor takes to accelerate from the initial speed to the final speed.

WR₂ = Flywheel effect, or moment of inertia, for the driven machinery plus the motor rotor in lb.ft.² (WR² of driven machinery must be referred to the motor shaft).

The application of the above formula will now be considered by means of an example. Figure A shows the speed-torque curves of a squirrel-cage induction motor and a blower which it drives. At any speed of the blower, the difference between the torque which the motor can deliver at its shaft and the torque required by the blower is the torque available for acceleration. Reference to Figure A shows that the accelerating torque may vary greatly with speed. When the speed-torque curves for the motor and blower intersect there is no torque available for acceleration. The motor then drives the blower at constant speed and just delivers the torque required by the load.

In order to find the total time required to accelerate the motor and blower, the area between the motor speed-torque curve and the blower speed-torque curve is divided into strips, the ends of which approximate straight lines. Each strip corresponds to a speed increment which takes place within a definite time interval. The solid horizontal lines in Figure A represent the boundaries of strips; the lengths of the broken lines the average accelerating torques for the selected speed intervals. In order to calculate the total acceleration time for the motor and the direct-coupled blower it is necessary to find the time required to accelerate the motor from the beginning of one speed interval to the beginning of the next interval and add up the incremental times for all intervals to arrive at the total acceleration time. If the WR² of the motor whose speed-torque curve is given in Figure A is 3.26 ft.lb.² and the WR² of the blower referred to the motor shaft is 15 ft.lb.², the total WR² is:

$$15 + 3.26 = 18.26 \text{ ft.lb.}^2$$

And the total time of acceleration is:

$$\frac{WR^2}{308} \left[\frac{rpm_1}{T_1} + \frac{rpm_2}{T_2} + \frac{rpm_3}{T_3} + \ldots + \frac{rpm_1}{T_9} \right]$$


$$t = \frac{18.26}{308} \Big[\frac{150}{46} + \frac{150}{48} + \frac{300}{47} + \frac{300}{43.8} + \frac{200}{39.8} + \frac{200}{36.4} + \frac{300}{32.8} + \frac{100}{29.6} + \frac{40}{11} \Big]$$

t = 2.75 sec.

Figure A

Curves used to determine time required to accelerate induction motor and blower

Accelerating Torques



Duty Cycles

Sales orders are often entered with a note under special features such as:

"Suitable for 10 starts per hour"

Or

"Suitable for 3 reverses per minute"

Appendices 351

Or

"Motor to be capable of accelerating 350 lb.ft.2"

Or

"Suitable for 5 starts and stops per hour"

Orders with notes such as these can not be processed for two reasons.

- The appropriate product group must first be consulted to see if a
 design is available that will perform the required duty cycle and,
 if not, to determine if the type of design required falls within our
 present product line.
- 2. None of the above notes contains enough information to make the necessary duty cycle calculation. In order for a duty cycle to be checked out, the duty cycle information must include the following:
 - a. Inertia reflected to the motor shaft.
 - b. Torque load on the motor during all portions of the duty cycle including starts, running time, stops or reversals.
 - c. Accurate timing of each portion of the cycle.
 - d. Information on how each step of the cycle is accomplished. For example, a stop can be by coasting, mechanical braking, DC dynamic braking or plugging. A reversal can be accomplished by plugging, or the motor may be stopped by some means then re-started in the opposite direction.
 - e. When the motor is multi-speed, the cycle for each speed must be completely defined, including the method of changing from one speed to another.
 - f. Any special mechanical problems, features or limitations.

Obtaining this information and checking with the product group before the order is entered can save much time, expense and correspondence.

Duty cycle refers to the detailed description of a work cycle that repeats in a specific time period. This cycle may include frequent starts, plugging stops, reversals or stalls. These characteristics are usually involved in batch-type processes and may include tumbling barrels, certain cranes, shovels and draglines, dampers, gate- or plow-positioning drives, drawbridges, freight and personnel elevators, press-type extractors, some feeders, presses of certain types, hoists, indexers, boring machines, cinder block machines, key seating, kneading, car-pulling, shakers

(foundry or car), swaging and washing machines, and certain freight and passenger vehicles. The list is not all-inclusive. The drives for these loads must be capable of absorbing the heat generated during the duty cycles. Adequate thermal capacity would be required in slip couplings, clutches or motors to accelerate or plug-stop these drives or to withstand stalls. It is the product of the slip speed and the torque absorbed by the load per unit of time which generates heat in these drive components. All the events which occur during the duty cycle generate heat which the drive components must dissipate.

Because of the complexity of the duty cycle calculations and the extensive engineering data per specific motor design and rating required for the calculations, it is necessary for the sales engineer to refer to the product department for motor sizing with a duty cycle application.

Last Updated September 1, 1998

Copyright ©2007, Baldor Electric Company. All Rights Reserved.

A	housing design 98
absolute velocity 19, 23	journals 33
acceleration 100, 101, 102	looseness 122
probes 100	shoe 122
accelerometers 100, 112	spans 98
acoustic resonances 194	belt driven 28
actual surge 88	blades 117, 119
adiabatic discharge temperature 54	vibration 19
adiabatic efficiency 12	bleed valves 69
altitude 54	blower 27
ambient pressure 65, 66	blowers 28, 81, 98, 125
ambient temperature 54, 65, 66	blow-off 108
American Petroleum Institute	boosters 27
Standard 618 98	borocilicate microfiber 58
amplitude 100	bottle unloader 45
analyzers 111	brake horsepower (BHP) 12, 39
angle of attack 16	
angle of deviation 21	C
annubar 112	camber line 21
antisurge protection 69	camber angle 21
approach factor 93	capacity control 73
Avogadro's Law 8	casing 99
axial 24, 81	pressure rating 98
component 17	centrifugal 24, 81, 131, 133, 135
compressor 15, 24, 25, 64, 82,	barrel compressor 99
97, 118, 119, 120	compressor 15, 22, 23, 24, 25,
	64, 69, 77, 98, 132, 137
В	forces 18, 19
balanced opposed compressor 51	characteristic speed curves 64
reciprocating 51	choke 70
separable 77	tube 199, 203
balance drum 99	chord 17
Barber, John 3	length 20
base plate 53	clearance pockets 178
resonance 101, 102	clearance volume 39, 56, 59, 70
bearing 51, 53, 70, 84, 99, 117, 126, 128	pockets 147

coalescing 125	throws 51
elements 58	crankshaft 32, 33, 36, 51, 53
compressibility 9, 69, 70	bearings 44
factor 10, 12, 20, 68, 93	journal 33
compression load 33	CR, compression ratio 12, 55, 56,
compression ratio (CR) 12, 56, 59,	59, 63, 68, 176
63, 68, 176	critical pressure 10
per stage 55	critical speed 60, 97
compression rings 39	critical temperature 10, 94
compressor 7, 29, 56, 63, 81, 115	crosshead 32, 33, 37, 51, 183, 184,
characteristic curve 17, 24, 25,	185, 188, 189, 190, 191
26, 63, 65, 70, 73, 74	cylinder interface 121
cylinders 53, 146	end 33
discharge pressure 119	guide 33, 35, 44, 184, 191
efficiency 24, 83, 117	pin 44
fouling 84	shoes 187
map 83	Ctesibius of Alexandria xi, 1, 2
piston 53, 122	C _v 106
pressure 7	cyclone separator 125
ratio 24, 83	cylinder 32, 37, 46, 51, 126, 147,
stall line 15	148, 149, 150, 151, 153, 154, 155,
throughput 39, 41, 44	158, 161, 162, 163, 164, 165, 166,
valves 125	168, 170, 172, 174, 177, 183, 184,
concave inlets 57	186, 187, 188, 189, 191, 192, 194,
concave surface 16	197, 199, 202, 206, 207, 216
concentric ring valve 211, 213, 214,	bore 37, 220
217	centerline 41
connecting rod 32, 33, 51, 53	clearance 218
contamination 119, 120	diameter 55, 56
converter 107	displacement curves 56
convex inlets 57	gas temperature 41
counterweight 37	head 56
coupling selection 98	liner 39
crankcase 33	loading 41
crank-end 33, 35, 37, 39, 121, 164	ports 216
collar 36	size 55
valves 122	toe 195
crankpin 33	valve cavity 41
bearings 44	

D Dalton's Law 11 density 93 design compression ratios 64 design conditions 54 diaphragms 117 differential pressure 68, 83 diffuser 22, 23 digital acoustic analysis 195 discharge 106 bottles 49, 197, 206 coefficient 93	efficiency 17, 84 electrical 116 electric control 105 electric motor 28, 52, 115 electric motor driven pump 46 enclosed 22 engine 53 entropy 11 equal percentage 105, 106 exit blade angle 21 exit flow angle 21
port 58	F
pressure 33, 54, 70, 83, 86, 93	factor Z 10
pulsation bottles 47, 194	finger type unloader 42, 43, 44
temperature 55	first law of thermodynamics 11
throttling 73	fixed blade row 20
control 75	fixed volume clearance pocket 174,
valve 39, 108, 121, 124, 213	179
cover temperatures 117	flexible shaft 97, 98
seats 56	floats 112
throttling 59, 60	flow 24, 67, 68, 77, 111, 112
distance piece 34, 35, 120, 164, 184	and horse power 79
double-acting pistons 37	coefficient 23, 24
drag 16, 17	orifice 68
dual variable control 86	squared 87
Dumball, John 3, 4	flutter 19, 214, 216, 218
DVA 214	forced-feed method 44
dynamic 63, 81, 115	fractional frequency whirl 98
compressor 15, 64, 70, 73, 74,	frame 32, 33, 51
108, 112, 119, 125	frequency 100
surge 125	fuel gas booster 77
displacement 85	
pressure drop 195	G
rotor stability analysis 98	gas compressibility 67
valve analysis 213	factor 12
	gas density 19
E	gas discharge pressure 54
effective flow area (EFA) 215	gas engine 52, 115

gas expansion factor 94	I
gas horsepower 12	Ideal Gas Law 7, 8
gas path analysis 117, 124	ideal head 23
gas pressure 70	impeller 22, 23, 24, 84, 98, 99, 117, 119
gas properties 54	inlet (eye) 22
gas suction pressure 54	inlet blade angle 21
gas suction temperature 54	inlet flow angel 21
gas turbine 52, 77, 115	inlet pressure 67
gate valve 105, 106	inlet temperature 119
gear 98	instruments 111
noise 101, 102	integral engine compressor 3, 31,
globe valve 105, 106	52, 53, 150
guide vanes 23, 73	integral engine compressors 157,
garde varies 25, 75	176
Н	reciprocating 98
harmonic resonance analysis 49	intercooler temperature 54
harmonics 193	I/P 107
head 10, 20, 24, 67, 68, 184	isolation valve 105
adiabatic 12	isometric piping 49
head-end 35, 37, 39, 77, 79, 80,	Bonieure piping 19
121, 174	J
bypass 41	journal 122
suction valve 178	bearing 33, 59
unloader 42, 43	bearing 60, 65
Hero of Alexandria 1	K
Hertz 102	kinetic energy 23
horsepower 15, 77	knife valve 105, 106
calculations 12	knock-out vessel 125
hydrates 70	k value of gas 56
hydrodynamic bearing 46, 98, 122,	R value of gas 50
129	L
whirl orbits 123	lateral 98
hydrodynamic journal bearing oil whirl 102	bending 98 modes 99
	level 112
hydrodynamic sleeve-type	lift 16
bearings 59	
hydrostatic testing 161, 165	linear 105, 106
	line booster 107
	liquid level 111

liquids 70, 125	0
load 51, 70	oil-flooded compressor 58
lobe 27	oil-free compressors 58
locknut 37	oil heater 46
looseness 101	oil reservoir 29, 33
lubrication 44, 217, 219	oil viscosity 217
oil 126, 129, 219, 220	oil wedge 98
rate 218	oil whirl 101
lubricity 126	oil wiper packing 35
	open 22
M	operating point 65, 82, 88
magnetic pickups 112	line 90
manometers 112	orbits 98
mass flow rate 9	orifice 112
mass in lb 100	plate 112
maximum motor current 86	original equipment manufacturer
mechanical 116	115
Mils 102	overall compression ratio 54
minimum suction pressure or	overspeed 69
temperature 86	
misalignment 101	P
molecular weight 8, 10, 63, 64, 67,	packager 115
68, 69, 70, 84, 93, 151, 218	packing 158
mole fraction 11	partial pressures 10
moles 8	passive gravity-feed method 44
mole weight 20	PEEK 212, 219
moving blade row 20	percent clearance 56
multi-cylinder balanced opposed	performance 116
compressor 31	problems 117
	piezometers 112
N	pinch valve 106
natural circular frequency 100	piping isometric 50
natural frequency 82, 97, 98	piston 29, 32, 33, 35, 37, 39, 42, 44,
natural lateral frequency 99	46, 51, 53, 56, 70, 98, 121, 122,
needle valve 106	148, 153, 155, 158, 165, 168, 176,
Newtons 32	184, 185, 186, 189, 190
non-synchronous precession 98	balance 37
	1:1 22
	diameter 33

rings 220	Q
rod 32, 34, 35, 37,51, 70, 120,	quick opening 105, 106
121, 168, 176, 183	
droop 35	R
nut 122	ratio control 87, 89
packing 220	ratio of specific heat 10, 54, 68
valve 106	reciprocating 29, 131
pitch 21	compressor 31, 47, 54, 59, 70,
Pitot tubes 112	73, 76, 79, 120, 121, 126, 128,
plates 40	129, 132, 133, 135, 136, 145, 146,
plate valve 41	174, 183, 194, 206, 212
plug 42	separable balanced opposed
type suction valve 177	52
type unloader 42, 76	valves 124, 211
valve 105, 106	reciprocating engine 28
pneumatic control 105	reciprocating linear motion 33
pocket unloader 41	reciprocating throughput 107
polytropic efficiency 68	recycle 106, 108
polytropic head 68, 87	control 73
poppet valves 40, 41, 165, 217	valve 77, 86, 137, 138, 139, 140
ported plate 218	control 76
valve 211, 213, 214, 215, 216, 217	reduced temperature and pressure
positive displacement 29, 85, 115	10
compressors 63, 70, 81	relative velocity 19
power loss 84	required flow capacity 54
power pistons 53	required horsepower 60
pressure 8, 63, 64, 70, 94, 111	required HP 55
ratio control 65	resistance temperature detectors
ratio differential 26	112, 113
relief valves 105	resonance 19
preventive maintenance 115	avoidance 194
primary oil pump 46	frequency 97, 98
process control 73, 105	Reynolds Number 93
proximity probes 100, 112	rider rings 189
pulsation bottle 27, 47, 157, 193, 195	rod 37, 70, 158, 165, 184, 187, 188, 189, 190
pulsation control 27, 48	damage 121
pulsation suppression devices 48	diameter 33
	load 32, 47, 155

nut 359	site conditions 54
packing 35	slide valve 58, 59, 73
reversal 47	smart transducers 113
run-out 184, 185, 186, 189, 190,	specific gas constant 8
191, 192	specific gravity 54, 94
sag 189, 190, 191	specific heat 63
Roots blower 2	ratio 12, 64, 70, 93
Roots, Philander and Francis 2	specific volume 8
rotary lobes 26	spectrographic vibration plot 102
rotating motion 33	speed 55, 64, 70, 98, 111
rotating stall 19, 82	speed control 59, 73
rotometer 112	split bearing design 46
rotor 60, 83, 98, 99	spring constant 100
imbalance 101	stage HP 55
lobe 59	stagger angle 21
shaft 100	stall 15, 17, 18, 19, 81
run-out 187, 192	limit 82
	line 82
S	margin 15, 82
safety valve 105	rotating 19
screw compressor 59, 73, 98, 125	static pressure drop 195
control 59	stators 83, 84
screws 57	steady state 82
scrubber 27, 125	operating 15
sealing rings 35	steam engine 52
seals 59, 70, 84, 117	steam turbine 52, 115
second law of thermodynamics 11	sticktion 213, 215, 218, 219, 220
seismic 112	stiff shaft 97, 98
probes 100	Stolze, Dr. Franz 3
seizing pulsation bottles 48	stone wall 15, 18
semi-enclosed 22	stop plate 219
sensors 111	stop surge algorithm 91
separable balanced opposed 116	stop surge line 95
compressor 52	stroke 39, 55, 56, 192
separable compressor 77	suction 27, 49, 106, 108, 117, 121
separable reciprocating	and discharge valves 199, 213
compressors 98	bottles 194, 197
shaft 84, 99	port 58
single-acting 37	pressure 33, 54, 68, 77, 79, 93

pulsation 47	Teflon rider rings 186
ring 213	temperature 8, 10, 63, 64, 67, 70,
strainers 219	111, 112
temperature 55, 68, 93	tension load 33
throttle valve 138	theoretical HP 55
valve 39, 60, 213	Thermal Expansion Factor 92
guards 56	thermocouples 112, 113
throttling 59, 60	thermodynamic analysis 115
unloaders 39, 41, 42, 73, 76,	thermodynamic laws 24
77, 132, 133	thermowells 113
plug type	throughput 84
finger type 41	control 73
supervisory control 131, 134, 140	thrust bearings 83
surge 15, 17, 26, 64, 65, 69, 81, 82,	tilt-pad bearing 123
85, 87, 91, 93, 112, 113, 117, 132,	tilt-pad designs 47
138	tilt-pad thrust bearings 59
avoidance algorithm 92	torque 36
avoidance line 91, 95	requirements 98
control 107, 113	torsional 98
line 88, 90, 95	analysis 52
map 88, 89	critical speed and response
limit 69, 70, 87	analysis 52
line 25, 64, 65, 66, 81, 88, 90, 95	natural frequencies 99
point 68	study 139
margin 75	total HP 55
point 74	total volume 8
region 86	transducers 112, 113
stop algorithm 92	transmitters 111
stop line 90	turbine meter 112
surging 83	turbocharger 28
surve avoidance line 90	turbulent flow 17
synchronization gears 57	
synchronous motor 177	U
system resistance 17, 63	undamped critical speed 98
curve 65	universal gas constant 8
	unloaders 174
T	unloading systems 146
tail rod 162	
tangential component 17	

V valve 39, 42, 105, 212, 213, 219 ball-type check valves 29 ball valve 105, 106 butterfly valve 105, 106 cages 165, 216 caps 165 check valve 105, 106, 108 choke valve 106 covers 121 cover temperature 124 dynamics 212 failure 70	variable or fixed volume pockets 79 variable speed drive 60 variable volume 174 pocket 126, 179, 180 velocity 100, 101, 102 diagrams 22 triangles 19 venturi meter 112 vibration 111, 112, 122 signature 117 volume booster 140 volume bottles 39
in bore 37	volume clearance pocket 155, 165,
-in-head 157	176
life 212	volume flow 98
lift 212, 216	volume pockets 39, 44, 73
out of bore 37	volumetric clearance 39
plate 42, 124	volumetric efficiency (Ev) 56
impact velocities 211	volumetric flow 9, 64, 83
lift 211	factor 93
type 211	VVP 128
pockets 151	
volume bottles 158	W
ports 56	water organ xi, 1, 2
seats 150	wear band 39
sequence 77	weight flow of the gas 12
trim 105, 106	whirl orbit 122
vanes 117	work 11
variable control 75	
variable frequency drive 132	Z
variable guide vanes (VGVs) 25, 74	Z, compressibility factor 55